Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HOCO U74

HOCO U74 Grand USB to Lightning Charging Data Cable User Manual

Introduction

This manual provides instructions for the proper use and care of your HOCO U74 Grand USB to Lightning Charging Data Cable. This cable is designed for efficient charging and reliable data synchronization between your Apple devices (with a Lightning port) and USB-A compatible power sources or computers.



Figure 1: The HOCO U74 Grand USB to Lightning Cable, showcasing its braided design and metallic connectors.

Setup

Follow these steps to set up your HOCO U74 Grand cable for use:

1. **Unpack the Cable:** Carefully remove the cable from its packaging. Inspect the cable and connectors for any visible damage.
2. **Identify Connectors:** The cable has two distinct connectors:
   - One end is a standard **USB-A connector**, typically used for power adapters, computers, or power banks.
   - The other end is a **Lightning connector**, designed for Apple iPhones, iPads, and iPods.
3. **Connect to Power Source or Computer:** Insert the USB-A connector into a compatible USB-A port on a power adapter, computer, or power bank. Ensure it is fully inserted.
4. **Connect to Apple Device:** Insert the Lightning connector into the Lightning port of your Apple device. Ensure it is fully inserted.



Figure 2: A close-up view of the USB-A and Lightning connectors of the HOCO U74 cable.

Operating Instructions

Charging Your Device

To charge your Apple device:

1. Connect the USB-A end of the HOCO U74 cable to a compatible USB wall adapter or a powered USB port (e.g., on a computer or power bank).
2. Connect the Lightning end of the cable to your Apple device's Lightning port.
3. Your device should indicate that it is charging. For optimal charging speed, use a power adapter that supports fast charging if your device and the cable's specifications allow.



Figure 3: The HOCO U74 cable facilitating charging between a power bank and an iPhone.

Data Synchronization

To synchronize data between your Apple device and a computer:

1. Connect the USB-A end of the HOCO U74 cable to an available USB-A port on your computer.
2. Connect the Lightning end of the cable to your Apple device's Lightning port.
3. Unlock your Apple device. If prompted, tap "Trust This Computer" on your device screen.
4. Use iTunes, Finder (macOS Catalina or later), or other compatible software on your computer to manage and synchronize data (photos, videos, music, documents, etc.).



Figure 4: The HOCO U74 cable connecting an iPhone to a laptop, illustrating a data transfer setup.

Maintenance and Care

Proper maintenance ensures the longevity and optimal performance of your cable:

- **Cleaning:** Use a soft, dry, lint-free cloth to gently wipe the cable and connectors. Avoid using liquids, sprays, or harsh chemicals.
- **Storage:** Store the cable in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tightly coiling or bending the cable at sharp angles, especially near the connectors, to prevent internal wire damage.
- **Handling:** Always grasp the connector housing when plugging or unplugging the cable. Do not pull directly on the cable itself, as this can damage the internal wiring or the connector.
- **Protection:** Keep the connectors free from dust, dirt, and moisture.

Troubleshooting

If you encounter issues with your HOCO U74 Grand cable, try the following solutions:

- **Device Not Charging:**
  - Ensure both the USB-A and Lightning connectors are fully and securely inserted into their respective ports.
  - Try a different USB wall adapter or a different USB port on your computer/power bank.
  - Check if your Apple device's Lightning port is clean and free of debris.
  - Test the cable with another compatible Apple device, if available, to determine if the issue is with the cable or the device.
- **Data Synchronization Not Working:**
  - Verify that the cable is securely connected to both your computer and your Apple device.
  - Ensure your Apple device is unlocked and you have tapped "Trust This Computer" when prompted.
  - Try connecting to a different USB port on your computer.
  - Restart both your computer and your Apple device.
  - Update your computer's operating system and iTunes/Finder to the latest version.
- **Slow Charging:**
  - Ensure you are using a power adapter with sufficient output (e.g., 5V/2A or higher for faster charging, if supported by your device).
  - Avoid charging from unpowered USB hubs or low-power USB ports on older computers.

Specifications

Model Number	U74
Brand	HOCO
Connector Type	USB-A to Lightning
Special Feature	Fast Charging
Product Dimensions	8.27 x 3.58 x 0.87 inches (packaging)
Item Weight	0.882 ounces / 25 Grams
Manufacturer	Hoco



Figure 5: The HOCO U74 Grand cable packaging, often containing detailed product specifications.

Warranty and Support

For warranty information and technical support, please refer to the documentation included with your purchase or contact the retailer where the product was acquired. You may also visit the official HOCO website for further assistance and contact details.

Please retain your proof of purchase for any warranty claims.

© 2023 HOCO. All rights reserved. Model U74 Grand.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08WJKYF5Y

More documents and user manuals: **https://manuals.plus/**