

EXIT 30.23.32.10

EXIT Toys Wood Pool with Solar Canopy

Model: 30.23.32.10 | Dimensions: 300x200x65cm

1. INTRODUCTION

This manual provides essential instructions for the safe assembly, operation, and maintenance of your EXIT Toys Wood Pool with Solar Canopy. Please read all instructions carefully before setting up and using the product. Keep this manual for future reference.

The EXIT Wood Pool 300 x 200 x 65 cm is a rectangular frame pool featuring a wood-look finish. This compact pool includes a filter pump and a solar canopy designed to provide sun protection. The powder-coated steel frame and robust corner points ensure stability and durability.

2. SAFETY INFORMATION

- Always supervise children in and around the pool.
- Ensure the pool is assembled on a level, stable surface.
- Do not dive into the pool.
- Keep electrical components (filter pump) away from water and ensure they are properly grounded.
- Regularly check all components for wear and tear. Replace damaged parts immediately.
- The pool meets safety standards: **TÜV, CE, EN 16582**

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- Rectangular Steel Frame Pool (300x200x65cm)
- Solar Canopy
- Cartridge Filter Pump (300 gal/h)
- Filter Cartridge (1 unit)
- Instruction Manual



Image: The EXIT Wood Pool with its solar canopy, accompanied by the included filter pump and a replacement filter cartridge.

4. SETUP INSTRUCTIONS

4.1 Site Preparation

- Choose a firm, level area free of sharp objects, debris, and excessive slopes.
- Ensure adequate drainage and proximity to a power outlet for the filter pump.

4.2 Frame Assembly

1. Unpack all components and lay them out.
2. Connect the steel frame pipes according to the diagrams provided in the separate assembly guide. Ensure all connections are secure.
3. Carefully spread the pool liner within the assembled frame, ensuring it is centered and smooth.

4.3 Filter Pump Installation

1. Attach the filter pump to the designated inlet and outlet connections on the pool liner.
2. Ensure all hoses are securely fastened to prevent leaks.

3. Insert the filter cartridge into the pump housing.
4. Connect the pump to a grounded power outlet.

4.4 Solar Canopy Attachment

1. Attach the canopy support poles to the designated points on the pool frame.
2. Unfold the canopy and secure it to the support poles using the provided straps or clips.
3. Adjust the canopy's position to achieve desired shade using the adjustable straps.



Image: The fully assembled EXIT Wood Pool with its solar canopy extended, providing shade over the water.

5. OPERATING INSTRUCTIONS

5.1 Filling the Pool

Begin filling the pool with water. As the water level rises, smooth out any wrinkles in the liner. Fill to approximately 90% capacity (approximately 3700 liters).

5.2 Filter Pump Operation

- Once the pool is filled, turn on the filter pump.
- Operate the pump for several hours daily to ensure proper water circulation and filtration. Consult local guidelines for recommended filtration times.

5.3 Solar Canopy Usage

- The solar canopy can be easily opened and closed using its fan system.
- Adjust the canopy's position throughout the day using the adjustable straps to maintain optimal shade as the sun moves.

- When not in use or during strong winds, fold and secure the canopy to prevent damage.



**GO PLAY
OUTSIDE!**



Image: Individuals enjoying the pool, demonstrating the effective shade provided by the solar canopy.



Image: A close-up view of the solar canopy in its folded and secured position, illustrating the compact storage.

6. MAINTENANCE

6.1 Water Treatment

- Regularly test pool water chemistry (pH, chlorine levels) and adjust as needed using appropriate pool chemicals.
- Shock treat the pool water periodically to prevent algae growth and maintain clarity.

6.2 Filter Cartridge Replacement

- Turn off and unplug the filter pump before performing any maintenance.
- Rinse the filter cartridge with a garden hose regularly to remove debris.
- Replace the filter cartridge every 2-4 weeks, or more frequently if the pump's performance decreases or the water remains cloudy.

6.3 Pool Cleaning

- Skim debris from the water surface daily.
- Brush the pool walls and floor weekly to prevent algae buildup.
- Vacuum the pool floor as needed.

6.4 Winterization

- Drain the pool completely before freezing temperatures arrive.
- Clean and dry all components thoroughly.
- Store the pool liner, frame, pump, and canopy in a dry, protected area.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Cloudy Water	Insufficient filtration, chemical imbalance, dirty filter cartridge	Run filter longer, test and adjust chemicals, clean/replace filter cartridge
Pump Not Working	No power, clogged impeller, airlock	Check power connection, clean impeller, bleed air from pump
Water Leakage	Loose hose connections, puncture in liner	Tighten connections, locate and patch liner puncture
Canopy Instability	Loose attachments, strong winds	Ensure all straps are tight, fold and secure canopy in high winds

8. SPECIFICATIONS

- **Model Number:** 30.23.32.10
- **Pool Dimensions (L x W x H):** 300 x 200 x 65 cm
- **Overall Product Dimensions (L x W x H):** 343 x 251 x 159 cm
- **Water Capacity (90% fill):** 3700 Liters
- **Material:** Alloy Steel (Frame)
- **Color:** Brown (Wood-look finish)
- **Filter Pump Capacity:** 300 gal/h
- **Components Included:** Filter pump, Shade sail, Filter cartridge
- **Product Weight:** 35 kg
- **Assembly Required:** Yes
- **Safety Certifications:** TÜV, CE, EN 16582






Image: A technical diagram illustrating the dimensions and 3700-liter capacity of the EXIT Wood Pool.

9. WARRANTY AND SUPPORT

EXIT Toys is committed to customer satisfaction. For any questions, assistance, or replacement parts, please contact EXIT Toys customer service. They are available to provide personal advice and support.

For information regarding warranty terms and conditions, please refer to the warranty card included with your product or visit the official EXIT Toys website.



Image: An illustration featuring the EXIT Toys logo and text indicating that spare parts are available for purchase.



[EXIT Toys Pool Ladder User Manual - Assembly, Safety, and Care Instructions](#)

Comprehensive user manual for the EXIT Toys Pool Ladder (48IN / 122CM), including detailed assembly instructions, important safety guidelines, care and usage tips, and limited warranty information. Learn how to safely install, use, and maintain your pool ladder.