

[Manuals.plus](#) /

› [Cogo](#) /

› Cogo 4173 City Fire Building Set Instruction Manual

Cogo 4173

Cogo 4173 City Fire Building Set Instruction Manual

Model: 4173

INTRODUCTION

Thank you for choosing the Cogo 4173 City Fire Building Set. This manual provides essential information for assembling, operating, and maintaining your building set. Please read these instructions carefully before beginning assembly to ensure a smooth and enjoyable experience. This set is designed for individuals aged 6 years and above.

PRODUCT OVERVIEW

The Cogo 4173 City Fire Building Set allows you to construct a detailed city fire scene, featuring a fire boat and a building. This set includes 318 pieces, designed to enhance creativity and motor skills. A special luminous brick is also included to add an interactive element to your creation.

Components

- 318 assorted building blocks
- 1 Luminous brick
- Instruction booklet for assembly
- Minifigures and accessories

Features

- Develops imagination and creativity
- Enhances manual dexterity
- Improves motor skills and hand-eye coordination
- Includes a unique luminous brick for added play value
- Non-toxic materials



Figure 1: Front packaging of the Cogo 4173 City Fire Building Set. It features a vibrant illustration of the completed fire boat and a building with simulated flames, along with minifigures engaged in a rescue scenario. The box highlights the 'Luminous brick included' and '318 pcs' count.

ASSEMBLY INSTRUCTIONS

1. **Unpack Components:** Carefully open the product packaging and remove all building blocks, the luminous brick, and the instruction booklet.
2. **Sort Pieces:** For easier assembly, sort the building blocks by color, size, or type as indicated in the instruction booklet.
3. **Follow Booklet:** Refer to the included instruction booklet for step-by-step visual guides. Each step illustrates which pieces to use and where to place them.
4. **Connect Pieces:** Firmly press the building blocks together to ensure a secure connection.
5. **Integrate Luminous Brick:** The instruction booklet will specify the exact step and location for integrating the luminous brick into your model. Ensure it is placed correctly according to the diagrams.
6. **Verify Assembly:** After completing all steps, review your assembled model to ensure all pieces are correctly placed and the structure is stable.



Figure 2: The back of the Cogo 4173 City Fire Building Set box illustrates additional product details, including close-ups of the fire boat's features like the rotating radar and water cannon. It also contains a 'WARNING: CHOKING HAZARD: Small parts. Not for children under 3 years.'

OPERATING THE LUMINOUS BRICK

The Cogo 4173 set includes a special luminous brick to enhance your play experience. To activate the light feature:

- Locate the luminous brick within your assembled model.
- Press the designated button or switch on the luminous brick to turn the light on.
- Press the button or switch again to turn the light off.

Note: The luminous brick typically comes with pre-installed batteries. If the light does not activate, refer to the troubleshooting section.

MAINTENANCE AND CARE

Proper care will ensure the longevity of your Cogo building set:

- **Cleaning:** To clean the building blocks, gently wipe them with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or hot water, as these can damage the plastic.
- **Storage:** Store the building set in a cool, dry place, away from direct sunlight and extreme temperatures. Keeping the

pieces in their original box or a dedicated storage container can help prevent loss and damage.

- **Luminous Brick:** Keep the luminous brick dry. If battery replacement is ever needed (though typically not user-serviceable), refer to the specific instructions provided with the brick or contact customer support.

TROUBLESHOOTING

If you encounter any issues during assembly or play, please refer to the following common solutions:

- **Missing Pieces:** Double-check all packaging materials. If a piece is genuinely missing, please contact Cogo customer support with details of the missing part (as identified in the instruction booklet).
- **Difficulty Assembling:** Review the instruction booklet carefully, paying close attention to the diagrams for each step. Ensure you are using the correct pieces and that they are oriented correctly. Sometimes, a piece may require a firm press to connect properly.
- **Luminous Brick Not Working:**
 - Ensure the brick is correctly installed according to the assembly instructions.
 - Press the activation button/switch firmly.
 - If the brick uses replaceable batteries (uncommon for small integrated bricks), check if they are correctly inserted or need replacement. (Consult the brick's specific instructions if available).
 - If the issue persists, contact customer support.

PRODUCT SPECIFICATIONS

Brand	Cogo
Model Number	4173
Number of Pieces	318
Recommended Age	6 years and up
Educational Objective(s)	Motor Skills, Imagination, Creativity
Special Features	Luminous Brick, Non-Toxic
Package Dimensions	37.6 x 25.4 x 6.2 cm
Package Weight	590 g

SAFETY INFORMATION

Please observe the following safety guidelines to ensure a safe play environment:

- **Choking Hazard:** This building set contains small parts. It is not suitable for children under 3 years of age due to a potential choking hazard. Adult supervision is recommended for all children during play.
 - **Ingestion:** Do not put building blocks or any other parts of the set in the mouth.
 - **Supervision:** Always ensure children are supervised while playing with the set, especially during assembly.
 - **Proper Use:** Use the product only as intended for building and creative play.
-

WARRANTY AND CUSTOMER SUPPORT

Cogo is committed to providing high-quality products. While specific warranty details are not provided in this manual, if you encounter any issues with your Cogo 4173 City Fire Building Set, such as missing or defective parts, please contact the retailer where you purchased the product or visit the official Cogo website for customer support information. Please have your model number (4173) ready when contacting support.