

Bush Furniture WDS124WAS-03

Bush Furniture Woodland 24W Small Shoe Bench with Drawer - White Ash User Manual

1. INTRODUCTION

This manual provides essential information for the assembly, operation, and maintenance of your Bush Furniture Woodland 24W Small Shoe Bench with Drawer. This unit combines transitional styling with practical design, offering an ideal organizer for entryways, mudrooms, and foyers. Please read these instructions carefully before proceeding with assembly or use.

2. SAFETY INFORMATION

Important Safety Precautions:

- Do not exceed the weight limit of 250 pounds (113.4 kg) when sitting on the bench or placing heavy objects on it.
- Ensure the bench is stable and secure on a level surface before use.
- Keep small parts and assembly hardware away from children.
- Always follow assembly instructions precisely to ensure structural integrity.

3. PRODUCT OVERVIEW

The Bush Furniture Woodland 24W Small Shoe Bench features a durable top surface for seating and a single drawer for storage. Its design complements various home decor styles.



Figure 3.1: Front view of the Bush Furniture Woodland 24W Small Shoe Bench in White Ash.



Figure 3.2: The shoe bench positioned in an entryway, demonstrating its functional placement.




Figure 3.3: Detailed dimensions of the shoe bench, including width, depth, and height measurements.




Figure 3.4: Illustration highlighting key features such as transitional design, 250 lb weight capacity, smooth full-extension ball bearing drawer slides, and stylish drawer hardware.



Figure 3.5: A close-up view of the stylish drawer hardware, showcasing its design and finish.



Figure 3.6: The drawer in an open position, illustrating the smooth full-extension ball bearing slides for easy access.

4. SETUP AND ASSEMBLY

This product requires assembly. Please ensure all components are present before beginning. Refer to the separate assembly instructions provided with your product for detailed, step-by-step guidance. Typically, assembly involves:

1. Unpacking all parts and hardware.
2. Identifying each component using the parts list.
3. Assembling the main frame of the bench.
4. Installing the drawer slides and assembling the drawer.
5. Attaching the drawer front and hardware.
6. Placing the unit in its desired location, ensuring it is level and stable.

Tools required for assembly are generally a Phillips head screwdriver and possibly a hammer (not included).

5. OPERATING INSTRUCTIONS

The shoe bench is designed for dual functionality:

- **Seating Surface:** The top surface of the bench is designed to support up to 250 pounds (113.4 kg). It provides a convenient place to sit while putting on or taking off shoes, or for temporarily placing items like bags.
- **Storage Drawer:** The single drawer operates on smooth full-extension ball bearing slides, allowing for easy access to its contents. Use it to store footwear, accessories, keys, or other small items to keep your entryway organized.

6. MAINTENANCE

To maintain the appearance and longevity of your shoe bench:

- **Cleaning:** Wipe with a dry cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Inspection:** Periodically check all hardware and connections to ensure they remain tight. Tighten any loose screws as needed.
- **Placement:** Avoid placing the bench in direct sunlight or near heat sources, which can cause fading or warping.

7. TROUBLESHOOTING

If you encounter any issues with your shoe bench, consider the following:

- **Instability/Wobbling:** Ensure the bench is on a level surface. Check that all assembly hardware is securely tightened.
- **Drawer Not Sliding Smoothly:** Verify that the drawer slides are correctly installed and free of obstructions. Ensure the drawer is not overloaded.
- **Damaged Parts:** If any part is damaged during assembly or use, do not attempt to force it. Contact customer support for replacement parts.

8. SPECIFICATIONS

Attribute	Detail
Product Dimensions	17.44"D x 24.49"W x 19.29"H (44.3 cm D x 62.2 cm W x 49.0 cm H)
Color	White Ash
Size	24W
Furniture Finish	Ash
Seat Height	19 Inches (48.3 cm)
Brand	Bush Furniture
Product Care Instructions	Wipe with Dry Cloth

Attribute	Detail
Maximum Weight Recommendation	250 Pounds (113.4 kg)
Manufacturer	Bush Industries
Item Weight	50.4 pounds (22.86 kg)
Model Number	WDS124WAS-03
UPC	042976139063

9. WARRANTY AND SUPPORT

This Bush Furniture Woodland 24W Small Shoe Bench is backed by a **3 Year Manufacturer's Warranty**. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, replacement parts, or further assistance, please contact Bush Furniture customer support. You may also reach out to the seller, Bison Commerce, for support related to your purchase.

Please retain your proof of purchase for warranty purposes.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question