Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bush Furniture WDL009WAS

Bush Furniture Woodland 40W Entryway Bench and Coat Rack User Manual

Model: WDL009WAS

Introduction

This manual provides essential information for the assembly, use, and maintenance of your Bush Furniture Woodland 40W Entryway Bench with Doors and Wall Mounted Coat Rack. Please read these instructions carefully before assembly and use to ensure proper function and longevity of your product.
The Bush Furniture Woodland 40W Entryway Bench and Wall Mounted Coat Rack offers a practical storage solution for your home. The bench provides a seating area and concealed storage, while the wall-mounted rack offers hooks and open cubbies for various items.

Included Components

The Bush Furniture Woodland 40W Entryway Bench and Coat Rack set includes the following main components:

- 40W Door Bench
- Seat Back for Bench
- Wall Mounted Coat Rack

Refer to the assembly instructions provided with your product for a complete list of hardware and detailed assembly steps.





Image: The Bush Furniture Woodland 40W Entryway Bench and Wall Mounted Coat Rack, shown as two separate units. The bench features two cabinet doors, and the coat rack has three open cubbies and four double-prong hooks.

Setup and Assembly

This product requires assembly. Detailed step-by-step assembly instructions and all necessary hardware are included in

the product packaging. Please follow these instructions carefully to ensure correct and safe assembly.

- Unpack all components and verify against the parts list in the assembly guide.
- Assemble the bench first, ensuring all connections are secure.
- Attach the seat back to the bench as instructed.
- Mount the coat rack to a sturdy wall using appropriate hardware and techniques for your wall type. Ensure it is level and securely fastened to prevent falling.
- It is recommended to have two people for assembly and installation, especially for mounting the coat rack.



Image: The assembled Bush Furniture Woodland 40W Entryway Bench and Coat Rack installed in a home entryway, demonstrating its functional use for seating, shoe storage, and coat hanging.

Operating Instructions

The Bush Furniture Woodland 40W Entryway Bench and Coat Rack is designed for practical use in an entryway or mudroom.

Bench Usage:

- The bench surface is designed to support up to 250 pounds, providing a stable seating area for putting on or taking off shoes.
- The two cabinet doors conceal internal storage compartments. Open the doors using the stylish hardware to access space for footwear or other items.

Coat Rack Usage:

- The wall shelf includes four double-prong coat hooks on the front and one on each side, suitable for hanging jackets, hats, scarves, and bags.
- Three open cubby spaces are available for smaller items such as gloves, keys, or decorative objects.




Image: Detailed view of the wall-mounted coat rack, highlighting the three open cubbies for accessories and the four double-prong hooks for hanging items. The design is noted as transitional.



Image: Detailed view of the entryway bench, illustrating its 250 lb weight capacity, the stylish door hardware, and the concealed storage compartments behind Euro-style hinged doors. The seat back design is also visible.

Maintenance and Care

To ensure the longevity and appearance of your Bush Furniture Woodland Entryway Bench and Coat Rack, follow these care instructions:

- **Cleaning:** Wipe with a dry cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Promptly wipe up any spills to prevent staining or damage to the engineered wood material.
- **Weight Capacity:** Do not exceed the maximum recommended load of 250 pounds on the bench surface.
- **Hardware:** Periodically check and tighten all assembly hardware to maintain structural integrity.
- **Placement:** Avoid placing the furniture in direct sunlight or near heat sources, as this can cause fading or warping.

Troubleshooting

If you encounter any issues with your Bush Furniture Woodland Entryway Bench and Coat Rack, consider the following common solutions:

- **Wobbly Bench/Rack:** Ensure all screws and fasteners are securely tightened. If the issue persists, re-check the assembly steps. For the coat rack, verify it is mounted to wall studs or appropriate anchors.
- **Doors Not Closing Properly:** Check the Euro-style hinges for proper alignment. Adjust if necessary according to the assembly instructions. Ensure no items are obstructing the door's path.
- **Damaged Parts:** If any parts were damaged during shipping or assembly, contact Bush Furniture customer support for assistance. Do not attempt to use damaged components.

Specifications

Feature	Detail
Model Number	WDL009WAS
Brand	Bush Furniture
Color	White Ash
Material	Engineered Wood
Overall Dimensions (L x W x H)	39.72 x 17.44 x 32.44 inches (Bench)
Item Weight	40.2 pounds
Maximum Bench Load	250 Pounds
UPC	042976140038



Image: Technical diagram illustrating the precise dimensions of both the entryway bench and the wall-mounted coat rack in inches and centimeters, including cubby dimensions.

Warranty Information

This Bush Furniture Woodland 40W Entryway Bench and Coat Rack is backed by a**3 Year Manufacturer's Warranty**.
This warranty covers defects in materials and workmanship under normal use.
For specific details regarding warranty coverage, claims, or to register your product, please refer to the warranty

documentation included with your purchase or visit the official Bush Furniture website.

Customer Support

For further assistance, questions, or to report any issues, please contact Bush Furniture customer support. Contact information can typically be found on the manufacturer's website or in the documentation provided with your product. When contacting support, please have your model number (WDL009WAS) and proof of purchase readily available.

© 2025 Bush Furniture. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08WJVX6Q1

More documents and user manuals: **https://manuals.plus/**