

[Manuals.plus](#) /

› [Seville Classics](#) /

› Seville Classics Solid Steel Wire Shelving Storage Unit (Model WEB674) - Instruction Manual

Seville Classics WEB674

Seville Classics Solid Steel Wire Shelving Storage Unit

Model: WEB674

INTRODUCTION

This instruction manual provides detailed guidance for the assembly, operation, and maintenance of your Seville Classics 4-Tier Solid Steel Wire Shelving Storage Unit. Designed for versatility and durability, this unit offers an efficient storage solution for various environments including homes, kitchens, offices, garages, bedrooms, and closets. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image: The Seville Classics 4-Tier Solid Steel Wire Shelving Unit, showcasing its chrome finish and four adjustable shelves.

PRODUCT OVERVIEW

The Seville Classics 4-Tier Solid Steel Wire Shelving Storage Unit is constructed from industrial-strength steel wire with a chrome plating, providing corrosion resistance suitable for dry and heated storage environments. Its design emphasizes both strength and adaptability, allowing for customized storage configurations.

Key Features:

- Industrial-strength steel wire construction for multipurpose storage.
- Chrome plating for corrosion resistance in dry environments.
- Each shelf holds up to 300 lbs. when using leveling feet.
- Includes 1.5-inch diameter casters (2 locking) for mobility.
- Shelves are height adjustable at 1-inch increments.
- No tools required for assembly.



Image: Detailed dimensions of the shelving unit, showing 30" W x 14" D x 49.5" H (48" H on leveling feet).

INCLUDED COMPONENTS

Before assembly, ensure all components are present:

- 4 Steel Wire Shelves (30" W x 14" D)
- 4 Steel Poles (3/4" diameter)
- 16 Slip Sleeves
- 4 Casters (1.5" diameter, 2 locking)
- 4 Leveling Feet

SETUP INSTRUCTIONS

Assembly of this shelving unit requires no tools and can be completed efficiently by following these steps. It is recommended to begin assembly on a waist-high horizontal surface for ease of handling.

1. **Prepare Poles:** Separate the 8 pole sections into 4 top poles and 4 bottom poles. The bottom poles are where the feet or casters attach. Insert the leveling feet or casters into the bottom poles. Insert the round plugs into the top poles.
2. **Attach First Shelf:** Decide the desired height for your lowest shelf. Take two black slip sleeves and ensure the arrow and "TOP" marking on each sleeve face upwards. Clip them onto one of the poles at the desired height. Repeat this for the remaining three poles, ensuring the sleeves are at the same height on all poles. The sleeves will click into place when aligned with the grooves on the poles.
3. **Slide on Shelf:** With the poles lying horizontally on your work surface, slide the first wire shelf over the poles, ensuring the shelf's corners align with the slip sleeves. Once all four poles are through, you can carefully stand the unit upright.
4. **Add Remaining Shelves:** For each subsequent shelf, repeat step 2 and 3. Place the slip sleeves at the desired height on each pole, then slide the shelf down over the sleeves until it rests securely. Ensure all shelves are level.
5. **Connect Pole Sections:** If using all four tiers, connect the top and bottom pole sections by screwing them together. Ensure they are tightly secured.
6. **Final Adjustment:** Once all shelves are in place, gently push down on each shelf corner to ensure it is fully seated and secure on the slip sleeves.



Image: A close-up view of the shelf attachment mechanism, showing the slip sleeves securing the wire shelf to the pole.

Assembly Video:

Video: An official video from Seville Classics demonstrating the assembly and features of the 4-Tier Steel Shelving unit.

OPERATING INSTRUCTIONS

Adjusting Shelf Height:

The shelves can be adjusted in 1-inch increments to accommodate items of various sizes. To adjust a shelf, remove all items from it. Carefully lift the shelf off the slip sleeves. Reposition the slip sleeves on the poles to the desired height, ensuring they are level across all four poles. Then, place the shelf back onto the sleeves, pressing down firmly to secure it.

Using Casters and Leveling Feet:

Your shelving unit comes with both casters (wheels) and leveling feet. Casters provide mobility, allowing you to easily move the unit. Two of the casters are lockable to prevent unintended movement. When using casters, the total weight capacity for the entire unit is 130 lbs. For stationary use and maximum weight capacity, install the leveling feet. With leveling feet, each shelf can support up to 300 lbs., with a total system capacity of 1500 lbs.



Image: The shelving unit equipped with casters, highlighting its mobile functionality.

MAINTENANCE

To ensure the longevity and appearance of your Seville Classics shelving unit, follow these simple maintenance guidelines:

- **Cleaning:** The manufacturer recommends hand washing only. Use a soft cloth with mild soap and water to clean the chrome surfaces. Avoid abrasive cleaners or scouring pads, as these can damage the finish.
- **Drying:** After cleaning, dry the unit thoroughly to prevent water spots and maintain the chrome's luster.
- **Inspection:** Periodically check all connections and ensure shelves are securely seated on the slip sleeves. Tighten any loose components.
- **Environment:** This unit is designed for dry and heated storage environments. Avoid prolonged exposure to excessive moisture or extreme temperatures to prevent corrosion.

TROUBLESHOOTING

If you encounter any issues with your shelving unit, consider the following:

- **Unstable Unit:** Ensure all shelves are properly seated on the slip sleeves and that the slip sleeves are correctly positioned in the pole grooves. If using leveling feet, adjust them to ensure the unit is stable on uneven surfaces. If using casters, ensure the locking casters are engaged when the unit needs to remain stationary.
- **Difficulty Adjusting Shelves:** Ensure the shelf is completely empty before attempting to lift and reposition it. The slip sleeves should slide easily along the poles when not bearing weight.
- **Weight Capacity Concerns:** Always adhere to the specified weight limits. Overloading shelves can compromise the unit's stability and structural integrity. Remember, capacity differs between leveling feet and casters.

SPECIFICATIONS

Feature	Detail
Model Name	Solid Steel Wire Shelving Storage Unit Adjustable Shelves Organizer Rack
Model Number	WEB674
Dimensions (W x D x H)	30" x 14" x 48" (49.5" H with casters)
Number of Shelves	4
Material	Alloy Steel
Finish Type	Chrome
Weight Limit (per shelf, leveling feet)	300 lbs.
Total Weight Capacity (leveling feet)	1500 lbs.
Total Weight Capacity (casters)	130 lbs.
Special Feature	Adjustable Shelf Height (1-inch increments)

Included Components

Shelves, Poles, Slip Sleeves, Casters, Leveling Feet



OFFICE



GARAGE



KITCHEN

VERSATILE SHELVING FOR ANY SPACE

Image: The versatile shelving unit shown in different environments, including an office, garage, and kitchen, demonstrating its adaptability.

WARRANTY & SUPPORT

Your Seville Classics shelving unit is backed by a Limited 10-Year Manufacturer's Warranty. This warranty protects against original defects in material or workmanship under normal home or office use for the duration of the warranty period.

For warranty claims, replacement parts, or any product support, please contact Seville Classics customer service. Refer to the product packaging or the official Seville Classics website for the most current contact information.