Dekain ELP-LP65

Dekain ELP-LP65 Projector Lamp Instruction Manual

For Epson H476A, H476B, H476C, H477A, H477B, H477C, H478A, H478B, H478C, H479A, H479B, H479C Series Projectors

1. Product Overview

This manual provides instructions for the Dekain Projector Lamp, model ELP-LP65. This replacement lamp is designed for use with various Epson projector models, including H476A, H476B, H476C, H477A, H477B, H477C, H478A, H478B, H478C, H479A, H479B, and H479C. It features an original Philips bulb, ensuring high quality and performance.




Image 1: The Dekain ELP-LP65 Projector Lamp module, featuring the bulb and housing.

2. Safety Information

Always observe the following safety precautions when handling or replacing the projector lamp:

- Ensure the projector is completely powered off and unplugged from the power outlet before beginning any installation or maintenance.
- Allow the projector and the old lamp to cool down for at least 30 minutes before handling. Lamps can become extremely hot during operation.
- Avoid touching the glass surface of the new lamp directly with bare hands. Oils from your skin can reduce lamp life. Use gloves or a clean cloth if necessary.
- Do not drop or subject the lamp to impact, as this can cause it to break.
- Dispose of old lamps according to local regulations. Projector lamps contain mercury and should not be discarded with regular household waste.

3. Installation (Setup)

Follow these steps to install your new Dekain Projector Lamp:

1. **Power Off and Cool Down:** Shut down your projector and unplug it from the power source. Allow sufficient time for the projector and the old lamp to cool completely.
2. **Locate Lamp Compartment:** Refer to your projector's original user manual to locate the lamp compartment cover. This is typically secured with screws.
3. **Remove Old Lamp:** Carefully unscrew and remove the lamp compartment cover. Disconnect any connectors and gently pull out the old lamp module.

4. **Insert New Lamp:** Align the new Dekain ELP-LP65 lamp module with the slot in the projector. Gently push it into place until it is securely seated. Ensure all connections are firm.
5. **Secure Cover:** Replace the lamp compartment cover and tighten the screws.
6. **Reset Lamp Timer:** Plug the projector back in and power it on. Navigate to the projector's menu settings and reset the lamp timer. This is crucial for accurate lamp life tracking. Consult your projector's manual for specific instructions on resetting the lamp timer.

Your browser does not support the video tag.

Video 1: This video provides general guidance on selecting and installing a projector replacement lamp, emphasizing compatibility, quality, and warranty considerations.

4. Operating Considerations

Once the lamp is installed, operate your projector as usual. The new lamp will provide optimal brightness and color output. For best performance and to maximize lamp life, consider the following:

- **Brightness and Color Output:** The lamp's brightness directly impacts performance, especially in larger rooms. This lamp is designed to provide superior brightness and quality.
- **Projector Settings:** Adjust your projector's brightness and picture mode settings to suit your viewing environment and preferences.
- **Cool-down Cycle:** Always allow the projector to complete its cool-down cycle after turning it off. Interrupting this cycle can shorten lamp life.



Image 2: A projector emitting a bright light beam, illustrating the lamp's function.

5. Maintenance

While the lamp itself requires no direct maintenance, maintaining your projector can extend the life of the lamp and ensure consistent performance:

- **Clean Air Filters:** Regularly clean or replace your projector's air filters to prevent dust buildup, which can lead to overheating and reduced lamp life.
- **Ventilation:** Ensure the projector has adequate ventilation and is not placed in an enclosed space that could restrict airflow.
- **Operating Environment:** Use the projector in a clean, relatively dust-free environment.

6. Troubleshooting

If you encounter issues after installing the new lamp, consider the following common troubleshooting steps:

- **No Image/Dim Image:**
  - Verify the lamp is securely seated in its compartment and all connectors are properly attached.
  - Ensure the lamp compartment cover is fully closed and secured. Some projectors will not power on if the cover is open.
  - Check if the lamp timer was reset. If not, the projector might still register the old lamp's life.
  - Confirm the projector's input source is correctly selected.
- **Overheating Warning:**
  - Check for blocked air vents on the projector.

- Clean the projector's air filters.
- Ensure the projector is in an area with good airflow.

For persistent issues, refer to your projector's original user manual or contact Dekain customer support.



Image 3: A projector in operation, casting an image onto a screen.

7. Specifications

Feature	Detail
Brand	Dekain
Model Number	ELP-LP65
Compatible Projector Models	Epson H476A, H476B, H476C, H477A, H477B, H477C, H478A, H478B, H478C, H479A, H479B, H479C
Light Type	Metal Halide
Wattage	230 watts
Bulb Manufacturer	Original Philips Bulb Inside
Bulb Shape Size	MR20
Bulb Base	Prong
Item Weight	14.4 ounces
Package Dimensions	6 x 6 x 5 inches
UPC	772288550057

8. Warranty and Lamp Life

The Dekain Projector Lamp is built with original OEM bulbs and undergoes rigorous testing to meet original quality, function, and performance standards. This ensures a lifespan significantly longer than economic lamps.
Lamp Life Expectancy: Most projector lamps offer about 2,000-3,000 hours of operation. Under normal operating conditions (no more than 3 to 5 hours per day in a clean, relatively dust-free environment), the lamp can last through its entire rated 3,000-5,000 hours (in power saving mode). Lamp life is rated by "Half-Life," meaning the time until the lamp brightness becomes half as bright as it was when new.
Warranty Coverage: It is important to confirm the specific warranty terms provided at the time of purchase. Dekain aims to provide long-term warranty coverage for quality-related issues. Please retain your proof of purchase for any warranty claims.

9. Support

For further assistance, technical support, or warranty inquiries, please contact Dekain Enterprise directly. Refer to your purchase documentation for contact details.

© 2023 Dekain Enterprise. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question