

[Manuals.plus](#) /

> [GILMOUR](#) /

> Gilmour Heavy Duty Front Control Garden Hose Nozzle with 8 Pre-set Spray Patterns, Water Hose Nozzle for Watering Garden or Lawn

GILMOUR 825702-1001

Gilmour Heavy Duty Front Control Garden Hose Nozzle

Model: 825702-1001

Brand: GILMOUR

PRODUCT OVERVIEW

The Gilmour Heavy Duty Front Control Garden Hose Nozzle is designed for comfortable and efficient watering. It features a Swivel Connect™ coupling to prevent hose kinking and an ergonomic front control handle with a one-handed lock for continuous use. The nozzle offers 8 pre-set spray patterns for various watering needs and is constructed with durable metal components for long-lasting performance.





Image: The Gilmour Heavy Duty Front Control Garden Hose Nozzle, showcasing its ergonomic design and spray head.

SETUP INSTRUCTIONS

Follow these steps to properly connect your Gilmour hose nozzle to a standard garden hose:

1. **Prepare the Hose:** Ensure your garden hose is free of kinks and the end is clean.
2. **Attach the Nozzle:** Align the Swivel Connect™ coupling of the nozzle with the threaded end of your garden hose.
3. **Tighten Connection:** Turn the coupling clockwise until it is hand-tight. The Swivel Connect™ design allows the nozzle to pivot without twisting the hose, reducing kinks. Do not overtighten.
4. **Check for Leaks:** Turn on the water supply slowly and check for any leaks at the connection point. If a leak occurs, tighten slightly more or check the hose washer.



Image: A person demonstrating the connection of the Gilmour hose nozzle to a garden hose, highlighting the Swivel Connect™ feature.

OPERATING INSTRUCTIONS

The Gilmour nozzle offers intuitive controls for various watering tasks:

- **Activating Water Flow:** Squeeze the front control trigger to begin water flow. The amount of pressure applied to the trigger will control the water volume.
- **Continuous Flow Lock:** For continuous watering without holding the trigger, push the small lever located near the trigger forward to engage the lock. To disengage, simply squeeze the trigger again.
- **Adjusting Spray Patterns:** The nozzle features 8 pre-set spray patterns. To change the pattern, rotate the head of the nozzle clockwise or counter-clockwise until the desired pattern clicks into place. The patterns are clearly marked on the nozzle head.



Image: A detailed view of the nozzle head, showing the 8 distinct spray pattern icons for easy selection.



Image: A person using the Gilmour hose nozzle to water a flower bed, demonstrating the gentle shower spray pattern.

Note: No official product videos with "Seller" creator type were found in the provided data to embed.

MAINTENANCE

Proper maintenance will extend the life of your Gilmour hose nozzle:

- **Cleaning:** Periodically clean the nozzle head to remove any mineral deposits or debris that may affect spray patterns. A soft brush and mild soap can be used. Rinse thoroughly.
- **Storage:** Store the nozzle in a dry, protected area when not in use, especially during freezing temperatures. Disconnect it from the hose to prevent water from freezing inside.
- **Inspection:** Regularly inspect the nozzle for any signs of wear or damage, particularly the connection points and the spray head. The heavy-duty metal water passage is designed for durability.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Water leaking from connection.	Loose connection, worn hose washer, or damaged hose threads.	Ensure the nozzle is tightly connected to the hose. Replace the hose washer if it appears worn or damaged. Check hose threads for damage.
Irregular or weak spray pattern.	Clogged nozzle holes, low water pressure, or debris in the nozzle.	Clean the nozzle head to remove any blockages. Ensure adequate water pressure from your spigot.
Trigger lock not engaging/disengaging.	Mechanism obstructed or damaged.	Check for any debris around the trigger lock mechanism. If damaged, contact customer support.

SPECIFICATIONS

- **Model Number:** 825702-1001
- **Material:** Metal
- **Dimensions (L x W x H):** 2.56 x 5.91 x 6.06 inches
- **Item Weight:** 8 ounces
- **Inlet Connection Size:** 0.75 Inches
- **Outlet Connection Size:** 0.75 Inches
- **Number of Ports:** 2
- **UPC:** 034411262757
- **Manufacturer:** Lawn and Garden LLC

WARRANTY AND SUPPORT

The Gilmour Heavy Duty Front Control Garden Hose Nozzle is backed by a **Lifetime Warranty**, ensuring long-term reliability and performance.





Image: Product packaging highlighting the "Lifetime Warranty" and "Swivel Connect" features.

For warranty claims, technical assistance, or any product-related inquiries, please contact Gilmore customer support. Refer to the product packaging or the official Gilmore website for the most current contact information. You can also visit the official Gilmore store for more information:[Gilmore Store](#)