

**Braun BR-81635667-81730030**

# Braun Charging Cord User Manual for Types 5513, 5516

Essential instructions for safe and effective use of your Braun Charging Cord.

## 1. PRODUCT OVERVIEW

This Braun Charging Cord is designed to provide reliable power to specific Braun personal care devices. It features a 2-pin connector for compatibility with various models.



Image 1: The Braun Charging Cord, featuring a standard wall plug and a 2-pin barrel connector for device input.

### Compatibility:

This charging cord is compatible with Braun shaver types **5513** and **5516**. It also supports the following Braun models:

- MGK 3010, MGK 3020, MGK 3021, MGK 3025
- MGK 3210, MGK 3220, MGK 3221, MGK 3225, MGK 3921
- BT 3000, BT 3020, BT 3021, BT 3022, BT 3221, BT 3222

Please verify your device's type or model number to ensure compatibility before use.

## 2. SETUP

## Connecting the Charger:

1. Ensure your Braun device is turned off before connecting the charger.
2. Locate the charging port on your Braun device. This is typically a small, circular port.
3. Insert the 2-pin connector of the charging cord firmly into the device's charging port.
4. Plug the wall adapter end of the charging cord into a standard electrical outlet.
5. A charging indicator light on your device (if present) should illuminate, indicating that charging has begun.

## 3. OPERATING INSTRUCTIONS

### Charging Your Device:

Once connected, your Braun device will begin charging. The charging time may vary depending on the device model and its current battery level. Refer to your device's specific user manual for estimated charging times and battery life indicators.

- Avoid overcharging your device. Disconnect the charger once the battery is fully charged to prolong battery life.
- Do not use the device while it is connected to the charger, unless specified by your device's manual.
- Ensure the charging cord is not bent or kinked excessively during use or storage to prevent damage.

## 4. MAINTENANCE

### Care and Storage:

- Keep the charging cord clean and dry. Wipe it with a soft, dry cloth if necessary.
- Store the charging cord in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid wrapping the cord too tightly around the adapter, as this can stress the cable and lead to damage.
- Regularly inspect the cord and connector for any signs of wear, fraying, or damage. Discontinue use if any damage is observed.

## 5. TROUBLESHOOTING

### Common Issues and Solutions:

- **Device not charging:**
  - Ensure the charging cord is securely plugged into both the device and the electrical outlet.
  - Try plugging the charger into a different electrical outlet to rule out a faulty socket.
  - Check the charging port on your device for any debris or obstruction.
  - Inspect the charging cord for visible damage. If damaged, replace the cord.
- **Slow charging:**
  - Ensure the charging cord is fully compatible with your device's power requirements.
  - Avoid using extension cords or power strips if possible, as they can sometimes reduce charging efficiency.

- **Charger feels hot:**

- It is normal for the charger to feel slightly warm during operation. However, if it becomes excessively hot, disconnect it immediately and contact customer support.

## 6. SPECIFICATIONS

Feature	Detail
Brand	Braun
Model Number	BR-81635667-81730030
Compatible Device Types	5513, 5516
Compatible Device Models	MGK 3010, 3020, 3021, 3025, 3210, 3220, 3221, 3225, 3921, BT 3000, 3020, 3021, 3022, 3221, 3222
Connector Type	2-Pin
Input Voltage	5 Volts
Output Current	2 Amps
Output Voltage	5 Volts
Wattage	10 watts
Color	Black
Item Weight	3 ounces

## 7. WARRANTY AND SUPPORT

For warranty information and customer support regarding your Braun Charging Cord, please refer to the documentation included with your original Braun device or contact Braun customer service directly. You may also reach out to the retailer where you purchased the charging cord for assistance.

For general product information, visit the official [Braun Store on Amazon](#).

### Related Documents - BR-81635667-81730030

	<p><a href="#">Braun Multi-Groomer Type 5544 User Manual and Instructions</a></p> <p>Comprehensive user manual for the Braun Multi-Groomer Type 5544, covering setup, usage, cleaning, maintenance, safety, and warranty information. Includes detailed instructions for various attachments and components.</p>
---	--

	<p><b><a href="#">Braun Type 5544 Grooming Device User Manual and Safety Instructions</a></b></p> <p>Comprehensive user manual for the Braun Type 5544 grooming device, covering operation, safety, maintenance, and warranty information. Includes multilingual support and product specifications.</p>
	<p><b><a href="#">Braun 5544 Multi Grooming Kit User Manual and Instructions</a></b></p> <p>Comprehensive user manual for the Braun 5544 Multi Grooming Kit, covering setup, charging, usage for beard trimming, hair clipping, body grooming, ear/nose trimming, and maintenance. Includes safety warnings and product specifications.</p>
	<p><b><a href="#">Braun Multi Grooming Kit User Manual and Guide</a></b></p> <p>User manual for Braun Multi Grooming Kits (MGK, BG, BT, AIO series) detailing safety instructions, product features, attachments, usage, maintenance, specifications, and warranty information.</p>
	<p><b><a href="#">Braun Grooming Kit User Manual: Type 5544 &amp; Model Series</a></b></p> <p>Comprehensive user instructions and maintenance guide for Braun grooming kits, including models MGK, BG, BT, and AIO series. Learn safe operation, charging, trimming techniques, and cleaning procedures.</p>
	<p><b><a href="#">Braun BT3 Beard Trimmer Type 5516 User Manual</a></b></p> <p>User manual for the Braun BT3 Beard Trimmer (Type 5516), providing detailed instructions on operation, charging, cleaning, maintenance, safety precautions, and warranty information. Includes descriptions of all components and accessories.</p>