

## NEXT 8000

# NEXT 8000 Full HD Satellite Receiver User Manual

Model: 8000

## INTRODUCTION

---

Thank you for choosing the NEXT 8000 Full HD Satellite Receiver. This manual provides detailed instructions for the proper installation, operation, and maintenance of your device. Please read this manual thoroughly before using the receiver to ensure optimal performance and safety.

The NEXT 8000 is designed to deliver a high-quality viewing experience with its Full HD capabilities, multi-satellite search, and media playback features. It supports various languages and offers convenient software upgrades via USB.

## PACKAGE CONTENTS

---

Please verify that all items are present in the package:

- NEXT 8000 Satellite Receiver Unit
- Remote Control
- HDMI Cable
- USB Cable
- Power Adapter



Image: The NEXT 8000 Full HD Satellite Receiver unit shown alongside its remote control.

## SETUP GUIDE

---

### 1. Connecting the Receiver

Follow these steps to connect your satellite receiver to your television and satellite dish:

1. **Satellite IN:** Connect the coaxial cable from your satellite dish to the 'LNB IN' port on the back of the receiver.
2. **HDMI Connection:** Use the provided HDMI cable to connect the 'HD OUT' port on the receiver to an available HDMI input on your television. Note the HDMI input number on your TV (e.g., HDMI 1, HDMI 2).
3. **AV Connection (Optional):** If your TV does not have an HDMI input, use an AV cable (not included) to connect the 'AV' port on the receiver to the corresponding AV inputs on your television.
4. **Power Connection:** Connect the power adapter to the 'DC 12V' input on the receiver, then plug the adapter into a power outlet.



Image: Rear view of the NEXT 8000 receiver, highlighting the LNB IN, HD OUT (HDMI), AV, and DC 12V power input ports.

## 2. Initial Power On and Setup

After connecting all cables:

1. Turn on your television and select the correct HDMI or AV input source.
2. The receiver will power on automatically. The initial setup wizard should appear on your screen.
3. Follow the on-screen instructions to select your preferred language, time zone, and perform a channel scan. Refer to the 'Operating Instructions' section for details on channel scanning.

## 3. Remote Control Overview

Familiarize yourself with the functions of the remote control:





Image: The remote control for the NEXT 8000 satellite receiver, showing various buttons for power, navigation, volume, channel, and special functions.

- **Power Button:** Turns the receiver on/off or to standby mode.
- **MENU:** Accesses the main menu for settings and features.
- **OK:** Confirms selections or displays channel list.
- **Arrow Buttons (Up/Down/Left/Right):** Navigates through menus and options.
- **EXIT:** Returns to the previous screen or exits the menu.
- **VOL +/-:** Adjusts volume.

- **CH +/-**: Changes channels.
- **EPG**: Displays the Electronic Program Guide.
- **SAT**: Selects satellite.
- **USB**: Accesses USB media playback.
- **Timeshift**: Activates the Timeshift function (requires USB storage).

## OPERATING INSTRUCTIONS

---

### 1. Channel Search and Management

To find and organize channels:

1. Press the **MENU** button on the remote control.
2. Navigate to 'Installation' or 'Channel Search' using the arrow buttons and press **OK**.
3. Select 'Multi-satellite search' or 'Network search' based on your setup.
4. Follow the on-screen prompts to initiate the scan. The receiver will automatically detect available channels.
5. After the scan, you can access options to 'Program lock', 'Delete', 'Move', or 'Rename' channels within the channel management menu.

### 2. Media Playback via USB

The receiver supports media playback from a USB flash drive.



Image: Front view of the NEXT 8000 receiver, showing the two USB ports available for connecting external storage devices.

1. Insert a USB flash drive into one of the USB ports on the receiver.
2. Press the **USB** button on the remote control or navigate to the 'Media' menu.
3. Select the type of media you wish to play (e.g., Video, Music, Photo).
4. Browse your USB drive content and select the desired file. The receiver supports AVI, MKV, TS, TP, TRP, MPG, and MP4 files.

### 3. Recording and Timeshift

To record programs or use the Timeshift function, a USB storage device must be connected.

- **Recording:** While watching a program, press the **Record** button (usually a red circle) on the remote control to start recording. Press it again to stop. Recorded content will be saved to the connected USB drive.
- **Timeshift:** Press the **Timeshift** button on the remote control to pause live TV. You can then fast-forward or rewind within the buffered content.

### 4. Electronic Program Guide (EPG)

Press the **EPG** button on the remote control to view the 7-day electronic program guide. This allows you to see upcoming programs and set reminders or recordings.

### 5. Parental Lock

To restrict access to certain channels or menus, navigate to the 'System Settings' or 'Parental Control' menu. You can set a password to lock programs or specific functions.

## MAINTENANCE

---

### 1. Software Upgrade via USB

To ensure your receiver has the latest features and bug fixes, you can upgrade its software:

1. Download the latest software file from the official NEXT website to a USB flash drive. Ensure the file is placed in the root directory of the USB drive.
2. Insert the USB flash drive into the receiver's USB port.
3. Go to **MENU** > 'System Settings' > 'Software Upgrade' (or similar option).
4. Select 'Upgrade by USB' and choose the software file.
5. Confirm the upgrade. The receiver will restart automatically after the upgrade is complete. **Do not power off the receiver during the upgrade process.**

### 2. Cleaning

To clean the receiver, disconnect it from the power supply. Use a soft, dry cloth to wipe the exterior surfaces. Do not use liquid cleaners or abrasive materials.

## TROUBLESHOOTING

---

If you encounter issues with your NEXT 8000 receiver, refer to the following table:

Problem	Possible Cause	Solution
No picture or sound	Incorrect TV input selected; Loose HDMI/AV cable; Receiver not powered on.	Select correct TV input; Check all cable connections; Ensure receiver is powered on.
No channels found	Satellite dish not aligned; Incorrect LNB settings; Channel scan not performed.	Check satellite dish alignment; Verify LNB settings in menu; Perform a channel scan.



Problem	Possible Cause	Solution
Remote control not working	Dead batteries; Obstruction between remote and receiver; Remote sensor blocked.	Replace batteries; Remove obstructions; Ensure receiver's IR sensor is clear.
USB media not playing	Unsupported file format; USB drive not properly inserted; Corrupted file.	Check file format compatibility; Re-insert USB drive; Try a different USB drive or file.

If the problem persists after trying these solutions, please contact customer support.

## SPECIFICATIONS

---

Key technical specifications for the NEXT 8000 Full HD Satellite Receiver:

- **Model:** 8000
- **Video Output Resolution:** 576i, 576p, 720p, 1080i, 1080p (50/60 Hz)
- **Connectivity:** HDMI, USB (2 ports), RS232, AV
- **Supported Audio Formats:** Dolby Digital, DTS, AAC, PCM
- **Supported Video/Media Formats:** AVI, MKV, TS, TP, TRP, MPG, MP4
- **Storage Memory:** 100 satellites, 4000 frequencies, 8000 channels
- **Processor:** Sunplus
- **Features:** Recording by USB flash, Screen enlargement, Multi-satellite search, Network search, Media playback, 7-day Electronic Program Guide (EPG), Teletext, Timeshift, Parental lock.
- **Dimensions:** 19.6 x 17.4 x 6.6 cm
- **Weight:** 396 g

## WARRANTY AND SUPPORT







---

For warranty information and technical support, please refer to the documentation provided with your purchase or visit the official NEXT product support website. Keep your purchase receipt as proof of purchase for warranty claims.



© 2023 NEXT. All rights reserved.

### Related Documents - 8000

	<p><a href="#">Next Kanky HD Gold Digital HD Satellite Receiver User Manual</a></p> <p>Comprehensive user manual for the Next Kanky HD Gold Digital HD Satellite Receiver, covering setup, connections, remote control functions, menu navigation, channel management, and media playback.</p>
	<p><a href="#">Intelbras AMT 8000 User Manual: Installation, Configuration, and Operation Guide</a></p> <p>Comprehensive user manual for the Intelbras AMT 8000 Alarm Center, detailing its advanced features, installation procedures, programming options, and operational guidance for effective security monitoring.</p>
	<p><a href="#">Yupiteru MVT-8000 Multiband Receiver Owner's Manual</a></p> <p>Comprehensive owner's manual for the Yupiteru MVT-8000 Multiband Receiver, detailing its features, operations, controls, and specifications.</p>
	<p><a href="#">DGS-8000 Series Ethernet Switch Hardware Installation Guide</a></p> <p>Comprehensive guide for installing and maintaining D-Link DGS-8000 series modular Ethernet switches, covering product overview, technical specifications, installation procedures, and troubleshooting.</p>
	<p><a href="#">Stetsom Bravo Full 5000/8000 Digital Amplifier User Manual</a></p> <p>This user manual provides detailed information on the Stetsom Bravo Full 5000 and 8000 digital amplifiers, covering installation, operation, troubleshooting, technical specifications, and warranty details.</p>
	<p><a href="#">AEG 8000 Series Cordless Vacuum Cleaner Instruction Manual</a></p> <p>Comprehensive instruction manual for AEG 8000 series cordless vacuum cleaners, including Ultimate, Animal, and Hygienic models. Covers assembly, usage, maintenance, and accessory information.</p>



