

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Valera](#) /

> [Valera Absolut Zero 658.01 Professional All-in-One Hair Clipper User Manual](#)

## Valera 658.01

# Valera Absolut Zero 658.01 Professional All-in-One Hair Clipper

User Manual

## INTRODUCTION

Thank you for choosing the Valera Absolut Zero 658.01 Professional All-in-One Hair Clipper. Engineered in Switzerland, this versatile grooming tool is designed for precision and durability, offering a minimal cutting length of 0.1 mm. It is suitable for trimming hair, beard, and body hair, providing a professional grooming experience at home or in a salon setting.

## SAFETY WARNINGS

To ensure safe operation and prevent injury or damage, please read and adhere to the following safety instructions:

- **Electrical Safety:** Always ensure the clipper is disconnected from the power source before cleaning or maintenance. Do not handle the power cord or plug with wet hands.
- **Water Exposure:** Avoid contact with water or other liquids during charging and operation. Do not use the clipper near bathtubs, showers, basins, or other vessels containing water. If the clipper falls into water, do not reach for it; unplug it immediately.
- **Children and Supervision:** This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- **Damage:** Do not use the clipper if the blades are damaged or broken, as this may cause injury. Inspect the clipper and its accessories for any damage before each use.
- **Charging:** Use only the charger supplied with the appliance. Do not attempt to modify the charger or use it with other devices.
- **Storage:** Store the clipper in a dry place, away from extreme temperatures and direct sunlight.

## PACKAGE CONTENTS

Upon unpacking, please verify that all items are present and in good condition:

- Valera Absolut Zero Professional Compact Clipper
- Charging Adapter
- Lubricating Oil
- Cleaning Brush
- 3 Guide Combs (various cutting lengths)



The complete Valera Absolut Zero package, including the professional compact clipper, charging adapter, lubricating oil, cleaning brush, and a set of three guide combs for various cutting lengths.

## SETUP

1. **Initial Charge:** Before first use, fully charge the clipper for approximately 120 minutes. Connect the charging adapter to the clipper and plug it into a suitable power outlet. The charging indicator light will show the charging status.
2. **Attaching Guide Combs:** Select the desired guide comb for your preferred cutting length. Align the comb with the clipper blade and push it firmly until it clicks into place. Ensure it is securely attached before use.
3. **Blade Lubrication:** Apply a small drop of the provided lubricating oil to the blades before each use. This ensures smooth operation and extends blade life.

## OPERATING INSTRUCTIONS

The Valera Absolut Zero clipper can be used cordlessly or while connected to the power adapter for continuous operation.

### General Usage Tips:

- Ensure hair is clean and dry before trimming for best results.
- Hold the clipper firmly and move it against the direction of hair growth.
- Use light, even pressure. Do not press too hard against the skin.

- For a 0.1 mm 'zero level' cut, remove any guide comb and use the bare blade directly on the skin. Exercise caution, especially on sensitive areas.



This image shows the Valera Absolut Zero professional hair clipper in action, being used to trim hair on the back of a man's head, highlighting its ergonomic design and precision for detailed work.

### **Hair Trimming:**

Attach the appropriate guide comb. Start with a longer comb if you are unsure of the desired length. Work from the bottom upwards, lifting the hair with the comb and guiding the clipper through.

### **Beard and Body Trimming:**

For beard and body hair, you can use the guide combs for longer styles or the bare blade for a very close trim. Always stretch the skin taut in sensitive areas to prevent nicks and cuts.



A detailed view of the Valera Absolut Zero's DuraBlade, made from Japanese steel, emphasizing its ability to achieve a 'Zero Level Haircut' with a minimal cutting length of 0.1 mm.



This image illustrates the compact and lightweight design of the Valera Absolut Zero clipper, fitting comfortably in the hand for easy maneuverability during grooming.

## MAINTENANCE

Regular cleaning and maintenance will ensure optimal performance and extend the life of your Valera Absolut Zero clipper.

1. **Cleaning the Blades:** After each use, switch off the clipper and detach any guide comb. Use the provided cleaning brush to remove loose hairs from the blades and the clipper head.
2. **Lubricating the Blades:** After cleaning, apply 1-2 drops of the lubricating oil to the blades. Turn the clipper on for a few seconds to distribute the oil evenly. This reduces friction and keeps the blades sharp.

3. **Cleaning the Body:** Wipe the body of the clipper with a soft, damp cloth. Do not use abrasive cleaners or immerse the clipper in water.
4. **Storage:** Store the clipper and its accessories in a dry, safe place, away from children.

## TROUBLESHOOTING

If you encounter any issues with your Valera Absolut Zero clipper, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Clipper does not turn on.	Battery is depleted.	Charge the clipper fully. Ensure the charging adapter is properly connected.
Clipper pulls hair or cuts poorly.	Blades are dirty or not lubricated. Blades may be dull.	Clean the blades thoroughly and apply lubricating oil. If the problem persists, consider professional blade sharpening or replacement.
Reduced battery life.	Battery is old or not fully charged.	Ensure the clipper is fully charged before use. Over time, rechargeable batteries may degrade; contact support for battery replacement options if necessary.
Clipper gets hot during use.	Blades are not lubricated or excessive friction.	Ensure blades are clean and well-oiled. Avoid prolonged continuous use; allow the clipper to cool down if it becomes excessively warm.

## SPECIFICATIONS

- **Model:** Valera Absolut Zero 658.01
- **Brand:** Valera
- **Country of Origin:** Switzerland
- **Blade Material:** DuraBlade (Japanese Alloy Steel, Diamond-ground)
- **Minimum Cutting Length:** 0.1 mm
- **Blade Width:** 42 mm
- **Power Source:** Cordless (Rechargeable Lithium-ion Battery) / Corded (Mains Power)
- **Battery Type:** 2 Lithium-ion (included)
- **Battery Life:** Up to 120 minutes (cordless operation)
- **Dimensions (L x W x H):** 14.5 x 4.5 x 3.5 cm
- **Weight:** 152 grams
- **Included Components:** Clipper, Charger, 3 Guide Combs, Lubricating Oil, Cleaning Brush

## WARRANTY AND SUPPORT

The Valera Absolut Zero 658.01 Professional All-in-One Hair Clipper comes with a **5-year warranty**, reflecting Valera's commitment to Swiss quality and precision. This warranty covers manufacturing defects and ensures reliable performance under normal use.



A red badge prominently displaying '5 YIL GARANTİ', signifying the product's 5-year warranty, reflecting its Swiss quality and durability.

For warranty claims, technical support, or any questions regarding your product, please contact Valera customer service through their official website or the retailer where the product was purchased. Please retain your proof of purchase for warranty validation.