

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Mabe](#) /

› [Mabe RME360FZMRX0 Automatic 360L Stainless Steel Refrigerator User Manual](#)

Mabe RME360FZMRX0

Mabe RME360FZMRX0 Automatic 360L Stainless Steel Refrigerator User Manual

Model: RME360FZMRX0 | Brand: Mabe

[Introduction](#) [Safety Information](#) [Setup](#) [Operating Instructions](#) [Maintenance](#)
[Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of your Mabe RME360FZMRX0 Automatic 360L Stainless Steel Refrigerator. Please read this manual thoroughly before using your appliance to ensure safe and efficient operation. Keep this manual for future reference.

The Mabe RME360FZMRX0 refrigerator offers a spacious interior for storing various food items and large containers. It features deep shelves designed for easy storage of bottles and tubs, and incorporates Home Energy Saver Technology for energy efficiency, improved food preservation, and freshness.

2. IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Read all instructions before using the appliance.
- Ensure the refrigerator is properly grounded.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not damage the refrigerant circuit.
- Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- Unplug the refrigerator before cleaning or performing any maintenance.
- Supervise children to ensure they do not play with the appliance.

3. SETUP AND INSTALLATION

3.1 Unpacking

Carefully remove all packaging materials, including tape and protective films. Dispose of packaging responsibly. Ensure no parts are missing or damaged.

3.2 Location Requirements

Place the refrigerator on a flat, stable surface away from direct sunlight, heat sources (like stoves or radiators), and moisture. Allow adequate space around the unit for proper ventilation (at least 10 cm on sides and back, 30 cm on top).

Imagen ilustrativa de las dimensiones del producto. Las características y configuración del mismo puede variar respecto a la imagen.

 **63.0 kg**




Figure 3.1: Product Dimensions. The refrigerator measures 181 cm in height, 71 cm in width, and 82 cm in depth, with a weight of 63 kg.

3.3 Leveling the Refrigerator

Adjust the leveling feet at the bottom of the refrigerator to ensure it is stable and level. This prevents vibrations and

ensures proper door sealing.

3.4 Electrical Connection

Connect the refrigerator to a dedicated, grounded electrical outlet. Do not use extension cords or adapters. Ensure the voltage matches the appliance's requirements (342 Volts as per specifications, please verify local electrical standards).

3.5 Initial Operation

After installation, wait at least 2-4 hours before plugging in the refrigerator to allow refrigerants to settle. Once plugged in, allow the unit to run for several hours (e.g., 4-6 hours) to reach optimal operating temperatures before loading with food.

4. OPERATING INSTRUCTIONS

4.1 Control Panel Overview

Your Mabe RME360FZMRX0 refrigerator features an intuitive control panel for managing various settings.



Figure 4.1: Control Panel. This panel allows adjustment of refrigerator temperature, activation of 'Turbo Cool' for rapid cooling, 'Holidays' mode for energy saving during extended absence, 'Alarm' for door open warnings, 'Lock' to prevent accidental changes, and 'Eco Activated' for energy-efficient operation.

4.2 Temperature Control

Use the 'Fridge Temp' button on the control panel to adjust the temperature of the refrigerator compartment. Settings typically range from 'cold' to 'coldest' (indicated by asterisks). Select a setting that best suits your food storage needs.

4.3 Special Functions

- **Turbo Cool:** Activates rapid cooling for a short period, useful when adding a large amount of new food or after the door has been open for an extended time.
- **Holidays:** Sets the refrigerator to an energy-saving mode suitable for periods when the appliance will not be opened frequently, such as during vacations.
- **Alarm:** Notifies you if the refrigerator door is left open for too long, helping to maintain internal temperature and save energy.
- **Lock:** Locks the control panel to prevent accidental changes to settings.
- **Eco Activated:** Indicates that the refrigerator is operating in an energy-efficient mode, leveraging the Home Energy Saver Technology.

4.4 Water Dispenser

Your refrigerator is equipped with an external water dispenser. To use, place a glass or container under the dispenser nozzle and press the lever. Ensure the internal water tank is filled for operation.



Figure 4.2: Water Dispenser. The external water dispenser provides convenient access to chilled water.

4.5 Ice Maker (Manual Twist)

The freezer compartment includes a manual twist ice maker. Fill the ice trays with water, allow them to freeze, then twist the knobs to release ice into the collection bin.



Figure 4.3: Manual Twist Ice Maker. Located in the freezer, this allows for convenient ice production.

5. MAINTENANCE AND CARE

5.1 Cleaning the Interior

Unplug the refrigerator before cleaning. Remove all food items and shelves. Wash interior surfaces with a solution of mild soap and warm water. Rinse and dry thoroughly. Do not use abrasive cleaners or harsh chemicals.



Figure 5.1: Refrigerator Interior. The spacious interior includes adjustable shelves and door bins for organized storage.

5.2 Cleaning the Exterior

Wipe exterior surfaces with a soft cloth dampened with mild soap and water. For stainless steel surfaces, use a specialized stainless steel cleaner and polish in the direction of the grain. Avoid harsh chemicals or abrasive pads.

5.3 Condenser Coils

Periodically clean the condenser coils located at the back or bottom of the refrigerator. Dust and debris can accumulate, reducing efficiency. Use a vacuum cleaner with a brush attachment to gently remove buildup.

5.4 Automatic Defrost System

This refrigerator features an automatic defrost system, eliminating the need for manual defrosting of the freezer compartment. Ensure the drain pan is clear of obstructions.

6. TROUBLESHOOTING GUIDE

Before contacting service, review this section for common issues and their solutions.

Problem	Possible Cause	Solution
Refrigerator does not operate.	No power supply; power cord unplugged; circuit breaker tripped.	Check power connection; reset circuit breaker.
Refrigerator is not cold enough.	Temperature setting too high; door left open; excessive food load; poor ventilation.	Adjust temperature setting; ensure door is closed; reduce food load; check ventilation.
Unusual noises.	Refrigerator not level; objects vibrating against the unit; compressor noise (normal).	Level the refrigerator; remove vibrating objects.
Water dispenser not working.	Water tank empty; dispenser locked.	Refill water tank; unlock dispenser via control panel.
Door alarm sounds frequently.	Door not closing properly; door seal damaged.	Ensure door is fully closed; inspect and clean door seal.

7. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Mabe
Model Number	RME360FZMRX0
Capacity	360 Liters
Configuration	Top Freezer
Color	Stainless Steel
Special Feature	Automatic Defrost, Home Energy Saver Technology
Installation Type	Freestanding
Number of Doors	1
Dimensions (D x W x H)	82 cm x 71 cm x 181 cm
Weight	63 kg
Voltage	342 Volts (Please verify local electrical standards)



Figure 7.1: Energy Efficiency. This refrigerator features Home Energy Saver Technology, contributing to significant energy savings.

8. WARRANTY AND SUPPORT

For detailed warranty information, please refer to the warranty card included with your product or visit the official Mabe website. Keep your purchase receipt as proof of purchase for warranty claims.

If you encounter issues not covered in the troubleshooting section or require technical assistance, please contact Mabe customer support. Contact details can typically be found on the Mabe website or in your product documentation.

You can also visit the [Mabe Brand Store on Amazon](#) for additional product information and support resources.