

[Manuals.plus](#) /

> [Beldray](#) /

> Beldray EH3328 4 in 1 Orbit Air Climate Circulator, Heater, Humidifier & Air Cooler User Manual

## Beldray EH3328

# Beldray EH3328 4-in-1 Orbit Air Climate Circulator User Manual

Model: EH3328

## IMPORTANT SAFETY INSTRUCTIONS

---

Please read these instructions carefully before using your Beldray EH3328 Orbit Air Climate Circulator. Keep this manual for future reference.

- Ensure the appliance is placed on a firm, flat, heat-resistant surface.
- Do not immerse the appliance in water or any other liquid.
- Keep out of reach of children and pets.
- Always unplug the appliance from the mains power supply when not in use, before cleaning, or before performing any maintenance.
- Do not operate the appliance with a damaged cord or plug.
- Do not block any ventilation openings.
- Use only clean, distilled water in the humidifier tank.
- Do not add essential oils directly into the water tank; use the designated aroma function tray.

## PRODUCT OVERVIEW

---

The Beldray EH3328 is a versatile 4-in-1 climate control device, combining the functions of a heater, humidifier, air cooler, and air circulator. It features adjustable temperature control, multiple wind modes, an aroma function, and a timer.





Image: Front view of the Beldray EH3328 4-in-1 Orbit Air Climate Circulator, showcasing its sleek white and black design with the control panel visible at the base.

## SETUP

---

### Unboxing and Placement

1. Carefully remove the appliance from its packaging.

2. Place the unit on a stable, level surface, ensuring there is adequate space around it for proper air circulation. Avoid placing it directly against walls or furniture.
3. Ensure the power cord is not obstructed or tangled.

### Filling the Water Tank (Humidifier Function)



Image: A hand pouring water into the removable water tank of the Beldray EH3328, demonstrating the refilling process for the humidifier function.

1. Locate the water tank at the base of the unit.
2. Carefully remove the water tank.
3. Fill the tank with clean, distilled water up to the 'MAX' fill line. The tank capacity is 350 ml.
4. Securely replace the water tank into the unit.
5. The humidifier function will not operate if the water tank is empty or incorrectly installed.

### Using the Aroma Function



Image: A hand adding drops of essential oil to the small, removable aroma diffusion tray of the Beldray EH3328, located near the base of the unit.

1. Locate the aroma tray, typically a small pull-out drawer or compartment, on the unit.
2. Add a few drops of your preferred essential oil onto the sponge or pad inside the tray.
3. Slide the aroma tray back into its position.
4. The aroma will diffuse into the air when the unit is operating.

## OPERATING INSTRUCTIONS

---

The Beldray EH3328 can be operated using the control panel on the unit or the supplied remote control.

### Control Panel and Remote Control



Image: The remote control for the Beldray EH3328, showing various buttons for power, mode selection, temperature, and timer functions. Both the control panel and remote control feature intuitive buttons for various functions. Ensure the remote control has working batteries (not supplied) before use.

### Power On/Off

- Plug the appliance into a suitable mains power outlet.
- Press the **Power** button (usually marked with an 'On/Off' symbol) on the control panel or remote control to turn the unit on or off.

### Mode Selection (Heater, Humidifier, Fan)



Image: The Beldray EH3328 in a living room setting, with visual effects indicating both heating (red glow) and cooling (blue glow) capabilities, demonstrating its dual functionality.

- Press the **Mode** button to cycle through the available modes:
  - **Heater:** Provides warm air. The heating power is 1800W.
  - **Humidifier:** Releases cool mist to increase humidity. Requires water in the tank.
  - **Fan/Air Cooler:** Circulates air without heating.

## Adjusting Temperature (Heater Mode)



## ADJUSTABLE TEMPERATURE CONTROL

Between 12 C and 27 C

Image: A close-up of the Beldray EH3328's digital display showing the temperature setting, indicating adjustable temperature control between 12°C and 27°C.

- In Heater mode, use the '+' and '-' buttons to adjust the desired temperature between 12°C and 27°C.

## Wind Selection and Modes (Fan Mode)

- In Fan mode, press the **Wind Speed** button to cycle through 12 levels of wind selection.
- Press the **Wind Mode** button to select from 4 wind modes:
  - **Normal:** Constant airflow.
  - **Natural:** Simulates natural breeze with varying speeds.
  - **Sleep:** Quieter operation with reduced fan speed for comfortable sleep.
  - **Eco:** Energy-saving mode.

## Oscillation Function



Image: The Beldray EH3328 with arrows indicating its oscillation capabilities, showing full air circulation for the entire room, including up/down and side-to-side movement.

- Press the **Oscillation** button to activate the oscillation function, allowing the unit to rotate and distribute air across a wider area.
- Press the button again to stop oscillation at the desired position.

## Timer Function



Image: A finger pointing to the control panel of the Beldray EH3328, with the digital display showing a timer setting, indicating the 7.5-hour timer function.

- Press the **Timer** button to set the operating duration. The timer can be set up to 7.5 hours.
- Each press typically increases the timer by a set increment (e.g., 0.5 hours or 1 hour). The unit will automatically turn off once the set time has elapsed.

## MAINTENANCE

Regular cleaning and maintenance will ensure the longevity and optimal performance of your Beldray EH3328.

### Cleaning the Exterior

- Always unplug the appliance from the mains power supply before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Ensure no water enters the internal components.
- Dry thoroughly before plugging back in.

### Cleaning the Water Tank and Humidifier Nozzle



## HUMIDIFIER FUNCTION

With 350 ml water tank

Image: A close-up of the Beldray EH3328's humidifier function, showing a fine mist being emitted from the nozzle, highlighting its ability to rejuvenate air.

- Remove the water tank and empty any remaining water.
- Rinse the tank thoroughly with clean water. For stubborn mineral deposits, a mild descaling solution (e.g., white vinegar diluted with water) can be used. Rinse thoroughly after descaling.
- Gently wipe the humidifier nozzle and surrounding area to remove any buildup.
- Allow all parts to air dry completely before reassembling.

## Aroma Tray Cleaning

- Remove the aroma tray.
- Clean the sponge or pad with mild soap and water, or replace it if necessary.
- Ensure the tray is dry before reinserting.

## Storage

- If storing the appliance for an extended period, ensure it is clean and dry.
- Store in a cool, dry place, away from direct sunlight and extreme temperatures.
- It is recommended to store the unit in its original packaging to protect it from dust and damage.

## TROUBLESHOOTING

Before contacting customer support, please refer to the following common issues and their solutions.

Problem	Possible Cause	Solution
Unit does not turn on.	Not plugged in; power outlet faulty; power button not pressed.	Ensure the power cord is securely plugged into a working outlet. Press the power button firmly.
No mist from humidifier.	Water tank empty; water tank not properly installed; humidifier mode not selected.	Fill the water tank. Ensure the tank is correctly seated. Select humidifier mode.
Weak airflow.	Fan speed set too low; air intake/outlet blocked.	Increase fan speed. Ensure nothing is obstructing the air intake or outlet grilles.
No heat in heater mode.	Heater mode not selected; temperature setting too low.	Ensure Heater mode is active. Increase the target temperature.
Remote control not working.	Batteries are dead or incorrectly inserted; remote not pointed at unit.	Replace batteries, ensuring correct polarity. Point the remote directly at the unit's sensor.

## SPECIFICATIONS

Feature	Detail
Brand	Beldray
Model Number	EH3328
Product Dimensions	32.5 x 27.5 x 44.8 cm
Item Weight	4.4 kg
Power/Wattage	1800 watts
Humidifier Capacity	350 Millilitres
Material	Plastic
Temperature Control Range	12°C - 27°C
Wind Selection Levels	12
Wind Modes	Normal, Natural, Sleep, Eco
Timer Function	Up to 7.5 hours
Special Features	Temperature Control, Timer, Aroma Function, Oscillation

## WARRANTY AND SUPPORT

For warranty information, product registration, or technical support, please refer to the official Beldray website or contact their customer service department.

- **Online Support:** Visit the Beldray official website for FAQs and support resources.
- **Customer Service:** Contact details for customer service can typically be found on the Beldray website or on the product packaging.
- **Proof of Purchase:** Please retain your proof of purchase for any warranty claims.



© 2023 Beldray. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.