

BoxWave ClearTouch Anti-Glare Screen Protector

BoxWave ClearTouch Anti-Glare Screen Protector User Manual

Model: ClearTouch Anti-Glare Screen Protector

INTRODUCTION

The BoxWave ClearTouch Anti-Glare Screen Protector is designed to protect your device's screen while enhancing visibility and usability. This manual provides essential information for the proper installation, use, and maintenance of your screen protector.

PACKAGE CONTENTS

Each package of the BoxWave ClearTouch Anti-Glare Screen Protector includes the following items:

- Two (2) ClearTouch Anti-Glare Screen Protectors
- One (1) Applicator Card
- One (1) Microfiber Cleaning Cloth
- One (1) Dust Removing Sticker



Image: Contents of the BoxWave ClearTouch Anti-Glare Screen Protector package, showing two screen protectors, an applicator card, a microfiber cloth, and a dust removing sticker.

***ClearTouch** screen protector* *included accessories*



***Applicator
Card***



***Microfiber
Cleaning Cloth***



***Dust Removing
Sticker***

Image: Close-up view of the included accessories: Applicator Card, Microfiber Cleaning Cloth, and Dust Removing Sticker.

INSTALLATION GUIDE

Follow these steps carefully for optimal installation of your ClearTouch Anti-Glare Screen Protector:

1. **Prepare Your Device:** Ensure your device is powered off. Use the included microfiber cleaning cloth to thoroughly clean the screen surface, removing all dust, smudges, and fingerprints. For stubborn spots, a small amount of screen cleaner can be used, followed by drying with the cloth.
2. **Remove Dust:** Use the dust removing sticker to lift any remaining dust particles from the screen. Lightly dab the sticker across the entire screen surface.
3. **Peel Back Layer 1:** Carefully peel back a small portion of the protective film labeled "Layer 1" from one end of the screen protector. Avoid touching the adhesive side.
4. **Align the Protector:** Align the exposed adhesive edge of the screen protector with one edge of your device's screen. Ensure precise alignment with all cutouts (e.g., camera, sensors) before proceeding.
5. **Apply and Smooth:** Slowly and steadily peel back the rest of "Layer 1" while simultaneously using the applicator card to smooth the screen protector onto the screen. Apply gentle, even pressure from the aligned edge towards the

opposite end, pushing out any air bubbles as you go.

6. **Remove Air Bubbles:** If bubbles remain, gently push them towards the nearest edge using the applicator card. For persistent bubbles, you may carefully lift a small section of the protector and reapply, smoothing it down again.
7. **Remove Layer 2:** Once the screen protector is fully applied and free of bubbles, carefully peel off the top protective film labeled "Layer 2".
8. **Final Clean:** Use the microfiber cloth to gently wipe the newly installed screen protector, removing any smudges from the installation process.

OPERATING AND FEATURES

The BoxWave ClearTouch Anti-Glare Screen Protector offers several key features to enhance your device experience:

- **Anti-Glare Surface:** The matte finish disperses light, significantly reducing glare from ambient light sources and direct sunlight. This improves screen readability in various lighting conditions and reduces eye strain.
- **Anti-Fingerprint & Anti-Smudge:** The specialized surface repels unwanted smudges, dust, and fingerprints, keeping your screen cleaner for longer.
- **Paper-like Feel:** The ultra-smooth matte surface provides a tactile experience similar to writing or drawing on paper, enhancing precision and comfort for stylus use.
- **Precision Cut:** Each ClearTouch protector is precision-cut to fit your specific device model's exact dimensions, including all contours and cut-outs, ensuring full accessibility to all device functionalities.
- **Reusable Adhesive:** The glueless adhesive allows for clean application without leaving sticky residue. The protector can be removed, cleaned, and reinstalled if needed.

Paper-like Feel

Write and draw on your screen with the same feel as on paper




Image: Demonstration of the paper-like feel feature, showing a stylus being used on a tablet screen with the screen protector applied.

Anti-Smudge

The ClearTouch Anti-Glare screen protector provides superior defense against scratches while resisting oil smudges and fingerprints. Its oleophobic layer helps keep your screen cleaner for longer, maintaining a smooth touch response throughout the day.

BoxWave ClearTouch Anti-Glare Screen Protector



Image: Visual comparison demonstrating the anti-smudge properties of the ClearTouch Anti-Glare screen protector versus a standard screen.



Image: Illustration showing how the anti-glare feature reduces distracting reflections on a smartphone screen.

MAINTENANCE

To maintain the clarity and effectiveness of your screen protector, follow these simple cleaning guidelines:

- Use the included microfiber cleaning cloth to gently wipe the screen protector.
- For more stubborn smudges or dirt, slightly dampen the microfiber cloth with water or a screen-safe cleaning solution. Avoid harsh chemicals or abrasive materials.
- Do not apply excessive pressure when cleaning, as this could potentially damage the screen protector or the device screen underneath.

TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|---------------------------------|--|--|
| Bubbles under the protector | Dust particles or trapped air during installation. | Gently push bubbles towards the nearest edge with the applicator card. For dust-related bubbles, carefully lift the nearest edge of the protector, use the dust removing sticker to lift the dust, then reapply. |
| Protector not adhering properly | Screen not clean enough, or adhesive side touched. | Ensure the screen is completely clean and free of oils/dust before application. If the adhesive side was touched, it might be compromised. Consider using the second protector from the 2-pack. |
| Misalignment | Incorrect positioning during initial application. | Carefully lift the protector from the misaligned edge and re-align. Reapply slowly, ensuring proper positioning before smoothing down. |

SPECIFICATIONS

| Attribute | Detail |
|-----------|--|
| Brand | BoxWave |
| Model | ClearTouch Anti-Glare Screen Protector |

| Attribute | Detail |
|--------------------|---|
| Compatible Devices | Samsung SHP-DP727 (and other devices as specified by product variant) |
| Material | Polyethylene Terephthalate (PET) |
| Special Feature | Anti-Glare, Anti-Fingerprint, Matte Finish |
| Finish Type | Matte |
| Number of Items | 2 (Two-Pack) |
| Item Weight | 0.7 ounces |

WARRANTY INFORMATION

BoxWave products are manufactured with quality and durability in mind. While specific warranty terms may vary, BoxWave typically offers support for manufacturing defects. Please retain your proof of purchase. For detailed warranty information or to make a claim, please refer to the official BoxWave website or contact their customer support directly.


SUPPORT AND CONTACT

If you encounter any issues or have questions regarding your BoxWave ClearTouch Anti-Glare Screen Protector, please contact BoxWave customer support:

- **Website:** www.boxwave.com (Please check the official website for the most current contact information.)
- **Email:** Refer to the official website for customer service email addresses.
- **Phone:** Refer to the official website for customer service phone numbers.

When contacting support, please have your product model (ClearTouch Anti-Glare Screen Protector) and purchase details ready.

Related Documents - ClearTouch Anti-Glare Screen Protector



[StarTech.com Privacy Screen for MacBook Pro 2021 Quick-Start Guide](#)

A quick-start guide for installing the StarTech.com Privacy Screen for MacBook Pro 2021. Includes package contents, requirements, and installation steps.