Fischer & Honsel 40075

Fischer & Honsel Pool TW 40075 LED Floor Lamp User Manual

Model: 40075

Introduction

This manual provides essential information for the safe and efficient operation of your Fischer & Honsel Pool TW 40075 LED Floor Lamp. Please read these instructions carefully before assembly and use, and retain them for future reference.

Safety Instructions

- Ensure the power supply voltage matches the lamp's requirements (230 Volts).
- This product is designed for indoor use only (IP20 rating). Do not expose to moisture or extreme temperatures.
- Do not attempt to modify or repair the lamp. Repairs should only be performed by qualified personnel.
- Always disconnect the power supply before cleaning or performing any maintenance.
- Keep packaging materials away from children to prevent choking hazards.
- The LED light sources are permanently installed and cannot be replaced by the user.

Package Contents

Verify that all components are present before assembly:

- 1 x Fischer & Honsel Pool TW 40075 LED Floor Lamp (unassembled)
- 1 x User Manual

Setup

Follow these steps to assemble your floor lamp:

1. Carefully unpack all components and place them on a clean, flat surface.
2. Attach the base to the main pole, ensuring it is securely fastened.
3. Connect the upper sections of the lamp pole, twisting them clockwise until tight. Ensure all electrical connections within the poles are properly aligned.
4. Position the flexible reading arm as desired.
5. Place the lamp in its desired location, ensuring it is stable and on a level surface.
6. Plug the power cord into a suitable 230V AC outlet.





The Fischer & Honsel Pool TW 40075 LED Floor Lamp assembled in a living room environment.



Dimensions of the floor lamp: 182 cm height, 32 cm base diameter, and 53 cm overall width.

Operating Instructions

Power On/Off and Dimming

The lamp features a sensor dimmer switch. To turn the lamp on or off, or to adjust the brightness, use the touch-sensitive controls located on the lamp pole. The uplighter and the reading arm can be dimmed continuously and independently.

Color Temperature (CCT) Adjustment

The CCT function allows you to select from three distinct color temperature levels:

- **2700 K (Warm White):** Provides a cozy and relaxing atmosphere.
- **3350 K (Neutral White):** Suitable for general illumination and daily tasks.
- **4000 K (Cool White):** Ideal for focused work or when higher alertness is desired.

Cycle through these color temperatures using the dedicated CCT control on the lamp. This function enhances the versatility of the lamp for various moods and activities.



The control panel showing CCT adjustment and dimming features.

Maintenance

Cleaning

- Before cleaning, ensure the lamp is unplugged from the power outlet.
- Wipe the lamp's metal surfaces with a soft, dry cloth.
- For glass components, use a soft, damp cloth and a mild glass cleaner if necessary. Avoid abrasive cleaners.

LED Lifespan

The integrated LED light sources have an average lifespan of 30,000 hours, providing long-lasting illumination without the need for bulb replacement.

Troubleshooting

If you encounter issues with your lamp, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Lamp does not turn on.	No power supply.	Check if the power cord is securely plugged into the outlet. Verify the outlet is functional.
Light flickers or is unstable.	Loose connection or power fluctuation.	Ensure all lamp sections are tightly assembled. Try plugging into a different outlet.
Dimming or CCT function not responding.	Sensor issue or temporary malfunction.	Unplug the lamp for 30 seconds, then plug it back in to reset. Ensure the sensor area is clean.

If the problem persists, contact customer support.

Specifications

Feature	Detail
Model Number	40075
Brand	Fischer & Honsel
Dimensions (L x W x H)	32 x 32 x 182 cm
Weight	7.61 kg
Color	Nickel
Material	Metal, Glass (shade)
Light Source	Integrated LED (Uplighter: 28W, Reading Arm: 5W)
Voltage	230 Volts AC
Luminous Flux	3500 lm (total)
Color Temperature (CCT)	2700 K, 3350 K, 4000 K (adjustable)
Dimmable	Continuously dimmable (uplighter and reading arm independently)
Switch Type	Sensor Dimmer
IP Rating	IP20 (Indoor use only)
Average Lifespan	30,000 Hours
Energy Efficiency	High energy efficiency

Feature	Detail
Color Rendering Index (CRI)	80

Warranty

This product is covered by a standard manufacturer's warranty. Please refer to your purchase documentation for specific terms and conditions. The warranty typically covers defects in materials and workmanship under normal use.

Support

For technical assistance, warranty claims, or further inquiries, please contact Fischer & Honsel customer service through their official website or the retailer where the product was purchased.

© 2023 Fischer & Honsel. All rights reserved.