

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [AECOJOY](#) /

› [AECOJOY 7 Piece Outdoor Patio Furniture Set Instruction Manual](#)

## AECOJOY B08WYL647B

# AECOJOY 7 Piece Outdoor Patio Furniture Set Instruction Manual

Model: B08WYL647B | Brand: AECOJOY

## 1. INTRODUCTION

Welcome to the AECOJOY family! This manual provides essential information for the assembly, operation, and maintenance of your new 7-piece outdoor patio furniture set. Designed for comfort and versatility, this set includes 4 armless chairs, 2 corner chairs, and 1 coffee table with a tempered glass top, allowing for numerous configurations to suit your outdoor space.

Please read these instructions carefully before assembly and use to ensure safe operation and longevity of your furniture.

## 2. SAFETY INFORMATION

Your safety is paramount. Adhere to the following guidelines to prevent injury or damage to the product:

- Always assemble the furniture on a flat, stable surface.
- Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not stand on the furniture.
- Do not place excessively hot items directly on the tempered glass tabletop without protection.
- As per manufacturer's instructions: *Do not clean with water or liquid substances, use a dry cloth to wipe off dirt or spills.*
- Keep children and pets away from the assembly area.
- Avoid exposing the furniture to extreme weather conditions for prolonged periods to maximize its lifespan.

### 3. PACKAGE CONTENTS

---

Before beginning assembly, verify that all components listed below are present and undamaged. The furniture will arrive in multiple boxes.

- 4 x Armless Chairs
- 2 x Corner Chairs
- 1 x Coffee Table with Tempered Glass Top
- 6 x Soft Cushions (Seat and Backrest)
- Assembly Hardware and Tools



Figure 3.1: Overview of all included components.

### 4. SETUP INSTRUCTIONS

---

Assembly of the AECOJOY patio furniture set is designed to be straightforward and can typically be completed by one person in 40-60 minutes. Follow the detailed instructions provided in the included hardware package.

#### 4.1 Assembly Steps

1. Unpack all components and lay them out on a clean, flat surface.
2. Identify the frame pieces for each chair and the coffee table.
3. Connect the frame pieces using the provided screws and tools. Do not fully tighten screws until all pieces are aligned.
4. Once all frame pieces are loosely assembled, gently place the unit on its intended location and then fully tighten all screws. This helps ensure proper alignment.
5. Place the tempered glass top onto the coffee table frame.
6. Attach the cushions to the chairs. The back cushions feature fastener clips for connection to the seat cushions, preventing them from sliding.

# Furniture Set Size

*There will be a total of two boxes delivered together, may not be delivered on the same day, please wait patiently.*







Figure 4.1: Furniture Set Dimensions for planning your layout.

# Product Details

Note Rain-Proof so please not expose to rainy days



STRAP CUSHION



WEATHER RESISTANT PE RATTAN



ANTI-SKIDDING FEET



ALUMINUM FRAME



Figure 4.2: Key product details including rattan weave and frame structure.

## 4.2 Assembly Video Guide

For a visual guide on assembly and key features, please watch the official product video:

Your browser does not support the video tag.

Video 4.1: AECOJOY 7 Pieces Patio Sectional Sofa Set - This video demonstrates the assembly process, highlighting features like thick padded cushions, weather-resistant rattan, tempered glass tabletop, fastener clips for connection, and splashproof fabric.

## 5. OPERATING INSTRUCTIONS

The AECOJOY 7-piece patio furniture set offers infinite combinations, allowing you to customize its layout to match your patio, deck, backyard porch, or pool area. The individual pieces can be freely rearranged to create various seating arrangements, from a large sectional sofa to separate chairs and a coffee table.



*Freely Recombine into Different Combinations*



Figure 5.1: Examples of various furniture configurations.

## 6. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your patio furniture set:

- **Cleaning the Wicker:** Wipe the PE wicker with a dry cloth to remove dirt or spills. Avoid using harsh chemicals or abrasive cleaners.
- **Cushion Care:** The cushions are zippered and washable. Remove the covers for easy cleaning. The fabric is splashproof, allowing water to bead off, but it is recommended to store cushions indoors during heavy rain or prolonged periods of non-use to prevent excessive moisture absorption and maintain their quality.
- **Tempered Glass:** Clean the tempered glass tabletop with a glass cleaner and a soft cloth.
- **General Protection:** While the set is designed for outdoor use, covering it during off-seasons or extreme weather conditions (heavy rain, snow, intense sun) will help preserve its material and color.



Figure 6.1: Cushion features for easy maintenance and comfort.

## 7. TROUBLESHOOTING

If you encounter any issues with your AECOJOY patio furniture set, refer to the common solutions below:

- **Cushions Sliding:** Ensure the fastener clips on the back cushions are properly secured to the seat cushions. Adjust the position of the cushions as needed.
- **Assembly Difficulties:** If pieces do not align, loosen all screws slightly, adjust the alignment, and then re-tighten. Refer to the assembly video (Video 4.1) for visual guidance.
- **Wicker Damage:** While the PE wicker is durable, extreme heat or sharp objects can cause damage. For minor fraying, carefully trim loose strands. For significant damage, contact customer support.
- **Water Stains on Cushions:** Although cushions are water-repellent, prolonged exposure to moisture can lead to stains. Remove cushion covers and wash them according to care instructions. Ensure they are completely dry before reattaching.

## 8. PRODUCT SPECIFICATIONS

Feature	Specification
Brand	AECOJOY
Model	B08WYL647B
Material	PE wicker, Tempered Glass
Color	Black Rattan & Beige Cushion
Item Depth	89.4 inches
Product Care Instructions	Wipe with Wicker

## 9. WARRANTY AND CUSTOMER SUPPORT

For information regarding product warranty, returns, or to purchase protection plans, please refer to the product's listing page on Amazon or contact AECOJOY customer support directly. Protection plans are available for 2-Year and 3-Year durations.

Visit the official AECOJOY Store for more products and support:[AECOJOY Store](#)