



Manuals.plus /

› JBL /

› JBL Clip 4 Portable Bluetooth Speaker User Manual

JBL JBLCLIP4BLKAM

JBL Clip 4 Portable Bluetooth Speaker User Manual

Model: JBLCLIP4BLKAM

INTRODUCTION

Thank you for choosing the JBL Clip 4 Portable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. The JBL Clip 4 delivers surprisingly rich audio and punchy bass from its compact size, featuring an ultra-portable design with an integrated carabiner, and is IP67 waterproof and dustproof.

SAFETY INFORMATION

Please read all safety instructions carefully before using this product. Keep this manual for future reference.

- Do not expose the speaker to extreme temperatures (above 45°C or below 0°C).
- Do not disassemble, repair, or modify the speaker. This will void the warranty.
- Use only the charging cable provided or a certified equivalent.
- Ensure the charging port is dry before connecting the charging cable.
- Keep the speaker away from strong magnetic fields.
- Dispose of the battery responsibly according to local regulations.

PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x JBL Clip 4 Portable Bluetooth Speaker
- 1 x USB-C Charging Cable
- 1 x Quick Start Guide
- 1 x Safety Sheet

PRODUCT OVERVIEW

Familiarize yourself with the components and controls of your JBL Clip 4 speaker.



Figure 1: Front view of the JBL Clip 4 speaker, showing the JBL logo and control buttons.



BOLD DESIGN



Portable, rugged materials protect your speaker on every adventure.

Figure 2: Side view highlighting the integrated carabiner and rugged design.

Controls and Indicators:

- **Power Button:** Located on the side, press to turn on/off.
- **Bluetooth Button:** Located on the side, press to enter pairing mode.
- **Volume Up (+):** Increases volume.
- **Volume Down (-):** Decreases volume.
- **Play/Pause Button:** Controls music playback.
- **USB-C Charging Port:** For charging the speaker.
- **Integrated Carabiner:** For attaching the speaker to bags or loops.

SETUP

1. Charging the Speaker

Before first use, fully charge your JBL Clip 4. The battery life is approximately 10 hours, but actual playtime may vary based on

volume level and audio content.

1. Connect the USB-C charging cable to the charging port on the speaker.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will show charging status. It will turn off once fully charged.



Figure 3: Illustration of the JBL Clip 4's battery life, indicating up to 10 hours of playtime.

2. Bluetooth Pairing

Pair your JBL Clip 4 with your Bluetooth-enabled device (e.g., smartphone, tablet).

1. Turn on the speaker by pressing the Power button. The LED indicator will blink blue, indicating it's in pairing mode.
2. On your device, go to Bluetooth settings and enable Bluetooth.
3. Select "JBL Clip 4" from the list of available devices.
4. Once connected, the LED indicator will turn solid blue.

Note: The speaker will automatically reconnect to the last paired device if it's within range and Bluetooth is enabled.

Music Playback

- Press the Play/Pause button once to play or pause music.
- Press the Play/Pause button twice to skip to the next track.
- Press the Volume Up (+) button to increase the volume.
- Press the Volume Down (-) button to decrease the volume.



Figure 4: The JBL Clip 4 is designed to deliver surprisingly big sound from a compact form factor.

Waterproof and Dustproof (IP67)

The JBL Clip 4 is rated IP67, meaning it is fully waterproof and dustproof. It can be immersed in water up to 1 meter for up to 30 minutes.

- Ensure the USB-C port cover is securely closed before exposing the speaker to water or dust.
- Rinse with fresh water after exposure to saltwater or chlorinated water.

- Do not charge the speaker if it is wet.



Figure 5: The JBL Clip 4 is shown near water, illustrating its IP67 waterproof rating.

MAINTENANCE

Cleaning

- Wipe the speaker with a soft, damp cloth.
- Do not use abrasive cleaners or solvents.
- For stubborn dirt, use mild soap and water, then rinse thoroughly.

Storage

- Store the speaker in a cool, dry place when not in use for extended periods.
- Avoid storing in direct sunlight or extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not turn on.	Battery is depleted.	Charge the speaker using the provided USB-C cable.
Cannot pair with Bluetooth device.	Speaker not in pairing mode; device Bluetooth off; too far from speaker.	Press the Bluetooth button on the speaker; ensure Bluetooth is enabled on your device; move device closer to speaker (within 10 meters).
No sound or low volume.	Volume too low on speaker or device; speaker not connected.	Increase volume on both speaker and device; ensure speaker is successfully paired.
Sound distortion.	Volume too high; poor Bluetooth connection.	Decrease volume; move device closer to speaker to improve signal.

SPECIFICATIONS



Figure 6: Physical dimensions of the JBL Clip 4 speaker.

Feature	Detail
Model Name	Clip 4
Speaker Type	Portable Wireless Speaker
Connectivity Technology	Bluetooth
Wireless Communication Technology	Bluetooth
Bluetooth Version	Not specified
Water Resistance Level	IP67 (Waterproof and Dustproof)
Battery Life	10 Hours
Charging Time	10 Hours
Power Output	5 Watts
Frequency Response	Minimum 100 Hz
Dimensions (H x W x D)	5.3" x 3.4" x 1.8" (13.46 cm x 8.64 cm x 4.57 cm)
Item Weight	0.84 Pounds (13.4 ounces / 380 grams)
Battery Capacity	1000 Milliamp Hours

WARRANTY AND SUPPORT

This product is covered by a limited warranty. For detailed warranty terms and conditions, please refer to the warranty card included in your package or visit the official JBL website.

For technical support, troubleshooting assistance, or service inquiries, please contact JBL customer support through their official website or the contact information provided in your product documentation.

- **JBL Official Website:** www.jbl.com
- **Customer Support:** Refer to your product's safety sheet or quick start guide for regional contact details.