

[Manuals.plus](#) /

› [Mebus](#) /

› MEBUS Model 26369 Mechanical Wind-Up Bell Alarm Clock User Manual

Mebus 26369

MEBUS Model 26369 Mechanical Wind-Up Bell Alarm Clock User Manual

Your guide to setting up, operating, and maintaining your MEBUS alarm clock.

1. INTRODUCTION

Thank you for choosing the MEBUS Model 26369 Mechanical Wind-Up Bell Alarm Clock. This classic, battery-free alarm clock is designed for reliable timekeeping and a loud alarm to ensure you wake up on time. This manual provides detailed instructions for its proper use and care.

2. PRODUCT OVERVIEW

The MEBUS Model 26369 is a mechanical alarm clock featuring a traditional design with a double bell for an extra loud alarm. It operates without batteries, relying on a manual wind-up mechanism. The clock includes luminous hands for visibility in the dark.



Figure 2.1: The MEBUS Mechanical Wind-Up Bell Alarm Clock in a bedroom setting.



Figure 2.2: Detailed view of the clock face, highlighting the mechanical movement, loud bell, classic ticking sound, and luminous hands.

3. SETUP

3.1 Unpacking

Carefully remove the alarm clock from its packaging. Inspect for any signs of damage. Retain packaging for future transport or storage.

3.2 Initial Winding

Before first use, the clock must be fully wound. Locate the two winding keys on the back of the clock. Turn the key labeled "TIME" clockwise until you feel resistance. This winds the clock mechanism. Turn the key labeled "ALARM" clockwise until you feel resistance. This winds the alarm mechanism.

Stilvolle Vintage Optik mit Mechanischem Uhrwerk



Mit klassischem
Tick-Geräusch



Extra Laut mit
Glocken-Läutwerk



Mechanisches
Uhrwerk



Fluoreszierende
Zeiger leuchten
im Dunkeln

Figure 3.1: Rear view of the alarm clock, indicating the winding keys and setting knobs.

3.3 Setting the Time

To set the current time, turn the knob labeled "TIME SET" (usually located in the center of the winding keys) in either direction until the hour and minute hands indicate the correct time. It is recommended to set the time by moving the minute hand clockwise.

3.4 Setting the Alarm

To set the alarm time, turn the knob labeled "ALARM SET" (often smaller and located near the alarm winding key) until the small alarm hand points to your desired wake-up time. Ensure the alarm is activated by pushing the alarm switch (usually a small button or lever on the side or back) to the "ON" position.

4. OPERATING INSTRUCTIONS

4.1 Daily Winding

For continuous operation and accurate timekeeping, the MEBUS mechanical alarm clock requires daily winding. Wind both the

"TIME" and "ALARM" keys fully each day, preferably at the same time, to ensure consistent performance. If not wound, the clock will stop after approximately 24 to 48 hours.

Kompaktes Maß – perfekt für unterwegs und zuhause




Figure 4.1: The clock features an authentic mechanical movement requiring daily winding and operates without batteries.

4.2 Alarm Activation and Deactivation

To activate the alarm, ensure the alarm switch (typically a small lever or button on the back or side) is in the "ON" position. To silence the alarm once it rings, push the alarm switch to the "OFF" position. The alarm will sound at the set time for a duration determined by the remaining spring tension.

4.3 Luminous Hands

The hour and minute hands, along with the hour markers, are treated with a luminous material. After exposure to light, they will glow in the dark, allowing you to read the time during the night without needing external illumination.



Der Wecker für Nostalgi-Liebhaber



Authentisches, mechanisches Uhrwerk –
erfordert tägliches Aufziehen



Benötigt keine Batterien –
funktioniert an jedem Ort

Figure 4.2: Key features include a classic ticking sound, luminous hands for night visibility, and battery-free operation requiring daily winding.

5. MAINTENANCE

5.1 Cleaning

To clean the clock, gently wipe the exterior with a soft, dry cloth. Avoid using abrasive cleaners, solvents, or chemical sprays, as these can damage the finish and internal components. Do not immerse the clock in water.

5.2 Storage

When not in use for extended periods, store the alarm clock in a dry, dust-free environment. Ensure it is not fully wound to relieve tension on the springs.

6. TROUBLESHOOTING

- **Clock is not running:** Ensure both the "TIME" and "ALARM" winding keys are fully wound. Mechanical clocks require daily winding to operate continuously.
- **Alarm is not sounding:** Check that the "ALARM" winding key is fully wound. Verify that the alarm set knob is correctly positioned for your desired wake-up time and that the alarm activation switch is in the "ON" position.
- **Time is inaccurate:** Mechanical clocks can exhibit slight variations in timekeeping. Ensure the clock is wound daily at approximately the same time. If significant inaccuracy persists, it may indicate a need for professional adjustment.
- **Luminous hands are not glowing:** The luminous material requires exposure to light to charge. Ensure the clock is exposed to ambient light during the day for optimal glow at night.

7. SPECIFICATIONS

Model Number	26369
Brand	Mebus
Dimensions (L x W x H)	5 x 10 x 13.5 cm (approx. 1.97 x 3.94 x 5.31 inches)
Weight	264 grams (approx. 0.58 lbs)
Material	Metal
Color	Silver
Display Type	Analog
Movement Type	Mechanical (Manual Wind-Up)
Power Source	Manual Wind-Up
Special Features	Loud Bell Alarm, Luminous Hands, Battery-Free Operation

Für den perfekten Start in den Tag



**Präzise Einstellung
der Weckzeit**



**Dezenter, schwarzer
Weckzeit-Zeiger**

**Praktische
Weckfunktionen**



Glocken-Läutkwerk

Figure 7.1: Compact dimensions of the alarm clock, suitable for various placements.

8. WARRANTY AND SUPPORT

8.1 Warranty Information

This MEBUS product is covered by a standard manufacturer's warranty against defects in materials and workmanship. The specific terms and duration of the warranty may vary by region and retailer. Please retain your proof of purchase for warranty claims.

8.2 Customer Support

For technical assistance, warranty service, or general inquiries, please contact your retailer or visit the official MEBUS website for support contact details. When contacting support, please have your product model number (26369) and purchase information ready.

You can also visit the [MEBUS store on Amazon](#) for more products and information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08WYRNVQG>

More documents and user manuals: <https://manuals.plus/>