

BoxWave SHS-D600

BoxWave ClearTouch Crystal Screen Protector User Manual

Model: Samsung SHS-D600 Compatible

Brand: BoxWave

INTRODUCTION

The BoxWave ClearTouch Crystal Screen Protector is engineered to provide superior protection for your Samsung SHS-D600 device's display. This high-quality film is designed to shield your screen from scratches, dust, and daily wear, ensuring its longevity and maintaining optimal visual clarity. With its crystal-clear transparency, it preserves the vibrant colors and sharpness of your device's screen without compromising touch sensitivity.

This manual provides detailed instructions for the proper installation, care, and maintenance of your ClearTouch Crystal Screen Protector.

PACKAGE CONTENTS

Each BoxWave ClearTouch Crystal Screen Protector package typically includes the following items:

- Two (2) ClearTouch Crystal Screen Protectors
- One (1) ClearTouch Applicator Card
- One (1) Microfiber Cleaning Cloth
- One (1) Dust Removing Sticker

***ClearTouch** screen protector included accessories*



***Applicator
Card***



***Microfiber
Cleaning Cloth***



***Dust Removing
Sticker***

Image: Contents of the ClearTouch Crystal Screen Protector package, showing two screen protectors, an applicator card, a microfiber cleaning cloth, and a dust removing sticker.

SETUP AND INSTALLATION

Follow these steps carefully for optimal installation of your ClearTouch Crystal Screen Protector. Ensure you are in a clean, dust-free environment.

1. 1. Prepare Your Device Screen

Thoroughly clean your device's screen using the provided microfiber cleaning cloth. Ensure all dust, fingerprints, and smudges are removed. For stubborn marks, a small amount of screen cleaner can be used, then wipe dry.



Image: A hand wiping a device screen with a microfiber cloth, illustrating the cleaning step.

2. 2. Remove Dust Particles

Use the dust removing sticker to pick up any remaining dust particles from the screen. Lightly dab the sticker across the entire screen surface. Do not touch the screen with your fingers after cleaning.



Image: A hand using a dust removing sticker to lift dust from a device screen.

3. 3. Peel Off Layer 1

Carefully peel back the protective film labeled "Layer 1" (or similar indicator) from one end of the screen protector. Avoid touching the adhesive side.



Image: A hand peeling off the first protective layer from the screen protector.

4. 4. Align and Apply

Align the exposed adhesive edge of the screen protector with one edge of your device's screen. Slowly lower the screen protector onto the screen, ensuring precise alignment with all cutouts and edges.



Image: A hand carefully aligning the screen protector onto the device screen.

5. 5. Smooth Out Bubbles

Using the provided applicator card, gently push out any air bubbles from the center towards the edges of the screen. Apply firm, even pressure. Small bubbles may dissipate over 24-48 hours.



Image: A hand using the applicator card to smooth out air bubbles from under the screen protector.

6. 6. Peel Off Layer 2

Once the screen protector is fully adhered and bubbles are minimized, carefully peel off the top protective film labeled "Layer 2" (or similar indicator).



Image: A hand peeling off the second protective layer from the newly applied screen protector.

7. 7. Final Check

Inspect the installed screen protector for any remaining bubbles or misalignments. The special low-tack adhesive may take up to 2 days to fully adhere around the edges, and any small air gaps should clear out during this time with regular use.



Image: A device with the screen protector fully installed, showing a clear and protected screen.

OPERATING (USAGE)

Once installed, the BoxWave ClearTouch Crystal Screen Protector operates seamlessly with your Samsung SHS-D600. It is designed to be virtually invisible, preserving the original touch sensitivity and display clarity of your device.

- **Touch Sensitivity:** The screen protector does not interfere with the touch responsiveness of your device.

- **Display Clarity:** Enjoy 99% visual transparency, ensuring vibrant colors and sharp images are maintained.
- **Protection:** The film acts as a protective barrier against scratches, scuffs, and minor impacts.

High Definition Clarity

Provides 99% visual transparency that preserves crystal clear optical clarity with vibrant colors



Image: A visual representation of the screen protector's high definition clarity, showing a clear view through the protector to a field of yellow flowers.

MAINTENANCE

To ensure the longevity and optimal performance of your BoxWave ClearTouch Crystal Screen Protector, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the screen protector regularly with the provided microfiber cleaning cloth to remove fingerprints and smudges. For deeper cleaning, dampen the cloth slightly with water or a mild, screen-safe cleaner.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, alcohol, or ammonia-based solutions, as these can damage the screen protector's coating.

- **Protection:** While the screen protector offers significant scratch resistance, avoid placing your device with sharp objects (keys, coins) in pockets or bags to prevent excessive damage.
- **Reusability:** ClearTouch screen protectors are designed for reusability. If you need to remove and reapply, ensure the adhesive side remains clean and free of dust.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Air Bubbles After Installation	Dust particles trapped underneath, or insufficient smoothing during application.	Use the applicator card to push bubbles towards the nearest edge. For small bubbles, allow 24-48 hours for them to dissipate naturally. If large bubbles persist due to dust, carefully lift the nearest corner of the protector, remove dust with the sticker, and reapply.
Edges Not Sticking	Dust or oil on the screen edges, or protector not fully pressed down.	Ensure the screen edges are perfectly clean before application. Press down firmly on the edges with the applicator card. The low-tack adhesive may take up to 2 days to fully bond.
Reduced Touch Sensitivity	Incorrect installation or a faulty protector (rare).	Re-check installation for any trapped air or debris. If issues persist, ensure your device's touch settings are optimized. If the problem continues, consider using the second protector provided.
Scratches on Protector	Normal wear and tear, or contact with sharp objects.	The screen protector is designed to absorb scratches to protect your device's screen. If scratches become too prominent, replace the protector with the spare one provided.

SPECIFICATIONS

Product Name	ClearTouch Crystal Screen Protector
Brand	BoxWave
Model Compatibility	Samsung SHS-D600
Material	Polyethylene Terephthalate (PET)
Transparency	99% Visual Transparency

Surface Description	Glossy
Package Quantity	2 Screen Protectors
Item Weight	0.7 ounces

WARRANTY AND SUPPORT

BoxWave products are designed for quality and durability. For any questions, concerns, or support regarding your ClearTouch Crystal Screen Protector, please contact BoxWave customer service. While specific warranty details are not provided in this manual, BoxWave is committed to customer satisfaction. Please refer to the official BoxWave website or your purchase documentation for the most current warranty information and support contact details.

Contact Information:

Website: www.boxwave.com

Customer Service: Refer to website for contact methods (email, phone, chat).