

MohMus Compatible with Bosch / Siemens G ALL

MohMus 10 Premium Microfiber Vacuum Cleaner Bags Instruction Manual

Model: Compatible with Bosch / Siemens G ALL Series

INTRODUCTION

This manual provides instructions for the proper installation and use of MohMus Premium Microfiber Vacuum Cleaner Bags. These bags are designed for optimal filtration and long-lasting suction power in compatible Bosch and Siemens vacuum cleaner models.

COMPATIBILITY

These vacuum cleaner bags are compatible with various Bosch and Siemens vacuum cleaner series, including but not limited to:

- Bosch Series: BGB2, BGB7, BGB8, BGL2, BGL3, BGL4, BGL7, BGL8, BGSL4, BGN2, BSA2, BSG6, BSGL2
- Bosch / Siemens G ALL Series
- Specific models: BBZ41FGALL(00), BGL8PRO4/08, BGL42455/01, BSG6B130/12, BGL3A313/01

Note: These bags are not compatible with Bosch Series BSG8... or BSN... models.

SETUP AND INSTALLATION

Follow these steps to install a new vacuum cleaner bag and universal filter:

1. **Open Vacuum Cleaner Compartment:** Refer to your vacuum cleaner's original manual for instructions on how to safely open the dust bag compartment. Ensure the vacuum cleaner is unplugged from the power outlet before proceeding.
2. **Remove Old Bag:** Carefully remove the full dust bag. The MohMus bags feature a dust closure flap to prevent dirt spills during removal.
3. **Install New Bag:** Insert the new MohMus microfiber vacuum bag into the compartment, ensuring it is securely

seated in the bag holder. Make sure the opening of the bag aligns correctly with the vacuum cleaner's intake port.

4. **Prepare Universal Filter:** The package includes a universal microfilter. This filter can be cut to size to fit your vacuum cleaner's filter compartment.
5. **Install Universal Filter:** Locate the filter compartment in your vacuum cleaner (often near the motor or exhaust). Cut the universal filter to match the dimensions of your existing filter or the filter compartment. Insert the cut filter.
6. **Close Compartment:** Close the vacuum cleaner's dust bag and filter compartments securely.




Image: Dust Closure Flap. This image illustrates the dust closure flap mechanism on the vacuum bag, designed to prevent dust from escaping when the bag is removed or handled. The flap ensures a cleaner and more hygienic disposal process.




UNIVERSAL FILTER
ZUM ZUSCHNEIDEN

UNIVERSAL FILTER
CUT TO SIZE

Image: Universal Filter. This image shows the universal microfilter provided, which can be cut to the specific dimensions required for your vacuum cleaner's filter compartment. This ensures optimal air filtration.

OPERATING INSTRUCTIONS

Once the new bag and filter are installed, your vacuum cleaner is ready for use. The multi-layer microfiber material of these bags ensures high filtration and maintains strong suction power throughout the bag's lifespan.




OPTIMALE FILTRATION - OHNE SAUGKRAFTVERLUST

HIGH FILTRATION - FOR
LONG-LASTING SUCTION POWER



MEHRLAGIGES UND HOCHWERTIGES MICROVLIES

HIGH QUALITY AND
MULTI-LAYER MICROFIBER



STARKES UND REISSFESTES MICROVLIES-MATERIAL

STRONG AND TEAR RESISTANCE
MICROFIBER MATERIAL



MIT UNIVERSAL FILTER - ZUM ZUSCHNEIDEN

WITH UNIVERSAL AIR FILTER
- CUT TO SIZE

Image: Filtration and Material Features. This diagram highlights the key features of the MohMus vacuum bags, including optimal filtration for long-lasting suction power, high-quality multi-layer microfiber material, and strong tear resistance. It also shows the inclusion of a universal air filter.

MAINTENANCE

Regular maintenance ensures optimal performance of your vacuum cleaner and the longevity of the bags.

- **Bag Replacement:** Replace the vacuum bag when it is approximately two-thirds full, or when you notice a decrease in suction power. Overfilling the bag can reduce efficiency and potentially damage your vacuum cleaner.
- **Filter Replacement:** The universal microfilter should be checked regularly and replaced every 3-6 months, or more frequently if you vacuum frequently or have pets.

- **Disposal:** Dispose of used vacuum bags and filters according to local waste disposal regulations.

TROUBLESHOOTING

If you encounter issues, consider the following:

- **Reduced Suction Power:**
 - Check if the vacuum bag is full and replace it if necessary.
 - Inspect the universal filter for excessive dirt and replace it if clogged.
 - Ensure all vacuum cleaner compartments are securely closed.
 - Check for blockages in the hose or attachments.
- **Dust Leakage:**
 - Ensure the vacuum bag is correctly installed and fully seated in the holder.
 - Verify that the dust closure flap is functioning properly.
 - Check if the filter is correctly installed and not damaged.

SPECIFICATIONS

Brand	MohMus
Material	Multi-layer Microfiber
Quantity	10 Vacuum Cleaner Bags + 1 Universal Microfilter
Compatibility	Bosch / Siemens G ALL Series and specified Bosch models
Filtration	High fine dust filtration

WARRANTY INFORMATION

For warranty details regarding MohMus products, please refer to the manufacturer's official website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

SUPPORT

If you require further assistance or have questions not covered in this manual, please contact MohMus customer service through their official channels. Provide your product details and a clear description of your inquiry for efficient support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question