

[Manuals.plus](#) /

› [L.O.L. Surprise!](#) /

› L.O.L. Surprise! World Travel™ Dolls Instruction Manual - Model 576006

L.O.L. Surprise! 576006

L.O.L. Surprise! World Travel™ Dolls Instruction Manual

Model: 576006

INTRODUCTION

Welcome to the world of L.O.L. Surprise! World Travel™ Dolls. Each doll is ready to explore the globe, bringing new trends and making new friends. This manual provides essential information for setting up, operating, and maintaining your L.O.L. Surprise! World Travel™ Doll.

Each L.O.L. Surprise! World Travel™ doll comes with 8 surprises, including fashions and travel accessories. Discover your doll's unique passport, a secret message, a sticker sheet, and a water surprise feature. The ball packaging transforms into an L.O.L. Surprise! World globe with an included stand for display.

SETUP

1. Unboxing Your Doll:

Carefully unwrap the outer layers of the L.O.L. Surprise! World Travel™ ball. Each layer reveals a new surprise. The outer packaging is designed with travel-themed graphics, including passport stamps and an airplane zipper pull.



8 SURPRISES AND WATER SURPRISE

Image: The L.O.L. Surprise! World Travel doll ball showing the layers and icons representing the 8 surprises to be unboxed.

2. Assembling the Globe Stand:

Once all layers are removed, the inner ball can be separated into two halves. Attach the included stand to one half of the ball to create a globe display for your doll.



BALL IS LOL SURPRISE WORLD GLOBE WITH STAND!

Image: The L.O.L. Surprise! doll packaging transformed into a globe display stand with a doll on top.

3. Identifying Accessories:

Inside the ball, you will find individually wrapped accessories. These include a secret message, a passport, a bottle, a fashion outfit, an accessory, shoes, and a sticker sheet. Unpack each item carefully.

OPERATING

1. Dressing Your Doll:

Once all accessories are unboxed, dress your L.O.L. Surprise! doll in her travel-themed fashion and shoes. Add any additional accessories like headbands or jewelry.

2. Water Surprise Feature:

Each L.O.L. Surprise! World Travel™ doll has a unique water surprise. Feed or bathe your doll to discover if she

changes color in cold water or warm water, or if she cries, spits, or tinkles. Refer to the collector's guide for specific details about your doll's water surprise.

Your browser does not support the video tag.

Video: An L.O.L. Surprise! doll demonstrating its water surprise feature, changing appearance when submerged in water.

MAINTENANCE

- **Cleaning:**

To clean your doll and accessories, wipe them gently with a damp cloth. Avoid harsh chemicals or abrasive materials that could damage the finish or paint. For water surprise dolls, ensure they are thoroughly dried after water play to prevent mold or mildew.

- **Storage:**

Store dolls and accessories in a clean, dry place away from direct sunlight and extreme temperatures. The globe packaging can be used as a display stand or for storage.

- **Small Parts Warning:**

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.

TROUBLESHOOTING

- **Doll's Head Detaching:**

If the doll's head detaches, it can typically be reattached by gently pushing it back onto the neck joint. Avoid excessive force or rough handling to prevent this issue.

- **Water Surprise Not Working:**

Ensure the water temperature is appropriate for the doll's specific color change feature (cold or warm). Some dolls may require a few seconds of immersion to activate the change. If the feature still does not work, ensure the doll is clean and free from any residue.

SPECIFICATIONS

- **Product Dimensions:** 3.9 x 3.9 x 3.9 inches
- **Item Weight:** 3.87 ounces
- **Item Model Number:** 576006
- **Manufacturer Recommended Age:** 4 - 14 years
- **Release Date:** January 1, 2022
- **Manufacturer:** MGA Entertainment

COLLECT THEM ALL

There are 9 brand new L.O.L. Surprise! World Travel™ dolls to collect, each with unique travel vibes and styles. Expand your collection and explore the L.O.L. Surprise! World!



Image: A variety of L.O.L. Surprise! World Travel dolls from the collection.



COLLECT THEM ALL

Image: Close-up of three L.O.L. Surprise! World Travel dolls, highlighting their unique designs and size.

Your browser does not support the video tag.

Video: A short promotional video showcasing various L.O.L. Surprise! World Travel dolls and their accessories.

Your browser does not support the video tag.

Video: An L.O.L. Surprise! video featuring various dolls and playsets, including the World Travel series.

WARRANTY AND SUPPORT

For information regarding product warranty or customer support, please visit the official L.O.L. Surprise! website or contact MGA Entertainment customer service. Keep your purchase receipt as proof of purchase. Visit the [L.O.L. Surprise! Store](#) for more products and information.

© 2026 L.O.L. Surprise! All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question