

[Manuals.plus](#) /

› [GOOD MOTHER](#) /

› GOOD MOTHER GMA9 Automatic Egg Incubator User Manual

GOOD MOTHER GMA9

GOOD MOTHER GMA9 Automatic Egg Incubator User Manual

Model: GMA9

INTRODUCTION

Thank you for choosing the GOOD MOTHER GMA9 Automatic Egg Incubator. This manual provides essential information for the safe and efficient operation of your incubator. Please read these instructions carefully before use to ensure optimal hatching results and product longevity. This incubator is designed for hatching various poultry eggs, including chickens, ducks, fowl, and geese.



Image: The GOOD MOTHER GMA9 Automatic Egg Incubator, suitable for various types of eggs and poultry.

IMPORTANT SAFETY INSTRUCTIONS

- Always place the incubator on a stable, level surface away from direct sunlight, drafts, or extreme temperature fluctuations.
- Ensure the power supply matches the voltage requirements specified on the incubator (100-110V).
- Do not immerse the incubator or its electrical components in water or any other liquid.
- Keep the incubator out of reach of children and pets.
- Unplug the incubator from the power outlet before cleaning or performing any maintenance.
- Do not operate the incubator with a damaged cord or plug. If damaged, contact the manufacturer for repair.
- Avoid opening the incubator frequently during incubation, as this can disrupt temperature and humidity levels.

PRODUCT OVERVIEW AND COMPONENTS

Familiarize yourself with the main parts of your GMA9 incubator:



Image: Top view of the incubator's control panel, highlighting the power socket, venting hole, digital display, and control buttons.

- **Power Socket:** For connecting the power cord.
- **Venting Hole:** Allows for air circulation.
- **Digital Display:** Shows the current temperature (Fahrenheit or Celsius).
- **Set Button:** Used to enter temperature setting mode.
- **Settings Button:** Used to adjust temperature values.



Image: Exploded view illustrating the individual components of the incubator: the transparent top cover, the automatic egg turning mechanism, the egg grid, the water tray, and the main base.

- **Top Cover:** Transparent lid for observation.
- **Egg Turning Mechanism:** Automatically rotates eggs.
- **Egg Grid:** Holds eggs in place during incubation.
- **Water Tray:** For maintaining humidity levels.
- **Base:** The main housing of the incubator.

SETUP INSTRUCTIONS

1. **Unpack and Inspect:** Carefully remove all components from the packaging. Inspect for any damage.
2. **Assemble the Base:** Place the water tray into the base of the incubator.
3. **Install Egg Grid and Turning Mechanism:** Position the egg grid over the water tray. Then, place the automatic egg turning mechanism onto the grid, ensuring it is properly seated.
4. **Add Water:** Fill the water tray with approximately 100ml of clean, distilled water. This helps maintain humidity. Do not overfill.
5. **Connect Power:** Plug the power cord into the power socket on the incubator's top cover, then plug the other end into a suitable electrical outlet.
6. **Pre-heat:** Allow the incubator to run for at least 2-3 hours to stabilize the internal temperature before placing eggs inside. This also allows you to verify the temperature display.


OPERATING INSTRUCTIONS

1. **Temperature Setting:**
 - Press the "Set" button once. The digital display will flash.
 - Use the "Settings" button (often indicated by an arrow or plus/minus) to adjust the desired temperature. Refer to specific egg type requirements for optimal temperature.
 - Press "Set" again to confirm and exit the setting mode. The incubator will automatically adjust to the new temperature.
2. **Placing Eggs:** Once the incubator has reached and stabilized at the desired temperature, carefully place the fertilized eggs onto the egg turning mechanism. The incubator can hold 9-12 standard chicken eggs.
3. **Automatic Egg Turning:** The GMA9 incubator features an automatic egg turning function. This mechanism will periodically rotate the eggs to ensure even heating and prevent the embryo from sticking to the shell. This process is often subtle and may not be visibly obvious, but it is functioning.
4. **Humidity Management:** Check the water level in the tray every 1-2 days. Refill with approximately 100ml of clean, distilled water as needed to maintain appropriate humidity. Higher humidity is often required during the last few days of incubation (lockdown period).
5. **Monitoring:** Regularly monitor the temperature display. Avoid opening the incubator unnecessarily, especially during the final days of incubation.
6. **Hatching:** Once eggs begin to hatch, do not open the incubator until all chicks have hatched and are dry. This helps maintain critical humidity levels for the remaining eggs.

MAINTENANCE

1. **Cleaning:** After each incubation cycle, unplug the incubator and allow it to cool. Disassemble the egg turning mechanism, egg grid, and water tray. Wash these components with warm, soapy water and a mild disinfectant. Rinse thoroughly and allow to air dry completely.
2. **Wipe Down:** Wipe the interior and exterior surfaces of the incubator with a damp cloth and mild disinfectant. Ensure no moisture enters the electrical components.
3. **Storage:** Store the clean, dry incubator in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Incubator not powering on.	Power cord not properly connected; power outlet issue.	Check power cord connection. Test outlet with another appliance.
Temperature display is inaccurate or fluctuating.	External thermometer used; incubator not stabilized; environmental factors.	The incubator uses an industrial-grade temperature probe, which is highly accurate. Civilian temperature probes (e.g., standard room thermometers) may show a significant deviation. Rely on the incubator's built-in digital display.  Since the incubator uses industrial-grade temperature probes, and the general thermometers use civilian temperature probes, We recommend that you don't need to place the thermometer, as this will cause a large temperature deviation.  Image: Illustration demonstrating the difference between industrial-grade and civilian temperature probes, advising reliance on the incubator's internal sensor. Ensure the incubator is in a stable environment, free from drafts or direct heat sources. Allow sufficient pre-heating time for stabilization.
Automatic egg turner not working.	Mechanism jammed; motor issue; power interruption.	The egg turning mechanism operates subtly. It may not be visibly obvious when it moves, but it does turn and work. Observe over a longer period (e.g., a few hours) to confirm movement. If still no movement, unplug the unit, carefully inspect the mechanism for obstructions, and ensure it is correctly assembled. If the issue persists, contact customer support.
Humidity too low/high.	Insufficient/excessive water in tray; environmental humidity.	Adjust the amount of water in the water tray. Ensure the room humidity is not excessively high or low.

SPECIFICATIONS




Image: Technical drawing showing the dimensions of the GMA9 incubator.

Feature	Detail
Model Number	GMA9
Capacity	9-12 standard chicken eggs (varies by egg size)
Material	Durable PP+ABS
Voltage	100-110V
Frequency	50-60Hz
Power	<60W
Dimensions (L x W x H)	Approx. 36.7 x 26.9 x 17.81 cm (14.4 x 10.6 x 7 inches)
Weight	Approx. 2.15 kg (4.74 lbs)
Automatic Egg Turning	Yes
Temperature Control	Automatic, constant temperature incubation

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided at the time of purchase or contact your retailer. You may also reach out to the manufacturer, GOOD MOTHER, directly for assistance.

© 2023 GOOD MOTHER. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question