

[Manuals.plus](#) /

› [Olela](#) /

› Olela Twin Over Full Bunk Beds with Trundle Bed Instruction Manual

Olela bang-BlackR10007

Olela Twin Over Full Bunk Beds with Trundle Bed Instruction Manual

Model: bang-BlackR10007

INTRODUCTION

Thank you for choosing the Olela Twin Over Full Bunk Beds with Trundle Bed. This manual provides essential information for the safe assembly, operation, and maintenance of your new bunk bed. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image: Olela Twin Over Full Bunk Bed with Trundle, Black Frame, shown in a room setting.

SAFETY INFORMATION

WARNING: Failure to follow these warnings and instructions could result in serious injury or death.

- Always assemble according to the provided instructions to prevent instability.
- Keep the area around the bed clear to prevent falls, especially for young children.
- Be cautious of sharp edges during assembly and use.
- Do not exceed the maximum weight capacity of 250 lbs for the upper bed, 350 lbs for the bottom bed, and 250 lbs for the trundle bed.
- Only mattresses meeting the specified dimensions should be used.
- Ensure all connections are tight before use and check periodically.

Weight Capacity




Image: Visual representation of weight capacities: 250 lbs for the top bunk, 350 lbs for the bottom bunk, and 250 lbs for the trundle bed.



Image: Detail of the full-length guardrails on the top bunk and one of the built-in ladders, highlighting safety features.

SPECIFICATIONS

Feature	Detail
Overall Product Dimensions	77"L x 55.9"W x 66.5"H
Top Twin Bed Dimensions	77"L x 40.94"W
Bottom Full Bed Dimensions	77"L x 55.9"W
Twin Size Trundle Bed Dimensions	70.87"L x 40.55"W
Recommended Mattress Thickness	6-8 inches (Mattresses not included)
Material	Heavy Duty Metal Frame, MDF
Color	Black Frame
Weight Capacity (Top Bunk)	250 lbs
Weight Capacity (Bottom Bunk)	350 lbs
Weight Capacity (Trundle)	250 lbs

7. **Final Check:** Once assembled, double-check all connections to ensure they are tight and secure.

Your browser does not support the video tag.

Video: An overview of the Olela Twin Over Full Metal Bunk Bed with Trundle, demonstrating its features and structure. Provided by OlelaStore.

Your browser does not support the video tag.

Video: A general presentation of the Olela Twin Over Full Bunk Beds, showcasing its design and functionality. Provided by OlelaStore.

OPERATING INSTRUCTIONS

This bunk bed system is designed for versatile sleeping arrangements for up to three individuals.

- **Using the Trundle Bed:** The trundle bed is located beneath the bottom full bed. To use, gently pull the trundle frame outwards from under the main bed. It is equipped with wheels for easy movement. To store, push the trundle back into its position under the main bed.
- **Accessing the Top Bunk:** Use the built-in ladders located on each side of the bunk bed to safely access the top twin bunk. Always use the ladders for entry and exit.
- **Mattress Placement:** Ensure mattresses are placed securely within the bed frames and do not exceed the recommended thickness of 6-8 inches for optimal safety and comfort, especially for the top bunk's guardrail height.



Image: The bunk bed with the trundle bed extended, illustrating its use as an additional sleeping space.

MAINTENANCE

Proper care will extend the life and appearance of your Olela bunk bed.

- **Cleaning:** Wipe the metal frame and MDF panels with a damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Regular Checks:** Periodically inspect all bolts and connections to ensure they remain tight. Re-tighten if necessary to maintain stability and safety.
- **Weight Limits:** Always adhere to the specified weight limits for each bed to prevent structural damage and ensure safety.
- **Moving the Bed:** When moving the bed, lift it rather than dragging to prevent damage to the frame or flooring.

TROUBLESHOOTING

If you encounter any issues with your bunk bed, refer to the following common solutions:

- **Squeaking Noises:** If the bed squeaks, check all bolts and connections. Tighten any loose hardware. Ensure the bed is on a level surface.
- **Instability/Wobbling:** Verify that all parts are correctly assembled according to the instructions and that all bolts are fully tightened. Ensure the bed is placed on a flat, stable floor.
- **Trundle Not Rolling Smoothly:** Check the trundle wheels for any obstructions or damage. Ensure the trundle frame is properly aligned.
- **Missing Parts:** If you find any parts missing during assembly, please contact customer support immediately with your model number and a description of the missing part.

WARRANTY AND SUPPORT

For any questions, concerns, or to report missing/damaged parts, please contact Olela customer support. Keep your purchase receipt and model number (bang-BlackR10007) handy for faster service.

While specific warranty details are not provided in this manual, most products come with a manufacturer's warranty against defects in materials and workmanship. Please refer to your purchase documentation or contact Olela customer service for detailed warranty information.

Contact Information: Please refer to the contact details provided at the point of purchase or on the official Olela website.

© 2024 Olela. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

