

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Ardes](#) /
- › [Ardes AR5T1000 Horacle HRC Tower Fan User Manual](#)

Ardes AR5T1000

User Manual for Ardes Tower Fan AR5T1000 Horacle HRC

Model: AR5T1000 Horacle HRC

1. PRODUCT OVERVIEW

The Ardes AR5T1000 Horacle HRC Tower Fan is a powerful and elegantly designed vertical fan engineered to provide efficient air circulation and cooling in your environment. Combining advanced technology with user-friendly functionality, this tall and slim fan is capable of moving large volumes of air, offering significant relief and serving as an effective alternative to air conditioning units. Its lightweight design ensures easy portability, allowing you to cool any room as needed.

Key features include an intuitive digital control panel with an LED display, a convenient timer function for up to 9 hours, and three intensity levels (minimal, medium, maximal). Additionally, it offers specialized natural breeze and night modes for enhanced comfort. The fan comes with a remote control for convenient operation from a distance.





Figure 1: Ardes AR5T1000 Horacle HRC Tower Fan, front view. This image shows the sleek white design of the tower fan with its black control panel at the top and the Ardes logo near the base.

2. SAFETY INSTRUCTIONS

Please read all safety instructions carefully before using the appliance. Failure to follow these instructions may

result in electric shock, fire, or serious injury.

- Ensure the power supply voltage matches the rating label on the fan.
- Do not immerse the fan, plug, or cord in water or other liquids.
- Unplug the fan from the outlet when not in use, before cleaning, or before moving.
- Keep fingers and other objects away from the fan blades and openings.
- Do not operate the fan with a damaged cord or plug.
- Place the fan on a stable, flat surface to prevent tipping.
- Do not use the fan outdoors or in wet conditions.
- This appliance is for household use only.

3. SETUP AND ASSEMBLY

The Ardes AR5T1000 tower fan requires minimal assembly, primarily involving the attachment of its base. Follow these steps for quick setup:

1. **Unpack the Fan:** Carefully remove all components from the packaging. Ensure all parts are present: the main fan body, the base (usually in two halves), and the remote control.
2. **Assemble the Base:**
 - a. Take the two halves of the base and align them. They are designed to fit together snugly.
 - b. Route the power cord through the designated channel in the base halves.
 - c. Secure the base halves together, typically using screws provided in the package. Use a screwdriver to tighten them firmly.
3. **Attach the Fan Body to the Base:**
 - a. Carefully place the main fan body onto the assembled base, ensuring the alignment pins or grooves match.
 - b. Secure the fan body to the base. This usually involves a large nut or screws that fasten from the underside of the base. Tighten securely to ensure stability.
4. **Position the Fan:** Place the assembled fan on a stable, flat surface, ensuring it is away from curtains or other objects that could obstruct airflow or oscillation.
5. **Connect to Power:** Plug the power cord into a standard 230V electrical outlet. The fan is now ready for operation.

**Disperde
aria fresca
a più livelli
di altezza**



Figure 2: Side view of the Ardes Tower Fan, illustrating its 101 cm height. This image highlights the slim profile and the overall dimensions of the fan, which is crucial for placement and understanding its reach.

4. OPERATING INSTRUCTIONS

The Ardes AR5T1000 tower fan can be operated using its digital control panel or the included remote control.

4.1. Control Panel and Display

The digital control panel is located at the top of the fan and features an intuitive interface with an LED display. The display shows the current settings and temperature.



**Pannello comandi
Touch**



**Modalità brezza
Naturale**



Figure 3: Ardes Tower Fan highlighting the touch control panel and the natural breeze mode feature. This image shows the top of the fan with its digital display and touch-sensitive buttons, indicating ease of use.

4.2. Basic Operation

- **Power On/Off:** Press the power button () on the control panel or remote control to turn the fan on or off.
- **Adjust Fan Speed:** Press the speed button (▲/▼) to cycle through the three intensity levels:
 - Minimal
 - Medium
 - Maximal
- **Oscillation:** Press the oscillation button () to activate or deactivate the automatic oscillation feature. This allows the fan to rotate from side to side, distributing air across a wider area.



Figure 4: Diagram illustrating the wide oscillation range of the Ardes Tower Fan. This graphic shows how the fan rotates to cover a broad area, enhancing air distribution in a room.

4.3. Special Modes

- **Natural Breeze Mode:** This mode simulates a natural outdoor breeze by varying the fan speed intermittently. Press the mode button to activate this feature.
- **Night Mode:** Designed for quiet operation during sleep, this mode reduces fan speed and dims the LED display. Press the mode button to activate this feature.



Figure 5: Ardes Tower Fan showcasing the Night Mode and the 9-hour Timer function. This image visually represents the convenience of setting the fan to operate quietly overnight or for a specific duration.

4.4. Timer Function

The integrated timer allows you to set the fan to operate for a specific duration, up to 9 hours. Press the timer button () repeatedly to select the desired operating time in hourly increments. The fan will automatically turn off once the set time has elapsed.

4.5. Remote Control

The fan comes with a convenient remote control that allows you to operate all functions from a distance. Ensure the remote control has working batteries (not included, typically AAA) and point it towards the fan's receiver.



Figure 6: Ardes Tower Fan shown with its accompanying remote control. This image emphasizes the convenience of operating the fan remotely, allowing users to adjust settings without needing to approach the unit.

5. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure optimal performance and extend the lifespan of your Ardes tower fan.

- **Before Cleaning:** Always unplug the fan from the power outlet before attempting any cleaning or maintenance.
- **Exterior Cleaning:** Wipe the exterior surfaces of the fan with a soft, damp cloth. Do not use abrasive cleaners, waxes, or solvents as they may damage the finish.
- **Dust Removal:** Use a vacuum cleaner with a brush attachment or compressed air to remove dust from the air intake and exhaust grilles. This helps maintain efficient airflow.
- **Storage:** If storing the fan for an extended period, unplug it, clean it thoroughly, and store it in a cool, dry place, preferably in its original packaging to protect it from dust and damage.

Do not attempt to disassemble the fan for internal cleaning. Refer to qualified service personnel for any internal maintenance.

6. TROUBLESHOOTING

If you encounter issues with your Ardes AR5T1000 tower fan, please refer to the following troubleshooting guide:

Problem	Possible Cause	Solution
Fan does not turn on.	Not plugged in. Power outlet not working. Power button not pressed.	Ensure the power cord is securely plugged into a working outlet. Test the outlet with another appliance. Press the power button on the fan or remote control.
Fan is noisy or rattling.	Fan not on a stable surface. Dust accumulation. Internal component issue.	Place the fan on a firm, level surface. Clean the air grilles to remove dust. If noise persists, contact customer support.
Remote control not working.	Batteries are dead or incorrectly inserted. Obstruction between remote and fan.	Replace batteries with new ones, ensuring correct polarity. Remove any obstructions and point the remote directly at the fan's receiver.
Oscillation not working.	Oscillation function not activated. Mechanical obstruction.	Press the oscillation button. Ensure no objects are blocking the fan's rotation.

7. SPECIFICATIONS

Feature	Detail
Brand	Ardes
Model Number	AR5T1000
Style	Horacle HRC
Color	White
Power Source	Corded Electric
Voltage	230 Volts
Wattage	45 Watts

Feature	Detail
Airflow	25.4 Cubic Meters per Minute
Product Dimensions (L x W x H)	30 cm x 30 cm x 101 cm
Item Weight	2 Kilograms
Special Features	Timer, Oscillating, Natural Breeze Mode, Night Mode
Included Components	Remote Control

8. WARRANTY AND SUPPORT

For information regarding warranty coverage and customer support, please refer to the documentation included with your purchase or visit the official Ardes website. Keep your proof of purchase for warranty claims.

If you require technical assistance or have questions not covered in this manual, please contact Ardes customer service.

Note: Specific warranty terms and support contact details may vary by region.

© 2024 Ardes. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.

Related Documents - AR5T1000

 <p>Ardes AR6520 Forno a Microonde</p>	<p>Ardes AR6520 Forno a Microonde: Manuale d'Uso e Sicurezza</p> <p>Manuale completo per il forno a microonde Ardes AR6520. Trova istruzioni dettagliate su sicurezza, installazione, funzionamento, pulizia e manutenzione per un uso domestico ottimale.</p>
 <p>Ardes AR5PL50 (C)CEILING FAN</p>	<p>Ardes AR5PL50 Ceiling Fan: User Manual and Installation Guide</p> <p>This document provides comprehensive instructions for the Ardes AR5PL50 ceiling fan, covering safe installation, operation, maintenance, disposal, and warranty information. It includes detailed safety warnings and usage guidelines.</p>

 <p>BEDIENUNGSANLEITUNG</p> <p>KONVEKTOR</p> <p><small>Questo manuale di uso è per l'utente finale e non deve essere distribuito separatamente. Questo manuale è parte integrante del prodotto.</small></p> <p>AR4C08T-AR4C08TT</p>	<p>Ardes Konvektor Heizung AR4C08T-AR4C08TT Bedienungsanleitung und Technische Informationen</p> <p>Umfassende Bedienungsanleitung, technische Spezifikationen, Sicherheitshinweise und Garantieinformationen für die Ardes Konvektor Heizungsmodelle AR4C08T und AR4C08TT.</p>
 <p>PER INFORMAZIONI E INFORMAZIONI EN/ INSTRUCTIONS FOR USE</p>  <p>ARFRYA05L - ARFRYA05LW</p> <p>Frittoriga 5L5 Air Fryer</p>	<p>Ardes Air Fryer ARFRYA05L - ARFRYA05LW User Manual</p> <p>Comprehensive instructions for the Ardes Air Fryer ARFRYA05L and ARFRYA05LW, covering safety, usage, programs, settings, cleaning, maintenance, and troubleshooting.</p>
 <p>DE MANUALE D'ISTRUZIONI</p> <p>Luftzirkulator AR5CIR02</p> 	<p>Ardes AR5CIR02 Air Circulator User Manual and Instructions</p> <p>Comprehensive user manual for the Ardes AR5CIR02 Air Circulator, covering safety instructions, operation, assembly, cleaning, maintenance, technical specifications, and warranty information.</p>
 <p>PER INFORMAZIONI E INFORMAZIONI EN/ INSTRUCTIONS FOR USE</p> <p>VENTILATORE AR5BL3</p> 	<p>Ardes AR5BL3 Ventilatore: Manuale di Istruzioni e Guida all'Uso</p> <p>Scopri come utilizzare al meglio il tuo ventilatore Ardes AR5BL3 con questo manuale completo. Include istruzioni di sicurezza, funzionamento, manutenzione e garanzia per un uso efficiente e sicuro.</p>