

[Manuals.plus](#) /

› [ZEBRONICS](#) /

› ZEBRONICS Zeb BT6591RUCF 5.1 Speaker System User Manual

ZEBRONICS Zeb BT6591RUCF

ZEBRONICS Zeb BT6591RUCF 5.1 Speaker System User Manual

Model: Zeb BT6591RUCF | Brand: ZEBRONICS

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your ZEBRONICS Zeb BT6591RUCF 5.1 Speaker System. Please read this manual thoroughly before using the product to ensure proper functionality and to maximize your audio experience. Keep this manual for future reference.

PACKAGE CONTENTS

Upon unpacking, please verify that all the following items are included in your package:

- Subwoofer: 1 unit
- Satellite Speakers: 5 units
- Remote Control: 1 unit
- Input Cable: 1 unit
- Antenna Cable: 1 unit
- Wall Mount Clamps: 5 units
- Screws: 10 units
- Stereo to RCA Adapter: 1 unit
- User Manual: 1 unit (this document)



Image: The complete ZEBRONICS Zeb BT6591RUCF 5.1 speaker system, including the central subwoofer unit, five satellite speakers, and the remote control.

PRODUCT OVERVIEW

The ZEBRONICS Zeb BT6591RUCF is a 5.1 channel speaker system designed to deliver immersive surround sound. It consists of a powerful subwoofer and five satellite speakers, offering multiple connectivity options.

Main Unit (Subwoofer)

The subwoofer houses the main controls, display, and connectivity ports. It provides deep bass for a rich audio experience.



Image: A rear-angled view of the ZEBRONICS 5.1 speaker system, highlighting the subwoofer and the five satellite speakers.

Satellite Speakers

Five compact satellite speakers provide clear mid-range and high-frequency audio, completing the surround sound field. These can be wall-mounted for optimal placement.

Remote Control

A full-function remote control allows convenient adjustment of volume, input mode, track selection, and other settings from a distance.

SETUP

Speaker Placement

Proper placement of the subwoofer and satellite speakers is crucial for achieving the best 5.1 surround sound experience. Consider the following guidelines:

- **Subwoofer:** Place the subwoofer on the floor, preferably in a corner or near a wall, to enhance bass response.

- **Front Left & Right Satellites:** Position these speakers to the left and right of your viewing/listening area, facing towards you.
- **Center Satellite:** Place this speaker directly in front of you, typically above or below your display.
- **Rear Left & Right Satellites:** Position these speakers behind your listening position, to the left and right, to create the surround effect.



Image: A diagram showing the recommended 5.1 speaker setup, with the subwoofer and five satellite speakers strategically placed around a listening area for optimal surround sound.



Image: A lifestyle photograph depicting the ZEBRONICS 5.1 speaker system set up in a modern living room, demonstrating practical placement.

Connections

1. **Connect Satellite Speakers:** Connect the five satellite speakers to the corresponding output ports on the rear panel of the subwoofer. Ensure correct polarity (positive to positive, negative to negative).
2. **Connect Audio Source:**
 - **AUX Input:** Use the provided input cable to connect your audio source (e.g., smartphone, TV, PC) to the AUX input port on the subwoofer.
 - **AC-3 Input:** For 5.1 channel audio from compatible devices (e.g., DVD player, set-top box), connect to the AC-3 input ports.
3. **FM Antenna:** Connect the antenna cable to the FM antenna port on the subwoofer for improved radio reception.
4. **Power Connection:** Plug the power cord into the subwoofer and then into a standard AC power outlet.

OPERATING INSTRUCTIONS

Power On/Off

Press the Power button on the front panel of the subwoofer or on the remote control to turn the system on or off.

Selecting Input Mode

Press the "MODE" button on the subwoofer or remote control to cycle through the available input modes:

- **Bluetooth (BT):** For wireless audio streaming from Bluetooth-enabled devices.
- **USB:** For playing audio files from a USB flash drive.
- **SD:** For playing audio files from an SD card.
- **AUX:** For wired connection to audio sources via a 3.5mm or RCA cable.
- **AC-3:** For 5.1 channel audio input from compatible devices.
- **FM Radio:** For listening to FM radio stations.



Image: A graphic displaying icons for the various connectivity features of the speaker system, including Bluetooth, USB, SD card, FM radio, AUX input, AC-3 input, subwoofer size, and wall-mountable design.

Bluetooth Pairing

1. Switch the speaker system to Bluetooth mode. The display will show "BT" and indicate pairing mode.
2. Enable Bluetooth on your mobile device or computer.
3. Search for "ZEB-BT6591RUCF" in the list of available devices and select it to pair.
4. Once paired, the speaker will confirm the connection, and you can start playing audio wirelessly.

USB/SD Playback

Insert a USB flash drive or SD card (with MP3/WMA audio files) into the respective slot on the subwoofer. The system will automatically switch to USB/SD mode and begin playback. Use the remote control or front panel buttons to control playback (play/pause, next/previous track).

FM Radio Operation

1. Switch to FM mode.
2. Press the "SCAN" button on the remote or front panel to automatically scan and save available FM stations.
3. Use the "PREV/NEXT" buttons to navigate through saved stations.

Volume and Tone Control

Adjust the master volume using the rotary knob on the subwoofer or the VOL+/- buttons on the remote control. Bass and treble levels can also be adjusted via the remote control for personalized sound.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker surfaces. Do not use liquid cleaners or abrasive materials.
- **Placement:** Avoid placing the speakers in direct sunlight, near heat sources, or in areas with high humidity.
- **Ventilation:** Ensure adequate ventilation around the subwoofer to prevent overheating. Do not block ventilation openings.
- **Power:** Disconnect the power cord from the wall outlet during lightning storms or when the unit is left unused for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cord not connected; Power outlet not working; Power switch off.	Ensure power cord is securely connected. Check power outlet with another device. Turn on the power switch.
No sound	Volume too low; Incorrect input mode selected; Audio cables not connected properly; Mute function active.	Increase volume. Select the correct input mode. Check all audio cable connections. Deactivate mute.
Bluetooth not connecting	Speaker not in pairing mode; Device Bluetooth off; Device too far.	Ensure speaker is in BT pairing mode. Turn on Bluetooth on your device. Move device closer to the speaker.

Problem	Possible Cause	Solution
USB/SD playback issues	Unsupported file format; Corrupted files; USB/SD card not inserted correctly.	Ensure files are in supported formats (MP3/WMA). Try another USB/SD card. Reinsert the card/drive.
Poor FM reception	Antenna not connected; Weak signal.	Connect the FM antenna. Adjust antenna position for better reception.

SPECIFICATIONS

Feature	Detail
Speaker Type	Surround Sound (5.1 Channel)
Subwoofer Diameter	10.16 cm (4 Inches)
Connectivity Technology	Bluetooth, USB, SD, AUX, AC-3, FM Radio
Wireless Communication	Bluetooth
Compatible Devices	Smartphone, Tablet, PC, TV, DVD Player
Control Method	Remote Control, On-unit buttons
Mounting Type	Wall Mount (for satellites)
Power Source	AC
Item Weight	5.1 kg
Package Dimensions	34.1 x 30.9 x 28 cm

WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. For detailed information regarding warranty terms and conditions, please refer to the warranty card included in your package or visit the official ZEBRONICS website. For technical support, service, or any inquiries, please contact ZEBRONICS customer service. You can find more information and support on the [ZEBRONICS Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08X6JFYDS>

More documents and user manuals: <https://manuals.plus/>