

FDW TY-D7432-Gray

FDW Patio Lounge Chair Instruction Manual

Model: TY-D7432-Gray

1. INTRODUCTION

Thank you for choosing the FDW Patio Lounge Chair. This manual provides essential information for the safe and effective use, setup, operation, and maintenance of your new lounge chairs. Please read these instructions carefully before use and retain them for future reference.

2. SAFETY INFORMATION

Your safety is paramount. Please adhere to the following guidelines:

- For safe use, ensure the chair is only used by individuals within the recommended weight limit of **330 pounds**.
- Adjust the back and foot positions carefully, and do not exceed the specified number of reclining positions.
- Always check the chair's stability before use, and avoid using it on uneven surfaces.
- Folding chairs should be fully opened and locked into position before sitting to prevent accidental folding.
- Do not leave chairs folded when not in use in a manner that could cause them to accidentally unfold or tip.
- Keep children and pets away from moving parts during adjustment or folding.

3. SETUP

The FDW Patio Lounge Chairs are designed for convenience and require no assembly. They arrive fully assembled and folded.

Initial Unfolding:

1. Carefully remove the lounge chair from its packaging.

2. Gently unfold the chair, ensuring all legs and support frames extend fully.
3. Confirm that all locking mechanisms (if present) are engaged to secure the chair in its open position before use.



Figure 3.1: The FDW Patio Lounge Chair requires no assembly and is ready to use out of the box.



Figure 3.2: Two FDW Patio Lounge Chairs displayed in their fully extended, ready-to-use state.

4. OPERATING THE LOUNGE CHAIR


Your FDW Patio Lounge Chair features adjustable backrest and footrest positions for personalized comfort.

Adjusting the Backrest:


The backrest can be adjusted to **5 different positions**. To adjust, slightly lift the backrest, select your desired angle, and ensure it locks securely into place before leaning back.

Adjusting the Footrest:

The footrest offers **2 different positions**. To adjust, lift the footrest section and position it to your preferred height, ensuring it clicks into place.



Moisture-resistant
and durable fabric



Stainless steel
anti-rust



LOUNGE CHAIR

Figure 4.1: Illustration of the five adjustable backrest positions for customized comfort.



Figure 4.2: The lounge chair offers 5 backrest and 2 leg positions for versatile reclining.

5. MAINTENANCE

Proper care will extend the life and appearance of your lounge chairs.

- **Cleaning:** The chair's fabric is ventilated and designed to be easy to clean. Simply wipe down the fabric and frame with a damp cloth. For stubborn dirt, a mild soap solution can be used, followed by rinsing with clean water.
- **After Rain:** The fabric may hold water after rain. It is recommended to wipe down the chairs to prevent water accumulation and speed up drying.
- **Storage:** When not in use for extended periods, especially during harsh weather, it is advisable to fold and store the chairs indoors to protect them from elements and prolong their lifespan.
- **Rust Prevention:** The frame is made of stainless steel for anti-rust properties. However, regular cleaning and ensuring the chairs are dry before storage can further prevent any potential corrosion.



Figure 5.1: Detail of the moisture-resistant fabric and stainless steel frame, highlighting durability and ease of maintenance.

6. STORAGE AND PORTABILITY

The FDW Patio Lounge Chair is designed to be foldable and lightweight, making it easy to store and transport.

Folding Instructions:

1. Ensure the backrest and footrest are in their most compact, folded positions.
2. Carefully collapse the chair's frame until it is fully folded.
3. Secure any straps or latches if available to keep the chair in its folded state.

Once folded, the chair is compact and can be easily moved from one location to another, such as from the pool to the backyard, or stored indoors during inclement weather or off-season.

Adjustable Lounge Chair

Can be easily moved 5 backrest positions
and 2 footrest positions



5 Backrest
Positions

2 Leg
Positions

Figure 6.1: The lounge chair's folding mechanism allows for compact storage and easy transport.




Figure 6.2: The folded chair fits conveniently into a car trunk, ideal for trips or picnics.

7. SPECIFICATIONS

Key technical details and dimensions of the FDW Patio Lounge Chair:

Feature	Detail
Brand	FDW
Model Name	TY-D7432-Gray
Product Dimensions (Unfolded)	73"D x 20.5"W x 18.5"H
Item Weight	41.3 pounds (per chair)
Maximum Weight Recommendation	330 Pounds
Reclining Position Count	3 (Backrest: 5, Footrest: 2)
Special Feature	Foldable
Indoor/Outdoor Usage	Outdoor
Frame Material	Stainless Steel
Fabric Material	Textilene (ventilated, moisture-resistant)
Color	Grey



DIMENSION

Figure 7.1: Detailed dimensions of the lounge chair, including length, width, height, and folded size.

8. TROUBLESHOOTING

This section addresses common concerns you might encounter with your lounge chairs.

- **Difficulty Unfolding/Folding:** If the chair is stiff or difficult to unfold/fold, ensure no parts are obstructed. Apply gentle, even pressure. Over time, the mechanism may become smoother with use. Avoid forcing the chair, which could cause damage.
- **Chair Instability:** Ensure the chair is placed on a flat, even surface. Verify that all legs are fully extended and all locking mechanisms are engaged after unfolding. Uneven ground can cause wobbling.
- **Rust Spots:** While the frame is stainless steel, prolonged exposure to moisture or certain chemicals can still lead to surface rust. Regularly clean and dry the chairs, especially after rain or pool use. Store indoors when not in use for extended periods.
- **Fabric Sagging/Damage:** Ensure the chair is not overloaded beyond its maximum weight capacity. Inspect the fabric periodically for any signs of wear or damage. Contact customer support for replacement parts if necessary.

9. WARRANTY AND SUPPORT

For warranty information, product support, or to inquire about replacement parts, please contact FDW customer service directly. Details regarding your product's warranty period and terms can typically be found on the product packaging or the manufacturer's official website.

When contacting support, please have your model number (TY-D7432-Gray) and purchase information readily available.

