

[Manuals.plus](#) /

› [BRESSER](#) /

› BRESSER ClimateScout Weather Station Additional Base (Model 7003100) Instruction Manual

BRESSER ClimateScout

BRESSER ClimateScout Weather Station Additional Base (Model 7003100) Instruction Manual

Your guide to setting up and operating your additional weather station base.

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your BRESSER ClimateScout Weather Station Additional Base, Model 7003100. This additional base unit is designed to expand the monitoring capabilities of your existing BRESSER 7-in-1 ClimateScout weather center, allowing you to view weather data in multiple locations within your home.

Please read this manual thoroughly before using the device to ensure correct operation and to maximize its lifespan.

2. PACKAGE CONTENTS

Verify that all items listed below are present in your package:

- Additional base station
- Instruction manual

Note: An external sensor is not included with this additional base station and is required for full weather data functionality. This base station is intended to be used with an existing BRESSER 7-in-1 ClimateScout weather center.

3. SETUP

3.1 Powering the Base Station

The additional base station is battery-powered. Insert the required batteries (not included) into the battery compartment located on the back of the unit. Ensure correct polarity (+/-) as indicated inside the compartment.

3.2 Placement

Place the additional base station in your desired location, such as a bedroom or bathroom, where you wish to monitor indoor conditions and receive data from your main weather station's external sensor. Ensure it is placed on a stable, flat surface.



Image 1: The BRESSER ClimateScout Additional Base Station positioned on a wooden side table in a room, demonstrating a typical placement scenario for monitoring indoor and outdoor weather conditions.



Image 2: The BRESSLER ClimateScout Additional Base Station, showcasing its display and silver finish. This image illustrates the device's appearance and size, suitable for placement on a desk or shelf.

3.3 Connecting to External Sensor

The additional base station will automatically attempt to connect to your existing BRESSLER 7-in-1 ClimateScout external sensor. Ensure your external sensor is powered on and within range. Refer to your main ClimateScout weather center manual for details on external sensor setup and pairing if you encounter connection issues.

4. OPERATING THE BASE STATION

4.1 Display Overview

The display provides comprehensive information at a glance. It shows both indoor measurements from its built-in sensor and outdoor data received from your external sensor.




Image 3: A detailed view of the BRESSER ClimateScout display, showing various weather parameters such as time, indoor/outdoor temperature, humidity, wind speed, wind direction, rain, UV index, and light intensity. The display also features a graphic indoor climate indicator.

4.2 Indoor Measurements

The built-in sensor provides:

- **Indoor Temperature:** Displayed in °C or °F.
- **Indoor Humidity:** Displayed as a percentage.
- **Air Pressure:** Current atmospheric pressure.
- **Indoor Climate Indicator:** A graphic representation (happy/sad smile, with or without drops) to quickly assess comfort levels and potential for mold or dry air.

4.3 Outdoor Measurements (from external sensor)

When connected to your 7-in-1 external sensor, the display will show:

- Outdoor Temperature
- Outdoor Humidity

- Wind Speed
- Wind Direction
- Rainfall
- UV Rays
- Light Intensity

4.4 Time and Date

The base station displays the current time and date, which is typically synchronized with the main weather station or an atomic clock signal if available through the main unit.

5. MAINTENANCE

- **Cleaning:** Wipe the display and casing with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** Replace batteries when the low battery indicator appears on the display. Always replace all batteries at the same time with new ones of the same type.
- **Storage:** If storing the device for an extended period, remove the batteries to prevent leakage.

6. TROUBLESHOOTING

- **No Display / Faint Display:**
 - Check battery installation and polarity.
 - Replace old batteries with new ones.
- **No Outdoor Data:**
 - Ensure the external sensor is powered on and its batteries are fresh.
 - Verify the external sensor is within range of the base station.
 - Check for obstructions between the sensor and the base station.
 - Re-establish connection between the base station and the external sensor (refer to your main weather station manual for pairing instructions).
- **Inaccurate Readings:**
 - Ensure the base station is not exposed to direct sunlight or heat sources, which can affect indoor temperature readings.
 - Ensure the external sensor is placed in an appropriate location, away from direct sun and rain, for accurate outdoor readings.

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	7.09 x 5.43 x 1.1 inches
Weight	11.64 ounces
Item Model Number	ClimateScout
Brand	BRESSER

Power Source	Battery Powered
Special Features	Alarm, Clock, Lightweight
Material	Metal
Color	Metallic Silver
Temperature Accuracy	1 °C

8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your main BRESSER ClimateScout Weather Station or visit the official BRESSER website. Keep your purchase receipt as proof of purchase for warranty claims.

For further assistance, you may contact BRESSER customer service through their official channels. Contact details are typically available on the manufacturer's website or in the main product manual.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08X7G32WP>

More documents and user manuals: <https://manuals.plus/>