

ZTO ztowoto-1

Ztowoto Double Shoulder Camera Strap Instruction Manual

Model: ztowoto-1

INTRODUCTION

Thank you for choosing the Ztowoto Double Shoulder Camera Strap. This manual provides essential information for the safe and effective use of your new camera strap. Please read these instructions carefully before setup and operation to ensure proper functionality and to maximize your photography experience.

PRODUCT FEATURES

- **Ergonomic Design:** Engineered for even weight distribution across both shoulders, reducing strain. An integrated waist pad enhances stability and minimizes camera swing during movement.
- **Comfortable Materials:** Constructed from neoprene for elastic pressure reduction and breathable sandwich mesh, ensuring comfort during extended use.
- **Dual Camera Capacity:** Capable of carrying two DSLR/SLR cameras simultaneously with a maximum load capacity of 50kg.
- **Versatile Components:** Includes two quick-release plates, two standard 1/4-inch screws, and two safety tethers. Quick-release plates are tripod-compatible.
- **Convertible Design:** The double shoulder strap can be separated into two individual single shoulder straps for flexible carrying options.
- **Durable Fasteners:** All plastic fasteners are made from high-quality, temperature-resistant material for long-lasting durability and safety.

SETUP INSTRUCTIONS

Follow these steps to properly assemble and adjust your Ztowoto Double Shoulder Camera Strap.

1. **Unpack Components:** Carefully remove all items from the packaging. You should have the main harness, two camera straps with quick-release plates, two 1/4-inch screws, and two safety tethers.

2. Attach Quick-Release Plates:



Image: Step-by-step guide for attaching the quick-release plate to your camera and then securing it to the strap.

Screw the 1/4-inch screw of the quick-release plate into the tripod socket at the bottom of your camera. Ensure it is tightened securely. The quick-release plate allows for rapid attachment and detachment of your camera from the strap.

3. Connect Safety Tethers:

ストラップを取り外さずにベースをすばやく調整し
三脚を接続してください。安全で、速く、便利です



小型でコンパクトなネジを選択することもできます
より便利で高速に使用する



Image: Detail of the safety tether attachment point on the camera and strap.

Attach one end of the safety tether to a secure point on your camera (e.g., a strap lug) and the other end to a D-ring or loop on the main shoulder strap. This provides a crucial secondary layer of protection against accidental drops.

4. **Wear the Harness:** Put on the double shoulder harness like a backpack. Adjust the shoulder straps and the waist strap for a snug and comfortable fit. The waist pad should rest comfortably on your lower back.



Image: Rear view of the double shoulder camera strap worn by a person, demonstrating proper fit.

5. **Attach Cameras:** Connect your cameras to the quick-release plates on the strap. Ensure the quick-release mechanism is fully engaged and locked.
6. **Adjust Strap Length:** Adjust the length of the camera straps so that your cameras hang at a comfortable and accessible position, typically at hip level. Ensure the cameras do not swing excessively.



肩の摩耗方法



左肩の着用方法



右肩の着用方法

Image: Various wearing configurations, including double and single shoulder options.

OPERATING INSTRUCTIONS

Once the strap is set up, using it is straightforward:

- **Quick Access:** To use a camera, simply slide it up the strap from your hip to your eye level. The smooth sliding mechanism allows for quick and effortless access.
- **Re-holstering:** After taking a shot, gently guide the camera back down to its resting position at your hip. The waist pad and strap design will help keep it stable.
- **Converting to Single Strap:** To convert the double strap into two single straps, unclip the central back buckle and detach the shoulder pads as needed. This provides flexibility for different shooting scenarios.



ダブルショルダーストラップをシングルショルダーストラップに変更する方法



プラスチック製のバックルを分解します

ベルクロを分解する

Image: Visual guide on converting the double strap to a single strap by releasing buckles and Velcro fasteners.

- **Tripod Use:** The quick-release plates allow you to mount your camera directly onto a tripod without removing the plate from the camera.

MAINTENANCE

Proper care will extend the life of your camera strap:

- **Cleaning:** Wipe the strap with a damp cloth and mild soap if it gets dirty. Do not use harsh chemicals or abrasive cleaners. Allow it to air dry completely.
- **Inspection:** Regularly inspect all buckles, straps, and quick-release mechanisms for signs of wear, damage, or loose connections.
- **Storage:** Store the strap in a cool, dry place away from direct sunlight when not in use.

TROUBLESHOOTING

If you encounter issues with your camera strap, consider the following:

- **Camera feels unstable:** Ensure all buckles are securely fastened and adjusted to your body. Verify that the quick-release plates are tightly screwed into your cameras and fully engaged with the strap's connectors. Always use the safety tethers.
- **Discomfort or shoulder pain:** Re-adjust the strap lengths and harness position to ensure even weight distribution. The waist pad should be properly positioned on your lower back.
- **Difficulty with quick-release mechanism:** Check for any debris or obstruction in the quick-release plate or receiver. Ensure the locking mechanism is functioning correctly.

SPECIFICATIONS

Feature	Detail
Brand	ZTO
Model Number	ztowoto-1 (Manufacturer Model: ztsj01)
Material	Neoprene, Sandwich Net
Product Type	2-point sling / Dual Camera Strap
Maximum Load Capacity	50 kg
Fastener Type	Buckle
UPC / GTIN	767065495515

WARRANTY AND SUPPORT

Ztowoto offers a 12-month warranty covering quality-related issues. This includes a full refund or free replacement for eligible defects.

If you encounter any problems during the use of your Ztowoto Double Shoulder Camera Strap, please do not hesitate to contact our customer service team. We are committed to providing a satisfactory solution to ensure your complete satisfaction.

For support, please visit our official website or contact us via the platform where you purchased the product.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question