

- [Manuals.plus](#) /
- › [VINGLI](#) /
 - › VINGLI 5 FT Brown Wooden Porch Swing Instruction Manual (Model VL-ClassicSwing)

VINGLI VL-ClassicSwing

VINGLI 5 FT Brown Wooden Porch Swing Instruction Manual

MODEL: VL-CLASSICSWING

Brand: VINGLI

1. INTRODUCTION AND PRODUCT OVERVIEW

This manual provides detailed instructions for the assembly, operation, and maintenance of your VINGLI 5 FT Brown Wooden Porch Swing, Model VL-ClassicSwing. Designed for outdoor use in courtyards and gardens, this heavy-duty swing chair bench offers a comfortable and durable seating solution. Please read all instructions carefully before assembly and use to ensure safe and proper operation.



Image 1.1: The VINGLI 5 FT Brown Wooden Porch Swing, showcasing its design and finish.

2. SAFETY INFORMATION

To prevent injury or damage to the product, always adhere to the following safety guidelines:

- **Weight Capacity:** Never exceed the maximum weight capacity of 880 pounds.
- **Assembly:** Ensure all bolts and fasteners are securely tightened before use. Periodically check for loose connections.
- **Installation:** Mount the swing to a sturdy, load-bearing structure capable of supporting the swing's weight plus the maximum user weight.
- **Supervision:** Children should be supervised while using the swing.
- **Clearance:** Ensure adequate clearance around the swing to prevent collisions with walls, furniture, or other objects.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact VINGLI customer support.

- Pre-assembled Seat Section
- Pre-assembled Backrest Section
- Armrests (2)
- Hanging Chains (2 sets)
- Hardware Pack (bolts, washers, nuts, Allen wrench)



Decent Improvements on Details

Adjustable Chains & Closed Ends
Provide more flexibility and security

Denser Wood Slats
Provide better sitting experience

Other

S-Shape Chain Ends
Have safety hazard when in use

Loose Wood Slats
Make users feel uncomfortable

Image 3.1: Illustration of the main components and hardware included for assembly.

4. ASSEMBLY INSTRUCTIONS

Assembly typically requires two persons and can be completed in approximately 20 minutes. Do not fully tighten bolts until all components are in place.

1. **Attach Armrests:** Secure the two armrests to the sides of the seat section using the provided bolts and nuts. Ensure the curved edges of the armrests are facing outwards for ergonomic comfort.
2. **Connect Backrest to Seat:** Align the backrest section with the rear of the seat section. Insert the bolts through the pre-drilled holes and secure with washers and nuts.
3. **Install Hanging Chains:** Attach the hanging chains to the designated eyelets on the armrests and the underside of the seat. The chains feature loop-locked connections for enhanced security.
4. **Final Tightening:** Once all components are loosely assembled, gradually tighten all bolts and nuts using the provided Allen wrench until secure. Avoid overtightening to prevent wood damage.
5. **Mount the Swing:** Carefully lift the assembled swing and attach the hanging chains to your pre-installed, sturdy overhead support. Adjust chain length to achieve desired swing height and angle.



High-Quality Cedarwood



Image 4.1: Close-up of the stainless chains and humanized design with curved edges, highlighting key assembly points.

Your browser does not support the video tag.

Video 4.2: An overview of the VINGLI Porch Swing, demonstrating its features and comfort. This video is provided by VINGLI-Direct.

5. OPERATING INSTRUCTIONS

Your VINGLI Porch Swing is designed for comfortable relaxation. The ergonomic design with curves in the knee area provides optimal sitting experience. The upgraded chains allow for angle adjustment to suit your preference. Enjoy your leisure time by gently swinging back and forth.



Image 5.1: Product dimensions and weight capacity of the VINGLI Porch Swing.

6. MAINTENANCE

To ensure the longevity and appearance of your porch swing, follow these maintenance tips:

- **Cleaning:** The well-coated surface is easy to clean. Wipe down with a damp cloth as needed to remove dirt and debris. Avoid harsh chemicals that may damage the finish.
- **Wood Care:** While the swing features a durable finish, periodic inspection for wear and tear is recommended. Reapply a protective sealant or stain if the finish appears dull or worn to maintain its weather resistance.
- **Hardware Check:** Regularly inspect all bolts, nuts, and chain connections for tightness. Tighten any loose hardware to ensure stability and safety.
- **Weather Protection:** Although designed for outdoor use, covering the swing during extreme weather conditions (heavy rain, snow, prolonged direct sunlight) can extend its lifespan.



Image 6.1: Demonstrating the easy-to-clean, well-coated surface of the swing.



Image 6.2: The swing's sun-resistant PU finish and waterproof cedarwood construction.

7. TROUBLESHOOTING

If you encounter any issues with your VINGLI Porch Swing, please refer to the following common solutions:

- **Creaking Noise:** If the swing creaks during use, check all bolted connections and tighten them. Apply a silicone-based lubricant to moving metal parts if necessary.
- **Unstable Swing:** Ensure the overhead mounting points are secure and the chains are evenly adjusted. Verify all assembly bolts are tight.
- **Wood Splitting/Cracking:** While rare with proper care, extreme weather can affect wood. Apply wood filler and re-seal if minor cracks appear. For significant damage, contact customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	VINGLI
Model Number	VL-ClassicSwing
Color	Brown
Product Dimensions	24.4"D x 60.6"W x 18.9"H
Frame Material	Wood (Cedar)
Seat Depth	15.4 inches
Item Weight	43.4 Pounds
Weight Capacity	880 LBS
Assembly Required	Yes
UPC	810158423428

9. WARRANTY AND SUPPORT

For warranty information, product support, or to order replacement parts, please visit the official VINGLI website or contact their customer service department. Keep your purchase receipt and model number (VL-ClassicSwing) handy for faster service.

Official VINGLI Store: [Visit VINGLI Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08XBGL8GM>

More documents and user manuals: <https://manuals.plus/>