

[manuals.plus](#) /› [MusiBaby](#) /› [MusiBaby M68 Bluetooth Speaker User Manual](#)

## MusiBaby M68

# MusiBaby M68 Bluetooth Speaker User Manual

Model: M68

### INTRODUCTION

Thank you for choosing the MusiBaby M68 Portable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. Please read this manual thoroughly before use.

### WHAT'S IN THE Box

- 1x Portable Bluetooth Speaker (MusiBaby M68)
- 1x Type-C Charging Cable
- 1x 3.5mm Audio Cable
- 1x M68 Quick Start Guide

### PRODUCT OVERVIEW

The MusiBaby M68 is a compact and powerful portable Bluetooth speaker designed for various indoor and outdoor activities. It features 360° stereo sound, booming bass, IPX5 water resistance, and dual pairing capabilities for an enhanced audio experience.





Figure 1: Front view of the MusiBaby M68 Bluetooth Speaker with control panel.

## Key Features

- **True 360° Stereo Sound & Booming Bass:** Delivers immersive audio with rich bass, mids, and highs.

- **Long Battery Life:** Up to 24 hours of playtime on a single charge.
- **Dual Pairing (TWS):** Connect two M68 speakers for a true surround sound experience.
- **IPX5 Waterproof:** Protected against water splashes and gentle spray, suitable for outdoor use.
- **Bluetooth 5.3:** Provides a stable connection with a wireless range of up to 100ft.
- **Multiple Connectivity Options:** Supports Bluetooth, 3.5mm audio jack, TF card slot, and USB.



Figure 2: Illustration of the speaker's 360-degree sound output.



Figure 3: Internal components highlighting the speaker and bass sound chamber.



Figure 4: Visual representation of two speakers connecting for dual pairing.

## 1500 Minutes Playtime



Figure 5: The speaker's IPX5 water resistance in action.

## SETUP

### 1. Charging the Speaker

Before first use, fully charge the speaker. Connect the provided Type-C charging cable to the speaker's charging port and a USB power adapter (not included). The charging indicator light will illuminate during charging and turn off when fully charged. A full charge takes approximately 2.5 hours.

### 2. Power On/Off

- To Power On:** Press and hold the Power button (■) for 2-3 seconds until you hear an audible prompt.
- To Power Off:** Press and hold the Power button for 2-3 seconds until you hear an audible prompt.

### 3. Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a blinking blue LED).
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.

3. Select "MusiBaby M68" from the list of devices.
4. Once connected, you will hear a confirmation tone, and the LED indicator will turn solid blue.

#### 4. Dual Pairing (True Wireless Stereo - TWS)

For an enhanced stereo experience, you can pair two MusiBaby M68 speakers together:

1. Ensure both M68 speakers are powered on and not connected to any other Bluetooth device.
2. On one of the speakers, double-press the Volume Down button ( ). You will hear a prompt indicating TWS pairing mode.
3. The two speakers will automatically connect to each other. Once connected, you will hear a confirmation tone.
4. Now, connect your device to one of the paired speakers via Bluetooth as described in the "Bluetooth Pairing" section. Both speakers will play audio in stereo.

### OPERATING INSTRUCTIONS

#### Basic Controls



# True 360° Sound

Figure 6: Control layout and port locations.

- **Power ON/OFF / Play/Pause / Pairing:** The top button on the control panel.
- **Volume Down / Previous Track:** The middle button. Press once for volume down, long press for previous track.
- **Volume Up / Next Track:** The bottom button. Press once for volume up, long press for next track.

## Connectivity Options

- **Bluetooth 5.3:** For wireless audio streaming from compatible devices.
- **3.5mm Audio Jack (AUX):** Connect non-Bluetooth devices using the provided 3.5mm audio cable.
- **TF Card Slot:** Insert a TF (Micro SD) card with MP3 audio files for direct playback.
- **USB Port:** For connecting USB drives with audio files or for charging other devices (power bank function).

## MAINTENANCE

### Water Resistance (IPX5)

The MusiBaby M68 speaker is IPX5 rated, meaning it is protected against water splashes and gentle spray from any direction. It is suitable for use in environments like parties, by the pool, on the beach, or during camping/hiking. **Caution: Do not submerge the speaker directly into water.**

### Cleaning

Wipe the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.

### Battery Care

To prolong battery life, avoid fully discharging the speaker frequently. Charge the speaker regularly, even if not in use for extended periods. Store in a cool, dry place.

## TROUBLESHOOTING

- **No Power:** Ensure the speaker is charged. Connect to a power source using the Type-C cable.
- **Cannot Pair via Bluetooth:** Make sure the speaker is in pairing mode (blinking blue LED). Turn off Bluetooth on your device and turn it back on. If using TWS, ensure both speakers are unpaired from other devices before initiating TWS pairing.
- **No Sound:** Check the volume levels on both the speaker and your connected device. Ensure the speaker is correctly paired. If using AUX, ensure the cable is fully inserted.
- **Poor Sound Quality:** Ensure the speaker is within the Bluetooth range (up to 100ft) of your device. Avoid obstacles that may interfere with the signal.
- **TWS Pairing Failure:** Ensure both speakers are M68 models and are not connected to any other device before attempting TWS pairing.

## SPECIFICATIONS

Feature	Specification
Model Name	M68
Brand	MusiBaby
Connectivity Technology	Bluetooth, Wireless
Bluetooth Version	5.3
Wireless Range	Up to 100 Feet
Speaker Type	Portable Speaker
Audio Output Mode	Stereo
Speaker Maximum Output Power	8 Watts
Signal-to-Noise Ratio	85 dB
Frequency Response	20 KHz
Power Source	Battery Powered
Battery Type	1 Lithium Polymer (included)
Battery Capacity	2400 mAh
Charging Time	2.5 Hours
Playtime	Up to 24 Hours
Water Resistance Level	IPX5 (Waterproof)
Product Dimensions	2.91"D x 2.91"W x 4.84"H
Item Weight	350 Grams (12.3 ounces)
Material	Plastic

## WARRANTY AND SUPPORT

All MusiBaby Bluetooth speakers come with a 12-month hassle-free warranty. For any questions or support needs, please contact our customer service. We offer 24-hour online service to assist you.


You can also use the Amazon shopping app to scan the Transparency barcode on the product's packaging to verify authenticity and learn more about your purchase.

## Related Documents - M68




## [MusiBaby M68 Portable Bluetooth Speaker: User Manual & Pairing Guide](#)

Comprehensive user manual and pairing instructions for the MusiBaby M68 portable Bluetooth speaker. Learn about specifications, setup, troubleshooting, and features.



## [MusiBaby M88 Bluetooth Speaker Quick Start Guide](#)

A quick start guide for the MusiBaby M88 Bluetooth speaker, covering setup, pairing, and features like dual pairing and water resistance.



### [MusiBaby M77 Bluetooth Speaker Quick Start Guide](#)

A comprehensive quick start guide for the MusiBaby M77 Bluetooth speaker, detailing package contents, Bluetooth pairing instructions, dual pairing capabilities, and its IPX7 waterproof rating for versatile use.



### [MusiBaby M71 Bluetooth Speaker Quick Start Guide](#)

A quick start guide for the MusiBaby M71 Bluetooth Speaker, covering setup, pairing, and dual pairing features.

### [MusiBaby M1 Portable Party Speaker User Guide](#)

User guide for the MusiBaby M1 Portable Party Speaker, covering button configuration, how to use, pairing, specifications, and care instructions.