

Divoom 1

Divoom Beetles Mini Bluetooth Speaker User Manual

Model: Divoom Beetles Mini

[Introduction](#) [What's in the Box](#) [Setup](#) [Operating Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

Thank you for purchasing the Divoom Beetles Mini Bluetooth Speaker. This compact and stylish speaker is designed to provide high-quality audio with the convenience of Bluetooth connectivity, FM radio, and TF card support. Its retro design and portable size make it an ideal companion for music on the go. Please read this manual carefully to ensure proper use and maintenance of your device.



Figure 1: Front view of the Divoom Beetles Mini Bluetooth Speaker in pink.

2. WHAT'S IN THE Box

Upon unboxing your Divoom Beetles Mini Bluetooth Speaker, please ensure all the following items are present:

- 1 x Divoom Beetles Speaker
- 1 x USB Charging Cable
- 1 x Lanyard
- 1 x User Manual (this document)
- 1 x Carry Box



Figure 2: The Divoom Beetles Mini speaker, its carry box, lanyard, and charging cable, as typically found in the package.

3. SETUP

3.1 Charging the Speaker

Before first use, fully charge the speaker. The Divoom Beetles Mini has a powerful battery providing up to 12 hours of playtime.

1. Locate the USB charging port on the side of the speaker.
2. Connect the smaller end of the provided USB cable to the speaker's charging port.
3. Connect the larger end of the USB cable to a USB power adapter (not included) or a computer's USB port.
4. The charging indicator light will illuminate. It will turn off or change color once charging is complete.



Figure 3: Various angles of the speaker, highlighting the charging port and controls.

3.2 Powering On/Off

To power on or off the speaker:

- **Power On:** Press and hold the power button (usually located on the side or top) for a few seconds until you hear an audible prompt or see an indicator light.
- **Power Off:** Press and hold the power button again for a few seconds until the speaker powers down.

3.3 Bluetooth Pairing

To connect your Divoom Beetles Mini to a Bluetooth-enabled device:

1. Ensure the speaker is powered on and in Bluetooth pairing mode (it usually enters this mode automatically when powered on for the first time or if no device is connected). An indicator light may flash to show it's ready to pair.
2. On your device (smartphone, tablet, computer), go to the Bluetooth settings.
3. Search for available devices. You should see "Divoom Beetles Mini" or a similar name in the list.
4. Select the speaker from the list to connect. Once connected, you will hear a confirmation sound, and the indicator light will become solid.

Note: If prompted for a password, enter "0000".

3.4 Inserting a TF Card

The speaker supports TF cards up to 32GB for MP3 playback.

1. Locate the TF card slot on the speaker.
2. Gently insert the TF card into the slot with the metal contacts facing down (or as indicated by a small icon next to the slot) until it clicks into place.
3. The speaker will automatically switch to TF card playback mode if a card with supported audio files is detected.

4. OPERATING INSTRUCTIONS

4.1 Bluetooth Playback

Once paired, you can control music playback directly from your connected device or using the speaker's controls:

- **Play/Pause:** Press the multi-function button (often marked with a play/pause icon).
- **Next Track:** Press and hold the volume up button or a dedicated next track button.
- **Previous Track:** Press and hold the volume down button or a dedicated previous track button.
- **Volume Control:** Rotate the dial or press the volume up/down buttons to adjust the volume.

4.2 FM Radio Operation

The Divoom Beetles Mini features a built-in FM radio antenna for listening to local stations.

1. Switch the speaker to FM mode. This might be done by pressing a dedicated mode button or by rotating a dial.
2. **Auto-Scan:** To automatically scan and save available FM stations, press and hold the play/pause button. The speaker will scan and store stations.
3. **Tune Stations:** Use the next/previous track buttons to cycle through the saved stations. The frequency dial on the front of the speaker will visually indicate the approximate frequency.



Figure 4: A detailed view of the FM frequency dial and the small indicator light on the speaker's top right.

4.3 TF Card Playback

Once a TF card with MP3 files is inserted, the speaker will typically switch to TF card mode automatically.

- **Play/Pause:** Press the multi-function button.
- **Next Track:** Press and hold the volume up button or a dedicated next track button.
- **Previous Track:** Press and hold the volume down button or a dedicated previous track button.

4.4 Call Handling (if applicable)

If your speaker supports hands-free calling (common for Bluetooth speakers):

- **Answer Call:** Press the multi-function button once when a call comes in.
- **End Call:** Press the multi-function button once during a call.
- **Reject Call:** Press and hold the multi-function button for a few seconds when a call comes in.

5. MAINTENANCE

To ensure the longevity and optimal performance of your Divoom Beetles Mini speaker, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the speaker's surface. Do not use abrasive cleaners, alcohol, or chemical solvents, as these can damage the finish.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Battery Care:** To preserve battery life, avoid fully discharging the battery frequently. If storing for an extended period, charge the speaker to about 50% every few months.
- **Water Resistance:** This speaker is not waterproof. Avoid exposing it to water or excessive moisture.
- **Handling:** Handle the speaker with care. Avoid dropping it or subjecting it to strong impacts.

6. TROUBLESHOOTING

If you encounter issues with your Divoom Beetles Mini speaker, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully.
Cannot pair via Bluetooth.	Speaker not in pairing mode; device Bluetooth off; too far from speaker.	Ensure speaker is in pairing mode. Turn Bluetooth off/on on your device. Move device closer to speaker (within 10 meters).
No sound from speaker.	Volume too low; incorrect source selected; speaker not connected.	Increase volume on both speaker and connected device. Ensure correct mode (Bluetooth, FM, TF) is selected. Re-pair Bluetooth if necessary.
FM radio static or poor reception.	Weak signal; interference.	Move the speaker to a different location. Perform an auto-scan again.
TF card not playing.	Card not inserted correctly; unsupported file format; corrupted card.	Re-insert TF card. Ensure files are in MP3 format. Try a different TF card.

7. SPECIFICATIONS

Key technical specifications for the Divoom Beetles Mini Bluetooth Speaker:

- **Brand:** Divoom
- **Model:** Divoom Beetles Mini (Item model number: 1)
- **Speaker Type:** Woofer
- **Connectivity Technology:** Bluetooth
- **Tuner Technology:** FM
- **Peak Power Handling:** 10 Watts
- **Product Dimensions (LxWxH):** 10 x 10 x 10 Millimeters (approx. 1 x 1 x 1 cm)
- **Item Weight:** 1 kg 200 g (1.2 kg)

- **Battery:** 1 Lithium Ion battery (required)
- **Play Time:** Up to 12 hours (approx.)
- **TF Card Support:** Up to 32GB (MP3 format)
- **Color:** Pink

8. WARRANTY & SUPPORT

The Divoom Beetles Mini Bluetooth Speaker comes with a **6 Month Warranty** from the date of purchase. This warranty covers manufacturing defects and issues arising from normal use.

For warranty claims, technical support, or any inquiries regarding your product, please contact Divoom customer service or the retailer from whom you purchased the product. Please retain your proof of purchase for warranty validation.

Manufacturer: Divoom, Zibbri India Private Limited

Importer: Zibbri India Pvt Ltd

© 2023 Divoom. All rights reserved.

This manual is subject to change without prior notice.


Related Documents

	<p>Divoom Tiivoo-2 Smart Pixel Speaker User Manual</p> <p>User manual for the Divoom Tiivoo-2 smart pixel speaker, detailing its features, functions, connectivity, and specifications. Learn how to use Bluetooth, FM radio, TF card, and USB modes, and connect to the Divoom app for enhanced features.</p>
	<p>Divoom Fairy-2 Portable Bluetooth Speaker User Manual</p> <p>Comprehensive user manual for the Divoom Fairy-2 portable Bluetooth speaker, covering setup, features like Bluetooth, TF card playback, FM radio, and karaoke functionality, along with technical specifications and safety guidelines.</p>



[Divoom SongBird-HQ Portable Karaoke Speaker System User Manual](#)

Comprehensive user manual for the Divoom SongBird-HQ portable karaoke speaker system, covering setup, operation, Bluetooth, TF card, AUX, charging, specifications, safety, and warranty information.



[Divoom LoveLock Mini Portable Bluetooth Speaker User Manual & Specifications](#)

Comprehensive guide to the Divoom LoveLock mini portable Bluetooth speaker, covering setup, features, TWS mode, charging, specifications, safety, warranty, and declaration of conformity.