

[Manuals.plus](#) /

› [Logitech G](#) /

› Logitech G PRO Mechanical Gaming Keyboard User Manual

Logitech G G PRO X

Logitech G PRO Mechanical Gaming Keyboard User Manual

Model: G PRO X

1. INTRODUCTION

The Logitech G PRO Mechanical Gaming Keyboard is engineered for competitive gaming, offering a compact tenkeyless design, durable mechanical switches, and customizable LIGHTSYNC RGB lighting. This manual provides instructions for setting up, operating, and maintaining your keyboard.



Image 1.1: Front view of the Logitech G PRO Mechanical Gaming Keyboard, showcasing its compact design and RGB backlighting.

2. WHAT'S IN THE BOX

Verify that all items are present in your package:

- Logitech G PRO Mechanical Gaming Keyboard
- Detachable Micro USB Cable

3. SETUP INSTRUCTIONS

1. **Connect the Keyboard:** Insert the detachable Micro USB cable into the port on the back of the keyboard. The three-pronged design ensures a secure connection. Connect the other end of the USB cable to an available USB port on your computer.



Image 3.1: Illustration of the detachable Micro USB cable connecting to the keyboard, highlighting the secure three-pronged design.

2. **Install Logitech G HUB Software:** For full customization of LIGHTSYNC RGB lighting and F-key programming, download and install the Logitech G HUB software from the official Logitech website (www.logitech.com/ghub).

3. **Adjust Keyboard Angle:** Utilize the three-step angle adjustment feet located on the underside of the keyboard to find your preferred typing or gaming angle. The rubber feet provide stability.



Image 3.2: Side view of the keyboard demonstrating the adjustable feet for ergonomic positioning and stability.

4. OPERATING THE KEYBOARD

4.1. Tenkeyless Design

The compact tenkeyless (TKL) design removes the numeric keypad, providing more space for mouse movement. This design is ideal for competitive gaming and portability.

PORTABLE + COMPACT



**MORE SPACE FOR MOUSE MOVEMENT WITH
COMPACT TENKEYLESS DESIGN.**

Image 4.1: The keyboard's compact, tenkeyless form factor, designed to maximize desk space for mouse movement.

4.2. GX Blue Click Switches

The keyboard features durable GX Blue Click mechanical switches. These switches provide an audible click and tactile feedback with each keypress, ensuring a solid and secure feel for precise input.

4.3. LIGHTSYNC RGB Backlighting

Customize your keyboard's lighting with LIGHTSYNC RGB. Using the Logitech G HUB software, you can select from 16.8 million colors and various lighting effects. Static lighting patterns can be programmed to the onboard memory for use on systems without G HUB installed.



LIGHTSYNC



**CUSTOMIZABLE LIGHTING AND ANIMATIONS
WITH LOGITECH G HUB SOFTWARE.**

Image 4.2: The keyboard illuminated with customizable LIGHTSYNC RGB backlighting, showcasing various color options.

4.4. F-Key Programming

The F-keys (F1-F12) can be programmed to execute complex actions or commands. This functionality requires the Logitech G HUB software. Note that keyboard macros may not be permitted in all competitive gaming environments.

5. MAINTENANCE

To ensure the longevity and performance of your Logitech G PRO Mechanical Gaming Keyboard, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the keyboard surface. For deeper cleaning, a can of compressed air can remove dust and debris from between the keycaps. Avoid using harsh chemicals or abrasive materials.
- **Cable Care:** Handle the detachable Micro USB cable with care. Avoid excessive bending or pulling to prevent damage to the cable or the keyboard's port.
- **Storage:** When not in use, store the keyboard in a clean, dry environment away from extreme temperatures.

6. TROUBLESHOOTING

If you encounter issues with your keyboard, refer to the following common solutions:

- **Keyboard Not Responding:**
 - Ensure the Micro USB cable is securely connected to both the keyboard and your computer.
 - Try connecting the keyboard to a different USB port on your computer.
 - Restart your computer.
- **RGB Lighting Not Working/Customizing:**
 - Verify that the Logitech G HUB software is installed and running.
 - Check for any software updates for Logitech G HUB.
 - Ensure the lighting is not disabled via a keyboard shortcut (e.g., Fn + F12 on some Logitech keyboards, though this model might have a dedicated lighting button).
- **Keys Not Registering:**
 - Clean the affected key area with compressed air to remove any debris.
 - If the issue persists, contact Logitech support.

7. SPECIFICATIONS

Feature	Detail
Brand	Logitech G
Model Number	G PRO X
Keyboard Type	Mechanical Gaming Keyboard
Switch Type	GX Blue Click
Design	Tenkeyless (TKL)
Connectivity	Detachable Micro USB Cable
Backlighting	LIGHTSYNC RGB (16.8 Million Colors)
Programmable Keys	F-keys (F1-F12) via Logitech G HUB
Adjustable Angle	Three-step adjustment
Product Dimensions	14.96"L x 6.3"W x 1.97"H
Item Weight	2.16 pounds
Compatible Devices	PC

8. WARRANTY AND SUPPORT

For detailed warranty information, please refer to the warranty card included with your product or visit the official Logitech G website. For technical support, software downloads (Logitech G HUB), and frequently asked questions, please visit the Logitech G support page:

support.logi.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08XF4WRG1>

More documents and user manuals: <https://manuals.plus/>