

ZORSOME Lenovo Tab M10 HD TB-X505F TB-X505L Tablet Case

ZORSOME EVA Shockproof Protective Case User Manual

Model: Lenovo Tab M10 HD TB-X505F, TB-X505L

Brand: ZORSOME

1. INTRODUCTION

This manual provides instructions for the ZORSOME EVA Shockproof Protective Case, designed specifically for the Lenovo Tab M10 HD (models TB-X505F and TB-X505L). This case offers enhanced protection for your tablet, making it suitable for use by children. It features a durable, lightweight design with a built-in handle and kickstand.

2. PRODUCT FEATURES

- **Eco-friendly and Non-toxic Material:** Constructed from EVA foam, this case is safe for children, non-toxic, and provides excellent shock absorption. Its ultra-lightweight design is comfortable for small hands.
- **Enhanced Protection:** Offers extra shock-absorbing, skid-proof, and anti-scratch protection. The flexible EVA material covers the back, frame, and extends over the screen edges for comprehensive defense.
- **Child-Friendly Handle:** Features a non-slip handle grip designed for easy carrying by children, also suitable for adults.
- **Integrated Kickstand:** Includes two foldable kickstands on the back, allowing the tablet to be propped up for hands-free horizontal viewing or typing positions.
- **Precise Cutouts:** Designed with accurate cutouts for all ports, buttons, and cameras, ensuring full access without needing to remove the case.

HIGH QUALITY MATERIALS,
ENVIRONMENTAL
PROTECTION AND COMFORT

Adopt environmental
protection EVA high-quality
material, belong to portable
and strong shell, provide
good protection.




Image 2.1: The ZORSOME protective case with a tablet, highlighting the integrated handle and kickstand functionality.



Image 2.2: Various angles of the ZORSOME case, showcasing its ergonomic handle and versatile kickstand.

3. SETUP AND INSTALLATION

1. **Prepare Your Tablet:** Ensure your Lenovo Tab M10 HD (TB-X505F or TB-X505L) is clean and free of debris.
2. **Insert Tablet:** Gently slide your tablet into the case, starting from one side. Apply even pressure around the edges to ensure the tablet fits snugly into the EVA frame.
3. **Verify Alignment:** Check that all ports, buttons, and camera lenses are correctly aligned with the case's cutouts. The case should not obstruct access to any tablet functions.

Camera Protection

3mm higher than the camera design prevents camera from being scratched.



Screen Protection

3mm higher than the camera design prevent the screen from being scratched by any inclusions.

Image 3.1: Detail showing the raised edges around the camera and screen for enhanced protection.

4. OPERATING INSTRUCTIONS

- **Using the Kickstand:** To use the kickstand, locate the two foldable stands on the back of the case. Gently pull them outwards until they lock into position. This allows the tablet to stand horizontally for viewing. To retract, push them back into the case until they are flush.
- **Using the Handle:** The integrated handle at the top of the case provides a secure grip for carrying the tablet. It is designed to be comfortable for both children and adults.

MODERN STYLISH

Upgrade the portable function and make it easy for children to carry.



Image 4.1: The case's handle provides a secure and comfortable grip for carrying.

5. MAINTENANCE AND CARE

- **Cleaning:** To clean the EVA case, wipe it gently with a damp cloth and mild soap. Avoid using harsh chemicals or abrasive cleaners, as these may damage the material.
- **Drying:** Allow the case to air dry completely before reinserting your tablet.
- **Storage:** Store the case in a cool, dry place away from direct sunlight when not in use for extended periods.

6. TROUBLESHOOTING

- **Difficulty Accessing Charging Port:** If you experience difficulty connecting the charging cable, ensure the cable is fully inserted and aligned with the port cutout. Some cables may have larger connectors that require slight adjustment.
- **Tablet Does Not Fit:** Verify that your tablet model is a Lenovo Tab M10 HD (TB-X505F or TB-X505L). This case is specifically designed for these models and may not fit other tablet versions.

- **Case Feels Loose:** Ensure the tablet is fully seated within the case and all edges are properly secured. The EVA material is flexible but should provide a snug fit for compatible models.

Military level Protection

- Effective shock absorption



Image 6.1: The case features a cushion air sac design for effective shock absorption.

7. SPECIFICATIONS

Feature	Detail
Brand	ZORSOME
Compatible Devices	Lenovo Tab M10 HD (TB-X505F, TB-X505L)
Material	EVA (Ethylene-vinyl acetate)
Form Factor	Case
Shell Type	Soft
Item Weight	8.4 ounces (approx. 238 grams)

Feature	Detail
Color (as reviewed)	Green

8. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your ZORSOME EVA Shockproof Protective Case, please contact the manufacturer directly. Refer to your purchase documentation or the seller's information for specific warranty details and contact methods.