

[manuals.plus](#) /

› [Lasko](#) /

› [Lasko CT24362 360-Degree Oscillating Ceramic Tower Heater User Manual](#)

Lasko CT24362

Lasko CT24362 360-Degree Oscillating Ceramic Tower Heater User Manual

Model: CT24362

1. IMPORTANT SAFETY INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USING THIS HEATER.

- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord.
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater and keep them away from the sides and rear.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Always unplug heater when not in use.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner.
- Do not use outdoors.
- This heater is not intended for use in bathrooms, laundry areas, and similar indoor locations. Never locate heater where it may fall into a bathtub or other water container.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- To disconnect heater, turn controls to OFF, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable vapors or liquids are used or stored.
- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.

- This heater includes an auto-off tip-over switch and overheat protection.

2. PRODUCT OVERVIEW

The Lasko CT24362 is a 360-degree oscillating ceramic tower heater designed to provide efficient and customizable warmth for your home. It features multiple heat settings, an adjustable thermostat, and a convenient remote control.

Key Features:

- **Full-Circle Heat Movement:** Select 90°, 180°, or 360° oscillation for even heat distribution.
- **Adjustable Thermostat:** Maintain desired room temperature in Fahrenheit or Celsius.
- **3 Heat Speeds:** Choose from low, medium, or high heat settings.
- **8-Hour Auto-Off Timer:** Program the heater to shut off automatically.
- **Multi-Function Remote Control:** Operate the heater conveniently from a distance.
- **Built-in Safety Features:** Includes auto-off tip-over switch and overheat protection. Exterior housing remains cool to the touch.
- **Easy-Vacuum Filter:** Simple maintenance for efficient operation.
- **Portable Design:** Lightweight with a built-in carry handle for easy room-to-room movement.

Product Components:

Key Features



Thermostatic Control

3 Comfort Settings: Low, Medium & High Heat

Oscillation On/Off

Figure 1: Key Features Overview

This image highlights the main control panel with indicators for Thermostatic Control, 3 Comfort Settings (Low, Medium, High Heat), and Oscillation On/Off.

Built-In Safety & Protection



Non-Combustible
Heating Element



Built-In
Overheat
Protection



Child &
Pet-Safe
Exterior

Figure 2: Built-in Safety & Protection

This image illustrates the safety aspects of the heater, including a non-combustible heating element, overheat protection, and a cool-touch exterior for child and pet safety.

Built for Everywhere



Figure 3: Product Dimensions

This image provides the physical dimensions of the heater, showing its height (24.1 inches) and base width/depth (9.2 inches), indicating its compact tower design.

Designed for Convenience



**Convenient
Carry Handle**



**Lightweight
Only 7.35 lbs**



**Easy to Use
Remote Control**



**Up to 8 Hour
Timer with
Automatic
Shut-off**

Figure 4: Designed for Convenience

This image highlights user-friendly features such as the convenient carry handle, lightweight design (7.35 lbs), easy-to-use remote control, and the 8-hour automatic shut-off timer.



Figure 5: Digital Control Panel

A detailed view of the heater's digital display and touch-sensing control buttons for power, heat settings, timer, and oscillation.





Figure 6: Remote Control

The multi-function remote control for convenient operation of the heater from a distance.

3. SETUP

Unpacking and Placement:

1. Remove the heater from its packaging. The Lasko CT24362 comes fully assembled.
2. Place the heater on a firm, level surface. Ensure it is at least 3 feet (0.9 meters) away from walls, furniture, and other combustible materials.
3. Plug the 6-foot power cord directly into a 120V wall outlet. Do not use extension cords or power strips.

4. OPERATING INSTRUCTIONS

The Lasko CT24362 can be operated using the touch-sensing controls on the unit's top panel or with the included multi-function remote control.

Control Panel Functions:

- **Power Button ()**: Press to turn the heater ON or OFF. The digital display will show the current room temperature when on.
- **Heat Setting Button ()**: Cycle through 3 heat speeds: Low, Medium, and High.
- **Temperature Adjustment Buttons (+ / -)**: Adjust the desired room temperature. The heater will cycle on/off to maintain this setting (Auto-Eco mode).
- **Oscillation Button ()**: Activate or deactivate the oscillation function. Cycle through 90°, 180°, and 360° heat sweep settings.
- **Timer Button ()**: Set the auto-off timer for up to 8 hours. Each press increases the timer by one hour.

Remote Control:

The remote control replicates all functions available on the unit's control panel, allowing for convenient adjustments from a distance.

Official Product Video:

Your browser does not support the video tag.

Video 1: Lasko Full Circle Warmth Ceramic Heater, CT24362, Black

This video provides an official overview of the Lasko CT24362 heater, demonstrating its features and operation. It showcases the 360-degree oscillation, digital controls, and overall design of the product.

5. MAINTENANCE

Cleaning the Filter:

The Lasko CT24362 features an easy-vacuum filter located on the back of the unit. Regular cleaning ensures optimal performance and efficiency.

1. Ensure the heater is turned OFF and unplugged from the power outlet.
2. Locate the filter cover on the back of the unit.
3. Gently open or remove the filter cover.
4. Use a vacuum cleaner with a brush attachment to carefully remove any dust or debris from the filter.
5. Replace the filter cover securely.
6. It is recommended to vacuum the filter monthly during periods of regular use.



Figure 7: Easy-Vacuum Filter Access

This image shows the rear of the heater with the filter access panel, indicating where to perform routine cleaning.

General Cleaning:

- Clean the exterior of the heater with a dry, soft cloth.
- Do not use water or any liquid cleaners directly on the unit.

6. TROUBLESHOOTING

Unit Shuts Down / Does Not Turn On:

If the heater unit unexpectedly shuts down or fails to turn on, follow these reset instructions:

1. Unplug the unit from the power outlet.
2. Wait for 5-10 minutes. This allows the internal safety mechanisms to reset.
3. Plug the unit back into a working wall outlet.
4. Turn the heater ON.

If the issue persists after following these steps, please contact Lasko customer support.

7. SPECIFICATIONS

| Feature | Detail |
|--------------------|------------------------|
| Brand | Lasko |
| Model Number | CT24362 |
| Color | Black |
| Form Factor | Tower |
| Product Dimensions | 9.2"D x 9.2"W x 24.1"H |
| Item Weight | 7.35 pounds |
| Fuel Type | Electric |
| Voltage | 120 Volts |
| Amperage | 12.5 Amps |
| Heating Coverage | Up to 150 sq.ft |
| Number of Speeds | 3 (Low, Medium, High) |

| Feature | Detail |
|---------------------|---|
| Special Features | 3 Heat Sweep Settings (90°, 180°, 360°), 8-Hour Timer, Adjustable Thermostat, Multi-Function Remote Control, Tip-Over Safety, Overheat Protection |
| Assembly Required | No (Comes fully assembled) |
| Included Components | Remote Control, Space Heater, User Manual |
| Care Instructions | Clean with a dry soft cloth, Keep away from water, Vacuum filter monthly |

8. WARRANTY & SUPPORT

Warranty Information:

This Lasko CT24362 Ceramic Tower Heater comes with a **3-year limited warranty**. Please refer to the warranty card included in your product packaging for full terms and conditions.

Customer Support:

For any questions, troubleshooting assistance, or warranty claims, please contact Lasko customer support directly. Contact information can typically be found on the product packaging or the official Lasko website.