

[Manuals.plus](#) /

› [LUXPRO](#) /

› LUXPRO 1000 Lumen Extremely Bright LED Handheld Flashlight, LP1201 User Manual

LUXPRO LP1200V2

LUXPRO 1000 Lumen Extremely Bright LED Handheld Flashlight User Manual

Model: LP1200V2

PRODUCT OVERVIEW

The LUXPRO LP1200V2 is a high-performance LED handheld flashlight designed for durability and versatility. It features advanced LPE Lighting Optics for a clear, crisp beam and a patented TackGrip handle for comfortable and secure handling in various conditions. This flashlight is suitable for a wide range of activities including camping, fishing, hiking, and general night safety.



Image: The LUXPRO LP1201 LED Handheld Flashlight, showcasing its sleek black design and durable construction.

Key Features

- **Multiple Light Modes:** Offers High (750 lumens), Medium (324 lumens), Low (61 lumens), and a Hidden Strobe mode.
- **Durable Construction:** Made from quality aircraft-grade anodized aluminum.
- **TackGrip Handle:** Patented grip feature molded directly to the flashlight for enhanced comfort and protection against heat/cold transfer.
- **Flexible Power Options:** Operates on 6 AA batteries (included) and can also run on 3 AA batteries.
- **Water Resistance:** IPX4 rated, designed to resist water splashes from any direction.
- **LPE Optics:** Proprietary reflector system for a clean, precise beam up to 380 meters.

SETUP AND BATTERY INSTALLATION

Your LUXPRO LP1200V2 flashlight comes pre-loaded with 6 AA alkaline batteries for immediate use. If you need to replace the batteries or wish to operate the flashlight with 3 AA batteries, follow these instructions:

1. **Unscrew the Tail Cap:** Hold the flashlight firmly and twist the tail cap counter-clockwise until it detaches from the body.
2. **Insert Batteries:** Insert 6 fresh AA alkaline batteries into the battery compartment, ensuring the positive (+) and negative (-) ends align with the indicators inside the flashlight. For 3-battery operation, insert 3 batteries, ensuring proper polarity.
3. **Secure the Tail Cap:** Carefully screw the tail cap back onto the flashlight body by twisting clockwise until it is fully tightened. Ensure a snug fit to maintain water resistance.

ADVANCED FEATURE

Operates on 6 AA or 3 AA batteries



Image: The LUXPRO LP1201 flashlight illustrating its capability to operate on either 6 AA or 3 AA batteries.

OPERATING INSTRUCTIONS

The LP1200V2 flashlight features multiple light modes for various situations. The power button is located on the side of the flashlight body.

- **Turning On/Off:** Press the power button once to turn the flashlight on. Press it again to turn it off.
- **Cycling Through Modes:** While the flashlight is on, quickly press the power button to cycle through the brightness modes: High (750 lumens) → Medium (324 lumens) → Low (61 lumens).
- **Accessing Hidden Strobe:** To activate the Hidden Strobe mode, press and hold the power button for approximately 3 seconds while the flashlight is on. To exit Strobe mode, press and hold the button again for 3 seconds, or cycle through the modes by quickly pressing the button.



ULTRA-BRIGHT

1000 Lumens on high mode

Image: The LUXPRO LP1201 flashlight in use, highlighting its ultra-bright 1000 lumen output on high mode.

EXTENDED RUN TIME

67 Hour run time on low mode



Image: The LUXPRO LP1201 flashlight illustrating its extended run time of 67 hours on low mode.

MAINTENANCE

Proper maintenance will ensure the longevity and optimal performance of your LUXPRO LP1200V2 flashlight.

- **Cleaning:** Wipe the flashlight body with a soft, damp cloth to remove dirt and debris. Do not use abrasive cleaners or solvents, as they may damage the finish or internal components.
- **Battery Care:** If the flashlight will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the circuitry. Always dispose of used batteries responsibly according to local regulations.
- **O-Ring Maintenance:** Periodically inspect the O-rings (seals) on the tail cap for any signs of wear or damage. A thin layer of silicone grease can be applied to the O-rings to maintain their integrity and ensure water resistance.

WATER RESISTANCE

Designed to resist water splashes
from any direction



Image: The LUXPRO LP1201 flashlight, highlighting its water resistance design to withstand splashes from any direction.

TACKGRIP

Advanced rubber grip molded directly to the light



Image: A hand holding the LUXPRO LP1201 flashlight, showcasing the advanced TackGrip for a secure and comfortable hold.

TROUBLESHOOTING

If you encounter issues with your LUXPRO LP1200V2 flashlight, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Flashlight does not turn on.	Dead or improperly installed batteries. Loose tail cap.	Replace batteries with fresh ones, ensuring correct polarity. Tighten the tail cap securely.
Light is dim or flickers.	Low battery power. Dirty battery contacts.	Replace batteries. Clean battery contacts with a clean cloth or cotton swab.
Cannot cycle through modes.	Button not pressed quickly enough. Internal electronic issue.	Ensure quick, distinct presses of the power button. If problem persists, contact customer support.

If these solutions do not resolve the issue, please refer to the Warranty and Support section for further assistance.

SPECIFICATIONS

Feature	Detail
Model Number	LP1200V2
Brightness	High: 750 Lumens, Medium: 324 Lumens, Low: 61 Lumens
Light Source Type	LED
Light Path Distance	380 Meters
Power Source	Battery Powered (6 AA or 3 AA)
Battery Cell Composition	Alkaline
Runtime	Up to 67 hours (on low mode)
Material	Aircraft-grade Anodized Aluminum
Color	Black
Water Resistance Level	IPX4 (Water Resistant)
Item Weight	1.11 Pounds
UPC	812436010375

WARRANTY AND SUPPORT

The LUXPRO LP1200V2 LED flashlight comes with a **Limited Lifetime Manufacturer Warranty**. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical support, or any questions, comments, or concerns regarding your product, please contact LUXPRO customer service. Refer to the official LUXPRO website or product packaging for the most current contact information.

Please retain your proof of purchase for warranty purposes.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08XLTSYQ4>

More documents and user manuals: <https://manuals.plus/>