

[Manuals.plus](#) /

› [Baby Born](#) /

› Baby Born 831168 Cute Horse Instruction Manual

Baby Born 831168

Baby Born 831168 Cute Horse Instruction Manual

Model: 831168 | Brand: Baby Born

INTRODUCTION

The Baby Born 831168 Cute Horse is an interactive toy designed to enhance imaginative play. This charming pony features realistic walking and neighing sounds, providing an engaging experience for children. It comes complete with a saddle, bridle, and decorative pins, allowing for personalization and creative play scenarios. This manual provides essential information for the safe and proper setup, operation, and care of your Cute Horse.

Please note that batteries are required for the full functionality of the horse and are not included with the product.



Image: The Baby Born Cute Horse with a Baby Born doll, demonstrating its use as a doll accessory.



Image: The Baby Born Cute Horse standing alone, showcasing its design.

PACKAGE CONTENTS

- 1 x Baby Born Cute Horse
- 1 x Saddle (pink)
- 1 x Bridle (pink)
- Decorative Pins

SETUP

1. Battery Installation

The Baby Born Cute Horse requires batteries for its walking and neighing functions. Locate the battery compartment, usually on the underside of the horse. Use a screwdriver to open the compartment, insert the required batteries (not included) according to the polarity indicators, and then securely close the compartment.

Important: Ensure batteries are inserted correctly. Do not mix old and new batteries, or different types of batteries.

2. Attaching the Saddle and Bridle

The pink saddle and bridle are designed for easy attachment to the horse. The saddle typically secures over the horse's back, and

the bridle fits over its head. Ensure all straps are fastened snugly but not too tightly.



Inklusive Sattel und Zaumzeug

Image: The pink saddle and bridle components, ready for attachment to the horse.



Image: The Baby Born Cute Horse with its pink saddle and bridle correctly attached.

3. Decorating with Pins

Use the provided decorative pins to personalize the saddle and bridle. These pins can be easily inserted into designated spots on the accessories, allowing for creative customization.



Image: A hand applying decorative pins to the horse's bridle, showcasing the customization feature.

OPERATING INSTRUCTIONS

1. Making the Horse Neigh

To hear the Cute Horse make realistic neighing sounds, gently press its **right ear**. The horse will respond with an excited neigh.



Mit Pins
zum selbst
dekorieren

Image: A hand pressing the right ear of the horse, which triggers its neighing sound.

2. Making the Horse Walk

To make the Cute Horse start walking, gently press its **left ear**. The horse will begin to move forward, accompanied by the sound of clattering hooves. For optimal movement, ensure the horse is on an even, flat surface.



Image: A hand pressing the left ear of the horse, initiating its walking motion.

3. Stopping the Horse

To stop the horse from walking, press its **left ear** again. The walking motion will cease.

4. Demonstration Videos

Your browser does not support the video tag.

Video: A demonstration of the Baby Born horse walking and neighing, suitable for children aged 3 and above. This video shows the horse's interactive features in action.

Your browser does not support the video tag.

Video: A closer look at the Baby Born Cute Horse, highlighting its design and interactive capabilities. This video provides additional visual details of the product.

MAINTENANCE

Cleaning

To clean the Baby Born Cute Horse, gently wipe its surface with a soft, damp cloth. Do not immerse the toy in water or use harsh

cleaning agents, as this may damage the electronic components.

Battery Replacement

When the horse's movements become slow or sounds become faint, it is time to replace the batteries. Follow the battery installation steps outlined in the "Setup" section. Always dispose of used batteries responsibly.

Storage

Store the toy in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, it is recommended to remove the batteries to prevent leakage.

TROUBLESHOOTING

- **Horse not walking or neighing:**
 - Check if the batteries are correctly installed and not depleted. Replace if necessary.
 - Ensure the ears are pressed firmly and correctly to activate the functions.
- **Movement is erratic or slow:**
 - Replace the batteries with fresh ones.
 - Ensure the horse is operating on a smooth, even surface.

SPECIFICATIONS

Model Number:	831168
Brand:	Baby Born
Product Dimensions:	15.35 x 5.91 x 12.2 inches
Item Weight:	2.73 pounds
Manufacturer:	Baby-born
Recommended Age:	3 years and older
Battery Requirement:	Batteries not included

SAFETY INFORMATION

- This toy is recommended for children aged 3 years and older.
- Adult supervision is recommended during play.
- Keep small parts (decorative pins) away from very young children to prevent choking hazards.
- **Battery Safety:**
 - Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
 - Do not mix old and new batteries.
 - Non-rechargeable batteries are not to be recharged.
 - Rechargeable batteries are only to be charged under adult supervision.
 - Exhausted batteries are to be removed from the toy.
 - The supply terminals are not to be short-circuited.

WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Baby Born 831168 Cute Horse, please refer to the manufacturer's official website or contact their customer service department. Please retain your proof of purchase for any warranty claims.

© 2026 Baby Born. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question