

[Manuals.plus](#) /

> [TOTO](#) /

> TOTO Washlet KS Series TCF8GS34#NW1 Instantaneous Warm Water Bidet Seat User Manual

## TOTO TCF8GS34

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

#### Question

Example: How do I reset this device or fix this error?

#### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

# TOTO Washlet KS Series TCF8GS34#NW1 Instantaneous Warm Water Bidet Seat User Manual

Model: TCF8GS34

## 1. INTRODUCTION AND OVERVIEW

This manual provides essential information for the safe and efficient use of your TOTO Washlet KS Series TCF8GS34#NW1 instantaneous warm water bidet seat. Please read it thoroughly before installation and operation, and keep it for future reference.

The TOTO Washlet KS Series TCF8GS34#NW1 is designed to enhance personal hygiene with its advanced features, including instantaneous water heating, a clean resin surface for easy maintenance, an auto power deodorizer, and convenient one-touch detachment for thorough cleaning.

## 2. SAFETY INFORMATION

Please observe the following safety precautions to prevent injury or damage to the product:

- Ensure the product is installed by a qualified professional to prevent electrical or plumbing hazards.
- Do not immerse the unit in water or spray water directly onto electrical components.
- Always unplug the unit from the power outlet before performing any cleaning or maintenance.
- Do not attempt to repair or modify the unit yourself. Contact TOTO customer service for assistance.
- Keep children and pets away from the unit during operation and cleaning.
- Use only the specified power supply (AC100V 50/60Hz).

## 3. PACKAGE CONTENTS

Verify that all the following items are included in your package:

- TOTO Washlet Main Unit
- Remote Control
- Remote Control Hanger
- Remote Control Mounting Screw Set
- Remote Control Batteries (Alkaline)
- Base Plate Set
- Warranty Card
- Instruction Manual (this document)

## 4. SETUP AND INSTALLATION

Installation of the TOTO Washlet involves plumbing and electrical connections. For safety and proper function, it is highly recommended that installation be performed by a qualified professional.

### Key Installation Considerations:

- **Power Supply:** The unit requires an AC100V 50/60Hz power source. The included 1.0m power cord features a leakage prevention plug and a ground wire for safety.
- **Water Connection:** Ensure proper water supply connection to prevent leaks.
- **Mounting:** Securely attach the base plate to the toilet bowl before sliding the Washlet main unit into place.

Refer to the detailed installation guide provided separately with your product for step-by-step instructions and diagrams.



Figure 1: The TOTO Washlet KS Series TCF8GS34#NW1 main unit, shown in white, ready for installation on a toilet bowl.

## 5. OPERATING INSTRUCTIONS

Your TOTO Washlet is designed for user-friendly operation. All functions are controlled via the remote control.

### 5.1. Instantaneous Warm Water

The Washlet features an instantaneous heating system. This means water is heated on demand, providing a continuous supply of warm water for washing without the need for a storage tank. This design also contributes to energy efficiency.

### 5.2. Washing Functions

The Washlet offers a comfortable and rich washing experience. It utilizes alternating water streams of different velocities to create larger water droplets, ensuring thorough and gentle cleansing.

快適

# たっぷりとした洗い心地

流速の違う水を交互に連射して、大きな水玉を作り、たっぷりの浴び心地をもたらします。

(おしり洗浄のみ)



Figure 2: A diagram illustrating the Washlet's rich washing feature, where alternating fast and slow water streams create larger, more comfortable water droplets for effective cleansing.

### 5.3. Auto Power Deodorizer

After each use, the Washlet's auto power deodorizer activates automatically. It switches from normal deodorization to a powerful deodorization mode, increasing the suction volume by approximately two times to effectively eliminate odors and ensure a fresh environment for the next user.

快適

# オートパワー脱臭

使用後は自動で吸い込み量約2倍※1



Figure 3: An internal view diagram of the Washlet, highlighting the airflow path of the auto power deodorizer function, which activates after use to remove odors.

## 5.4. Energy-Saving Functions

The Washlet is equipped with various energy-saving features to reduce power consumption:

- **Timer Energy Saving:** Once set, the toilet seat heater automatically turns off at the same time every day, saving energy.
- **Auto Energy Saving:** The unit learns your usage patterns and automatically lowers the toilet seat temperature during periods of infrequent use.



## 多彩な節電機能

いつも通り使っていても経済的！



ON OFF

### タイマー節電

一度設定すると、毎日同じ時間に便座ヒーターを自動で切って節電。



### お任せ節電

トイレの使用頻度を記憶して、普段あまり使用しない時間帯は便座の温度を自動的に下げて節電

Figure 4: A visual representation of the Washlet's energy-saving features, showing a timer for scheduled power off and an adaptive clock for automatic temperature adjustment based on usage.

## 6. MAINTENANCE AND CLEANING

Regular cleaning ensures hygiene and extends the product's lifespan. Always unplug the unit before cleaning.

### 6.1. Clean Resin Surface

The toilet seat and nozzle are made with a highly stain-resistant clean resin. This material repels dirt, making it easy to wipe clean with a single swipe, simplifying daily maintenance.

清潔

# お手入れラクラク！

クリーン樹脂を使っているためサッとひとふきでお掃除ができます。



従来の便座



クリーン便座

Figure 5: A visual comparison showing how a conventional toilet seat accumulates dirt versus the clean resin toilet seat, which repels stains for easier cleaning.

## 6.2. One-Touch Main Unit Detachment

For thorough cleaning of hard-to-reach areas, such as the space between the toilet seat and the tank, the Washlet main unit can be easily detached with a single touch. This allows for comprehensive cleaning of the entire toilet area.

**Important: When detaching the Washlet main unit for cleaning, always unplug the power cord from the outlet first.**

清潔

# 本体ワンタッチ着脱

カンタンに取り外し隅々までお掃除ラクラク！



Figure 6: An illustration demonstrating the one-touch detachment mechanism, allowing the Washlet main unit to be easily removed from the toilet bowl for comprehensive cleaning.

## 7. TROUBLESHOOTING

If you encounter any issues with your TOTO Washlet, please refer to the troubleshooting section in the comprehensive instruction manual included with your product. Common issues and their solutions are typically covered there.

If the problem persists or if you are unsure about any troubleshooting steps, please contact TOTO customer support or a qualified service technician.

## 8. SPECIFICATIONS

Feature	Specification
---------	---------------

Feature	Specification
Brand	TOTO
Model Number	TCF8GS34#NW1
Product Dimensions (W x D x H)	39.1 x 53.1 x 17.6 cm
Product Weight	4.5 kg
Color	White
Surface Material	Clean Resin
Power Supply	AC100V 50/60Hz
Power Cord Length	1.0m (with leakage prevention plug and ground wire)
Rated Power Consumption	1268W
Annual Power Consumption	114 kWh/year (150 kWh/year without timer energy-saving function)
Included Batteries (for remote)	Alkaline

## 9. WARRANTY AND SUPPORT

For detailed warranty information, please refer to the warranty card included with your product. TOTO provides support for product defects and operational issues.

Please note that according to Amazon's return policy, returns or exchanges for toilet seats due to customer convenience are generally not possible. We advise careful consideration before purchase to ensure the product meets your requirements.

For specific inquiries regarding product specifications, functions, or usage, please contact the manufacturer directly. Be aware that product colors may appear differently on screen compared to the actual item.

For technical support or service requests, please visit the official TOTO website or contact their customer service department.