

Manuals.plus /

- › BABY born /
- › BABY born Bath Walk-In Shower for 43 cm Dolls – Instruction Manual

## BABY born 830604

# BABY born Bath Walk-In Shower Instruction Manual

Model: 830604

## INTRODUCTION

The BABY born Bath Walk-In Shower is designed to provide an interactive and imaginative play experience for children aged 3 years and up. This accessory allows BABY born dolls (36 cm to 43 cm) to enjoy a realistic shower experience with real water flow. It encourages role-play, empathy, and social skill development.



Image: Overview of the BABY born Bath Walk-In Shower.

## PACKAGE CONTENTS

Please ensure all components are present before assembly and use.

- 1 x BABY born Bath Walk-In Shower Unit
- 1 x Adjustable Shower Head
- 1 x Duck-shaped Water Activator / Temperature Control
- 1 x Blue Bath Mat
- Required: 4 x AA Batteries (not included)




Image: Visual representation of the included components: shower unit, duck, bath mat, and clear partition.

## SETUP

### Battery Installation

1. Locate the battery compartment on the shower unit. This is typically on the underside or back of the base.
2. Using a small Phillips head screwdriver, open the battery compartment cover.
3. Insert 4 x AA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Replace the battery compartment cover and secure it with the screw.

**Important:** Always use new batteries. Do not mix old and new batteries, or different types of batteries. Remove batteries if the toy will not be used for an extended period.

### Assembly

1. Place the shower unit on a flat, stable surface, preferably one that can withstand water splashes.
2. Position the blue bath mat in front of the shower unit to catch any excess water.
3. Ensure the adjustable shower head is securely attached to the main unit.
4. Fill the water reservoir (located at the base of the shower) with clean tap water. Do not overfill.



Image: The fully assembled BABY born Bath Walk-In Shower with the duck accessory and bath mat in place.

## OPERATING INSTRUCTIONS

---

### Using the Shower

1. Place your BABY born doll (36-43 cm) inside the shower unit.
2. To activate the water flow, turn the duck-shaped knob located at the base of the shower. Turning the duck will start the pump, causing real water to flow from the shower head.
3. The duck also serves as a pretend temperature control. Children can turn it to simulate adjusting the water temperature for imaginative play.
4. To stop the water flow, turn the duck-shaped knob back to its original position.



Image: A BABY born doll enjoying a shower, demonstrating the water flow feature.

### **Adjusting the Shower Head**

The shower head is adjustable to accommodate different doll sizes (36 cm to 43 cm). Gently slide the shower head mechanism up or down the vertical track to set the desired height for your doll.



Image: A detailed view of the adjustable shower head, showing its movable design.

## MAINTENANCE

---

### Cleaning

- After each use, empty any remaining water from the reservoir.
- Wipe down all surfaces of the shower unit with a damp cloth.
- Do not submerge the entire unit in water.
- Allow all parts to air dry completely before storing to prevent mold or mildew.

### Storage

Store the BABY born Bath Walk-In Shower in a clean, dry place away from direct sunlight when not in use.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Water is not flowing from the shower head.	<ul style="list-style-type: none"> <li>Batteries are dead or incorrectly installed.</li> <li>Water reservoir is empty.</li> <li>Duck knob is not fully turned.</li> </ul>	<ul style="list-style-type: none"> <li>Replace batteries with new AA batteries, ensuring correct polarity.</li> <li>Refill the water reservoir.</li> <li>Ensure the duck knob is fully turned to activate the pump.</li> </ul>
Weak water flow.	<ul style="list-style-type: none"> <li>Low battery power.</li> <li>Insufficient water in reservoir.</li> </ul>	<ul style="list-style-type: none"> <li>Replace batteries.</li> <li>Add more water to the reservoir.</li> </ul>
Unit makes noise but no water flows.	<ul style="list-style-type: none"> <li>Air in the pump.</li> <li>Water reservoir is empty.</li> </ul>	<ul style="list-style-type: none"> <li>Ensure reservoir is full. Turn the duck knob on and off a few times to prime the pump.</li> <li>Refill the water reservoir.</li> </ul>

## SPECIFICATIONS

Feature	Detail
Product Dimensions (L x W x H)	29.5 x 24 x 44 cm (11.6 x 9.4 x 17.3 inches)
Weight	2.6 kg (5.7 lbs)
Recommended Age	36 months - 10 years (3+ years)
Educational Value	Spatial perception, Empathy, Social skills, Responsibility, Communication
Model Reference	830604
Number of Players	1 piece (single player)
Assembly Required	No (minor setup for batteries/water)
Scale	1:12 Scale
Batteries Required	Yes, 4 x AA batteries (not included)
Main Material	Plastic
Color	Colourful (Pink and White)
Compatibility	Suitable for BABY born dolls 36 cm to 43 cm

## WARRANTY AND SUPPORT

This product is designed for durability and long-lasting play. While specific warranty details are not provided, for any issues or inquiries regarding the product, please contact the manufacturer, BABY born, directly through their official website or customer service channels.

Please note that spare parts for this product are generally unavailable, as indicated in the product specifications. For optimal performance and longevity, follow all setup, operating, and maintenance instructions carefully.

For more information about BABY born products, visit the official BABY born Brand Store.

