BarcaLounger 9PH-3716-3727-44

BarcaLounger Kester Power Recliner with Power Headrest User Manual

Model: 9PH-3716-3727-44

Introduction

Thank you for choosing the BarcaLounger Kester Power Recliner with Power Headrest. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new recliner. Please read these instructions carefully before use and retain them for future reference.

Important Safety Information

To reduce the risk of injury, fire, electric shock, or damage to the product, please adhere to the following safety guidelines:

- **Keep Clear of Moving Parts:** Ensure hands, feet, and clothing are clear of the reclining mechanism and headrest when operating the recliner.
- **Children and Pets:** Do not allow children or pets to play on or around the recliner, especially when it is in motion. Always supervise children near the product.
- **Weight Limit:** This recliner is designed for one person. Do not exceed the recommended weight capacity (consult product specifications for details).
- **Power Cord:** Position the power cord safely to prevent tripping hazards and damage. Do not place heavy objects on the cord.
- **Unplug When Not in Use:** Disconnect the power cord from the outlet before cleaning, moving, or if the recliner will be unused for an extended period.
- **Avoid Liquids:** Do not spill liquids on the recliner, especially near electrical components.
- **Professional Repair:** Do not attempt to repair the recliner yourself. Contact qualified service personnel for any repairs.

Package Contents

Please check that all components are present before beginning assembly. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- Recliner Base

- Backrest
- Power Adapter and Cord
- Legs (pre-attached or separate, depending on model)
- Instruction Manual (this document)

Setup and Assembly

Assembly is required for this recliner. It is recommended that two adults perform the assembly to ensure safety and ease.

1. **Unpack Components:** Carefully remove all components from the packaging. Place them on a soft, clean surface to prevent scratching.
2. **Attach Backrest:** Align the metal receivers on the backrest with the posts on the recliner base. Slide the backrest down firmly until it locks into place. You should hear a click.
3. **Connect Power:** Locate the power cord connection point at the rear or underside of the recliner base. Connect the power adapter to the recliner and then plug the adapter into a standard wall outlet. Ensure the connection is secure.
4. **Position Recliner:** Place the recliner in its desired location, ensuring there is sufficient clearance from walls (minimum 2.2 inches for wall proximity) and other furniture for full recline.



Figure 1: Overall dimensions of the BarcaLounger Kester Power Recliner. The recliner measures approximately 39.8 inches deep, 39.4 inches wide, and 41.9 inches high.

Operating Instructions

Your BarcaLounger Kester Power Recliner features power recline and a power headrest for personalized comfort.

- **Power Recline:** Locate the control panel, typically on the side of the recliner. Press and hold the recline button to smoothly extend the footrest and recline the backrest. Release the button at your desired position. To return to the upright position, press and hold the opposite button.
- **Power Headrest:** Use the dedicated headrest buttons on the control panel to adjust the angle of the headrest independently. This allows for optimal neck and head support in any reclined position.
- **USB Charging Port:** The control panel includes a USB port. You can use this port to charge compatible electronic devices while relaxing in your recliner.



Figure 2: Side view of the recliner, highlighting the integrated control panel with power recline and headrest buttons, and a USB charging port.



Figure 3: The BarcaLounger Kester Power Recliner fully extended, demonstrating the recline function and footrest.

Maintenance and Care

Proper care will extend the life and appearance of your leather recliner.

- **Regular Cleaning:** Dust the leather regularly with a soft, dry cloth. For light cleaning, wipe with a damp cloth and immediately dry with a clean, soft cloth.
- **Stain Removal:** For spills, blot immediately with a clean, absorbent cloth. Do not rub. For stubborn stains, use a mild leather cleaner specifically designed for the type of leather on your recliner. Always test cleaners on an inconspicuous area first.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or harsh detergents, as these can damage the leather finish.
- **Sunlight and Heat:** Avoid placing the recliner in direct sunlight or near heat sources, as this can cause the leather to fade, dry out, or crack.

- **Mechanism Lubrication:** The reclining mechanism is designed for long-term use and typically does not require lubrication. If you notice unusual noises or stiffness, contact customer support.

Troubleshooting

If you encounter issues with your recliner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Recliner does not operate (no power)	Power cord unplugged; outlet not working; loose connection.	Ensure power cord is securely plugged into both the recliner and a working wall outlet. Check circuit breaker.
Reclining mechanism is stiff or noisy	Obstruction in mechanism; components need adjustment.	Check for any obstructions under the recliner. Do not force the mechanism. Contact customer support if the issue persists.
Headrest does not adjust	Loose connection to headrest motor; motor malfunction.	Verify all internal connections are secure. If problem continues, contact customer support.
USB port not charging	Device incompatibility; power issue.	Ensure the recliner is powered on. Try a different device or USB cable.

If these solutions do not resolve the issue, please contact customer support for further assistance.

Specifications

Feature	Detail
Model Name	Kester
Model Number	9PH-3716-3727-44
Overall Dimensions (D x W x H)	39.8" x 39.4" x 41.9" (101.1 cm x 100.1 cm x 106.4 cm)
Item Weight	143.3 Pounds (65 kg)
Seat Height	20.9 Inches (53.1 cm)
Seat Depth	21.3 Inches (54.1 cm)
Seat Length	22.1 Inches (56.1 cm)
Arm Height	26.4 Inches (67.1 cm)
Material	Leather (Top grain leather with matching vinyl on sides & back)
Frame Material	Wood (Furniture grade plywood construction)
Power Features	Power Recline, Power Headrest, USB Charging Port
Wall Proximity	2.2 inches (5.6 cm)
Assembly Required	Yes

Warranty Information

BarcaLounger products are manufactured to high-quality standards. For specific warranty details regarding your Kester Power Recliner, please refer to the warranty documentation provided with your purchase or consult the official BarcaLounger website. Warranty coverage typically includes manufacturing defects and may vary by component.

Customer Support

If you have any questions, require assistance with assembly, or need troubleshooting support that is not covered in this manual, please contact your retailer or the manufacturer directly. Have your model number (9PH-3716-3727-44) and proof of purchase ready when contacting support.
For more information, you may visit the official BarcaLounger website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question