

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Harper & Bright Designs](#) /
- › [Harper & Bright Designs Twin Over Twin Bunk Bed Instruction Manual](#)

## Harper & Bright Designs B08XQNH5PR

# Harper & Bright Designs Twin Over Twin Bunk Bed Instruction Manual

Model: B08XQNH5PR

### IMPORTANT SAFETY WARNINGS

Please read and understand all instructions and warnings before assembling and using this bunk bed. Keep this manual for future reference.

- **Maximum Weight Capacity:** The top bunk is designed to support a maximum weight of 175 lbs (79 kg). The bottom bunk is designed to support a maximum weight of 250 lbs (113 kg). Do not exceed these limits.
- **Guard Rails:** Always use the guard rails on the top bunk. Ensure they are properly installed and secured.
- **Mattress Requirements:** Use only mattresses that are 75 inches long and 39 inches wide. The maximum mattress thickness for the top bunk should not exceed 6 inches to ensure proper guard rail height.
- **Ladder Safety:** Always use the ladder for entering and exiting the top bunk. Do not use the bed as a climbing frame.
- **No Jumping:** Do not allow jumping on the bed.
- **Age Restriction:** The top bunk is not suitable for children under 6 years of age.
- **Ventilation:** Ensure adequate ventilation around the bed.
- **Regular Checks:** Periodically check and ensure that all connectors are tight.
- **Strangulation Hazard:** Do not attach or hang items to any part of the bunk bed that are not designed for use with the bed; for example, but not limited to, hooks, belts, and jump ropes.

### PACKAGE CONTENTS

Before beginning assembly, ensure all parts are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- Bed Frame Components (Headboards, Footboards, Side Rails)
- Guard Rails
- Ladder

- Slats for mattress support
- Hardware Pack (screws, bolts, nuts, washers, Allen wrench)
- Instruction Manual

## SETUP AND ASSEMBLY

---

Assembly typically requires two adults. Clear a spacious area for assembly and keep all hardware out of reach of small children. Do not use power tools for assembly as this may overtighten and damage the wood.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a soft, clean surface to prevent scratches.
2. **Assemble End Panels:** Attach the headboards and footboards to the vertical posts using the provided hardware. Ensure all connections are snug but do not fully tighten yet.
3. **Attach Side Rails:** Connect the side rails to the assembled end panels for both the top and bottom bunks.
4. **Install Ladder:** Securely attach the ladder to the designated side of the bunk bed frame.
5. **Install Guard Rails:** Attach the guard rails to the top bunk frame. Verify they are firmly in place.
6. **Place Slats:** Distribute the mattress slats evenly across the support rails for both bunks and secure them according to the instructions.
7. **Final Tightening:** Once all components are in place, carefully go back and tighten all bolts and screws. Do not overtighten.



Image: Angled view of the bunk bed frame, illustrating the general structure for assembly reference.

This bunk bed is designed for sleeping purposes. Adhere to the safety warnings provided in this manual.

- Ensure mattresses are correctly sized and placed on the slats.
- Always use the ladder to access the top bunk.
- Do not allow more than one person on the top bunk at a time.
- Regularly inspect the bed for any signs of wear or damage.

## MAINTENANCE

Proper maintenance will extend the life of your bunk bed.

- **Cleaning:** Wipe down the wood surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Hardware Check:** Periodically (e.g., every 3-6 months) check all bolts, screws, and connections to ensure they are tight. Retighten if necessary, but do not overtighten.
- **Wood Care:** Protect the wood from extreme temperature changes and direct sunlight to prevent warping or fading.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Bed feels wobbly or unstable	Loose hardware connections.	Check and tighten all bolts and screws. Ensure all parts are correctly aligned.
Squeaking noises	Loose connections or friction between wood parts.	Tighten all hardware. If squeaking persists, apply a small amount of paraffin wax or silicone spray to contact points between wood components.
Missing parts during assembly	Packaging error or lost during unpacking.	Carefully re-check all packaging materials. Contact customer support with the specific part number from the assembly diagram.

## SPECIFICATIONS

- **Model:** B08XQNH5PR
- **Brand:** Harper & Bright Designs
- **Size:** Twin Over Twin
- **Product Dimensions:** 79"L x 41"W x 50"H
- **Color:** Espresso
- **Finish Type:** Wood
- **Material:** Pine Wood, Wood
- **Included Components:** Guardrails, Slats
- **Form Factor:** Bunk Bed



Image: Overall dimensions of the Twin Over Twin Bunk Bed.

## WARRANTY INFORMATION

---

Specific warranty details for this product are typically provided by the manufacturer or the retailer at the time of purchase. Please refer to your purchase documentation or contact the seller directly for information regarding warranty coverage, terms, and conditions.

## CUSTOMER SUPPORT

---

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact the retailer or Harper & Bright Designs customer service. Have your product model number (B08XQNH5PR) and purchase date ready when contacting support.

For general inquiries, you may visit the Harper & Bright Designs store page: [Harper & Bright Designs Store](#)