Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HOMCOM 833-872V02LG

HOMCOM Set of 2 Adjustable Media Storage Shelves (Model 833-872V02LG) Instruction Manual

Model: 833-872V02LG

1. Introduction

This manual provides instructions for the assembly, operation, and maintenance of your HOMCOM Set of 2 Adjustable Media Storage Shelves. These units are designed to store CDs, DVDs, Blu-rays, video games, books, and other decorative items. Each unit features six compartments with adjustable shelves, offering flexible storage solutions for your home or office. The design includes a lengthened base for stability and anti-tipping straps for safety.



Image 1.1: Two HOMCOM media storage shelf units, showcasing their use in a home office environment.



Image 1.2: The media storage units offer spacious compartments suitable for various items, including CDs, DVDs, and decorative pieces.

2. Setup Instructions

Assembly is required for these media storage units. Please follow the steps below carefully. It is recommended to have a short Phillips screwdriver available for assembly, as it is not supplied.

2.1 Unpacking and Component Check

- Carefully unpack all components from the packaging.
- Verify that all parts are present and undamaged. Refer to the included parts list (usually found in the product packaging).
- Inspect for any cosmetic flaws or chips. Minor marks can often be removed with an eraser.

2.2 Assembly of Each Unit

Each unit is assembled individually. Pay attention to the orientation of the side panels, as they are not symmetrical. Ensure consistent assembly if you intend to place the units side-by-side.

1. Attach the base and top panels to the side panels using the provided hardware. Ensure all connections are secure.
2. Insert the fixed middle shelf into its designated slots.
3. Install the back panel. Ensure the marked side (if any) faces the rear.



Image 2.1: The lengthened base design contributes to the unit's overall stability.

2.3 Installing Adjustable Shelves

The units come with five adjustable shelves per unit, offering three height options for each shelf. This allows customization for different media sizes.

1. Locate the pre-drilled holes on the inner sides of the unit.
2. Insert the shelf pins into the desired holes.
3. Place the adjustable shelves onto the pins.



Image 2.2: Adjustable shelves provide flexibility for various item sizes. Each shelf has three height options, with 3.2 cm increments.

2.4 Anti-Tipping Kit Installation

For safety, especially in homes with children or pets, it is crucial to install the anti-tipping straps provided. These straps secure the units to the wall, preventing accidental tipping.

1. Position the assembled unit(s) in the desired location.
2. Attach one end of the anti-tipping strap to the top rear of the unit using the provided screws.
3. Mark the corresponding spot on the wall.
4. Drill a pilot hole in the wall (use appropriate wall anchors if necessary, depending on wall material).
5. Attach the other end of the strap to the wall using the provided screws.
6. Ensure the strap is taut and securely fastened.



Image 2.3: The anti-tipping kit ensures the unit is securely anchored to the wall for enhanced safety.

2.5 Flexible Placement Options

The two units can be used together or separately. They can be placed side-by-side or stacked vertically to create a taller storage solution. If stacking, ensure the anti-tipping mechanism is properly installed for the combined height.



Image 2.4: The units can be arranged side-by-side or stacked to suit different space requirements.



Image 2.5: Horizontal placement of the units, demonstrating versatility in room arrangement.

3. Operating Instructions

3.1 Adjusting Shelf Height

To adjust the height of the shelves:

1. Remove all items from the shelf you wish to adjust.
2. Carefully lift the shelf off its pins.
3. Remove the shelf pins from their current holes.
4. Re-insert the shelf pins into the desired new height holes.
5. Place the shelf back onto the pins, ensuring it is level and secure.

Note: When storing taller items like Blu-rays or DVDs, you may need to adjust shelves to create larger compartments, which might result in fewer usable shelves per unit.

4. Maintenance

4.1 Cleaning

- Wipe surfaces with a soft, damp cloth.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the engineered wood finish.
- Dry immediately with a clean, dry cloth to prevent moisture damage.

4.2 General Care

- Periodically check all screws and connections to ensure they remain tight.
- Ensure the anti-tipping straps are still securely fastened to both the unit and the wall.
- Avoid placing excessively heavy items on the shelves to prevent bowing or damage. Each shelf has a maximum load capacity of 2kg.
- Keep the unit away from direct sunlight and excessive moisture to prolong its lifespan.

5. Troubleshooting

Problem	Possible Cause	Solution
Unit feels unstable or wobbly.	Loose connections; uneven floor; anti-tipping kit not installed or loose.	Tighten all screws. Ensure the unit is on a level surface. Install or re-secure the anti-tipping straps to the wall.
Shelves do not fit taller items (e.g., Blu-rays, DVDs).	Shelf height is set for CDs.	Adjust the shelf pins to a lower position to create taller compartments. Note that this may reduce the total number of usable shelves.
Visible marks or minor chips on the surface.	Manufacturing imperfection or handling during assembly.	Minor marks can often be removed with a soft eraser. Small chips may be touched up with furniture repair pens or wood filler.
Difficulty assembling due to unclear instructions.	Diagrams may be small or unclear.	Review the diagrams carefully. Ensure side panels are oriented correctly (they are not symmetrical). Identify parts by number of connectors if diagrams are difficult to read.

6. Specifications



Image 6.1: Detailed dimensions and weight capacity of a single HOMCOM media storage unit.

- **Model Number:** 833-872V02LG
- **Color:** Grey
- **Material:** Engineered Wood (Particle Board)
- **Overall Dimensions (per unit):** 88.5 cm (H) x 21 cm (W) x 22.5 cm (D) / 34.84 inches (H) x 8.27 inches (W) x 8.27 inches (D)
- **Shelf Dimensions:** 12.5 cm (H) x 17.5 cm (L) x 17 cm (W)
- **Shelf Adjustable Height:** 3.2 cm increments
- **Number of Shelves:** 5 adjustable shelves per unit (plus 1 fixed middle shelf)
- **Weight Capacity (per unit):** 15 kg (33 lbs)
- **Weight Capacity (per shelf):** 2 kg (4.4 lbs)
- **Number of Pieces:** 2 units per set
- **Assembly Required:** Yes
- **Special Features:** Adjustable shelves, Anti-tipping kit, Lengthened base design

- **Room Type:** Office, Home
- **Installation Type:** Wall Mount (with anti-tipping kit)

7. Warranty & Support

7.1 Warranty Information

Specific warranty details for your HOMCOM product may vary by region and retailer. Please refer to your purchase documentation or contact the retailer where you purchased the product for precise warranty terms and conditions.

7.2 Customer Support

For assistance with assembly, missing parts, or any other product-related inquiries, please contact HOMCOM customer support or the retailer from whom you purchased the product. Contact information can typically be found on the product packaging or the retailer's website.

© 2026 HOMCOM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08XQZ9WTR

More documents and user manuals: **https://manuals.plus/**