

[Manuals.plus](#) /

> [CHESONA](#) /

> CHESONA Keyboard Case for iPad 9th/8th/7th Gen 10.2" and iPad Air 3/Pro 10.5" - User Manual

CHESONA for iPad 9th/8th/7th Gen 10.2-inch

CHESONA Keyboard Case User Manual

For iPad 9th/8th/7th Gen 10.2" and iPad Air 3/Pro 10.5"

PRODUCT OVERVIEW

This manual provides instructions for the CHESONA detachable wireless keyboard case, featuring a multi-touch trackpad and pencil holder. It is designed to enhance your tablet experience by providing laptop-like functionality and protection.



Image: The CHESONA keyboard case with an iPad inserted, shown in a working setup.

COMPATIBILITY

This keyboard case is compatible with the following iPad models. Please verify your iPad's model number (starting with "A" on the back) before use.

- **iPad 9th Gen 10.2 inch 2021:** Models A2602, A2603, A2604, A2605
- **iPad 8th Gen 10.2 inch 2020:** Models A2270, A2428, A2429, A2430
- **iPad 7th Gen 10.2 inch 2019:** Models A2197, A2200, A2198
- **iPad Pro 10.5 inch 2017:** Models A1701, A1709, A1852
- **iPad Air 3rd Gen 10.5 inch 2019:** Models A2152, A2123, A2153, A2154



Magnetic
Keyboard



Type-C
Charging Port



Multi-Touch
Trackpad



Scissor
Key Structure



Image: A visual guide detailing compatible iPad models and their corresponding model numbers.

Your browser does not support the video tag.

Video: Overview of the keyboard case and its compatibility with various iPad models (1:52 duration).

SETUP INSTRUCTIONS

1. Inserting Your iPad into the Case

1. Align your iPad with the case's frame.
2. Gently press the iPad into the case, ensuring all corners are securely fitted.
3. Verify that all ports, buttons, and the camera are accessible and unobstructed.

2. Connecting the Bluetooth Keyboard

1. Ensure the keyboard is charged.
2. Slide the power switch on the keyboard to the **ON** position. The indicator light will flash.
3. On your iPad, go to **Settings > Bluetooth** and turn Bluetooth **ON**.
4. Look for "Bluetooth Keyboard" or a similar name in the **Other Devices** list and tap to connect.
5. Once connected, the indicator light on the keyboard will turn off.

Your browser does not support the video tag.

Video: Demonstrates the process of connecting the keyboard via Bluetooth and using key shortcuts (0:34 duration).

OPERATING INSTRUCTIONS

Keyboard and Trackpad Functions

- **Multi-touch Trackpad:** The integrated trackpad supports various iOS gestures for navigation, clicking, scrolling, and swiping.
- **Trackpad Activation:** To turn the trackpad function on/off, press the **"Fn"** and **"cmd"** keys simultaneously.
- **Detachable Keyboard:** The keyboard is magnetically attached and can be removed from the case for flexible use.
- **Scissor Keys:** The keyboard features a scissor-key structure for a responsive typing experience.



Image: A user interacting with the multi-touch trackpad on the keyboard.




Image: Illustration of the detachable magnetic keyboard being separated from the case.

Adjustable Viewing Angles

The case offers three horizontal stand angle grooves, allowing you to adjust your iPad to a comfortable viewing angle (e.g., 110°, 120°, 125°). The flip magnet design at the bottom ensures stability.



Image: The keyboard case demonstrating its three adjustable viewing angles.

Pencil Holder

The case includes a built-in holder for your Apple Pencil, along with slots for the cap and adapter, ensuring secure storage and easy access.



Image: The keyboard case featuring its integrated Apple Pencil holder.

MAINTENANCE

- **Cleaning:** Use a soft, damp cloth to wipe the exterior of the case and keyboard. Avoid harsh chemicals or abrasive materials.
- **Charging:** Charge the keyboard using the provided USB-C cable. A full charge provides extended usage time.
- **Storage:** When not in use for extended periods, store the keyboard case in a cool, dry place.
- **Battery Care:** To prolong battery life, avoid fully discharging the keyboard frequently. Charge it regularly.



Image: Close-up of the USB-C charging port on the keyboard.

TROUBLESHOOTING

Issue	Solution
Keyboard not connecting via Bluetooth	Ensure the keyboard is charged and powered on. Turn off and on your iPad's Bluetooth. Forget the device in iPad Bluetooth settings and re-pair.
Trackpad not responding	Press Fn + cmd to ensure the trackpad is enabled. Check iPad settings for trackpad functionality.
Keys not responding	Check keyboard charge level. Reconnect Bluetooth. Restart your iPad.
iPad not fitting securely in case	Verify your iPad model number against the compatibility list. Ensure the iPad is aligned correctly before pressing into the case.

SPECIFICATIONS

Feature	Detail
Brand	CHESONA
Connectivity Technology	Wireless (Bluetooth)
Keyboard Description	Multi Functional, Detachable
Special Features	Rechargeable, Multi-Touch Trackpad, Pencil Holder, Adjustable Stand
Material	Plastic
Power Source	Battery Powered (1 Lithium Polymer battery included)
Keyboard Layout	QWERTY
Switch Type	Scissor-Switch
Minimum Required OS	iPadOS 13

Feature	Detail
Parcel Dimensions	26.9 x 20.5 x 3.2 cm; 810 g

WARRANTY AND SUPPORT

The CHESONA Keyboard Case comes with a **1-YEAR WARRANTY**.

For technical support, warranty claims, or further assistance, please contact CHESONA customer service. Refer to the contact information provided with your product packaging or visit the official CHESONA website.

You can also visit the [CHESONA Store on Amazon](#) for more information and product updates.