

FDW Computer Gaming L Shaped Desk

FDW 51-inch L-Shaped Computer Desk User Manual

Model: Computer Gaming L Shaped Desk

INTRODUCTION

Thank you for purchasing the FDW 51-inch L-Shaped Computer Desk. This manual provides comprehensive instructions for assembly, operation, maintenance, and troubleshooting to ensure you get the most out of your new desk. Designed for home office, gaming, and study, this desk offers ample space and a sturdy structure for various activities.

SAFETY INFORMATION

- Always follow assembly instructions carefully.
- Ensure all screws and fasteners are tightened securely before use. Periodically check and re-tighten as needed.
- Do not exceed the maximum weight recommendation of 50 kilograms (approximately 110 pounds) on the desk surface.
- Keep small parts and packaging materials away from children to prevent choking hazards.
- Place the desk on a level surface to prevent tipping. Use the adjustable feet to stabilize on uneven floors.
- Avoid placing hot items directly on the desk surface without protection.

PARTS LIST

Before beginning assembly, please verify that all components are present and undamaged. All necessary assembly tools are included with your purchase.

- Desk Panels (L-shaped sections, monitor stand)
- Steel Frame Components (legs, support bars)
- Adjustable Foot Pads
- Assembly Hardware (screws, bolts, nuts)
- Assembly Tools (e.g., Allen wrench)

SETUP AND ASSEMBLY

Assembly is required for this product. It is recommended that two people assemble the desk for ease and safety.

Step 1: Unpack and Identify Components

Carefully unpack all parts from the box. Lay them out on a clean, soft surface to prevent scratches. Refer to the included parts diagram to identify each component.



Figure 1: Desk Dimensions and Component Layout. Note the overall L-shape and the elevated monitor stand.

Step 2: Assemble the Steel Frame

Connect the various steel frame components using the provided hardware. Ensure all connections are firm but do not fully tighten screws until the entire frame is assembled. This allows for minor adjustments.

X Shape Design

X-shaped design provides more support and ensures stability and durability. No serious shaking or movement.



Adjustable Feet

Adjustable leg pads ensure the desk keep sturdy even on uneven ground.



Larger Monitor Shelf

Free to install the monitor shelf on the right or left according to your needs and habits.



Figure 2: Details of the X-shape frame design for enhanced stability and adjustable feet for leveling on uneven surfaces.

Step 3: Attach Desk Panels

Carefully place the L-shaped desk panels onto the assembled steel frame. Align the pre-drilled holes in the panels with the holes in the frame. Secure the panels using the appropriate screws. The desk features a 15mm thick desktop made from environmental grade board.

Large Size & Ample Space

This L shaped gaming desk includes necessary tools and instructions, please follow the installation instructions steps and avoid reassembly .



Figure 3: Overview of the large surface area of the L-shaped desk, highlighting its various sections and the thickness of the desktop material.

Environmental Grade Board

This L shaped gaming desk includes necessary tools and instructions, please follow the installation instructions steps and avoid reassembly .



Figure 4: Detail of the environmental grade board used for the desk's surface, ensuring durability and quality.

Step 4: Install Monitor Stand

The monitor stand can be installed on either the left or right side of the desk, according to your preference and setup. Attach the monitor stand to the main desk surface using the designated hardware. This stand helps raise your monitor to a more ergonomic viewing height.

Step 5: Final Tightening and Leveling

Once all components are in place, go back and fully tighten all screws and fasteners. Adjust the leg pads at the bottom of the desk to ensure the desk is stable and level on your floor. This prevents wobbling and ensures a sturdy workstation.

OPERATING INSTRUCTIONS

The FDW L-Shaped Computer Desk is designed for versatile use in various settings.

- **Monitor Stand Usage:** Utilize the elevated monitor stand to position your display at an ergonomic height, reducing strain on your neck and eyes.

- **Space Utilization:** The L-shaped design provides ample surface area for multiple monitors, keyboards, and other office or gaming peripherals. The corner design optimizes space in your room.
- **Multi-functional Use:** This desk is suitable for various activities including computer work, gaming, studying, and general office tasks.



Figure 5: The FDW L-Shaped Computer Desk in a typical setup, demonstrating its spacious and functional design.

Multipurpose Computer Desk

This corner desk can be used as a computer desk, kid study desk, home office desk, gaming desk and so far.



Figure 6: Illustrations of the desk's versatility for studying, gaming, and efficient office work.

MAINTENANCE

To maintain the appearance and longevity of your FDW L-Shaped Computer Desk, follow these simple care instructions:

- **Cleaning:** Wipe the desk surface and frame with a dry or damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the desktop material.
- **Stability Check:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if any looseness is detected.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which may cause fading or discoloration over time.

TROUBLESHOOTING

If you encounter any issues with your desk, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Desk is wobbly or unstable.	Loose fasteners or uneven floor.	Ensure all screws are fully tightened. Adjust the leg pads at the bottom of the desk to level it on uneven surfaces.
Parts do not align during assembly.	Incorrect orientation of parts or screws tightened too early.	Review the assembly instructions to ensure correct part orientation. Loosen all screws slightly, align parts, then re-tighten.
Monitor stand feels loose.	Screws securing the monitor stand are not tight enough.	Tighten the screws that attach the monitor stand to the main desk surface.

SPECIFICATIONS

Feature	Detail
Brand	FDW
Product Dimensions	51"D x 51"W x 30"H
Color	Vintage (Black frame, Vintage wood-look top)
Style	Modern
Base Material	Alloy Steel
Top Material Type	Glass (Tempered Glass finish)
Special Feature	Adjustable (Adjustable leg pads)
Room Type	Office
Recommended Uses	Gaming, Study, Home Office
Model Number	Computer Gaming L Shaped Desk
Model Name	Corner Desk Home Office Writing
UPC	195030034030
Item Weight	40 Pounds
Maximum Weight Recommendation	50 Kilograms (approx. 110 lbs)
Tabletop Thickness	0.24 Inches (6mm)
Minimum Height	30 Inches
Working Surface Diagonal Length	60.83 Inches
Required Assembly	Yes
Recommended Number of People for Assembly	2

Feature	Detail
Includes All Assembly Tools	Yes

WARRANTY AND SUPPORT

Manufacturer Warranty: This product comes with a 90-day manufacturer warranty from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

Customer Support: For any questions regarding assembly, missing parts, or product issues, please contact FDW customer service. Refer to your purchase documentation for specific contact details or visit the FDW brand store on Amazon.

Online Resources: For additional support and product information, you may visit the official FDW store:[FDW Store on Amazon](#).

© 2025 FDW. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question