

ABCCANOPY JS-04-10B straight with netting white

ABCCANOPY Pop-Up Canopy Tent User Manual

Model: JS-04-10B straight with netting white

1. INTRODUCTION

Thank you for choosing the ABCCANOPY Outdoor Easy Pop-Up Canopy Tent with Netting Wall. This manual provides essential information for the safe and effective use, setup, and maintenance of your canopy tent. Designed for convenience and durability, this 10x10 canopy offers ample shade and protection for various outdoor activities.



Image: The ABCCANOPY 10x10 Pop-Up Canopy Tent with Netting Wall, showcasing its overall design and mesh walls.

2. SAFETY INFORMATION

Important Safety Warning:

This product should not be left outside in wild weather, especially stormy weather. Remove the top from the frame and store it in the storage bag after drying. Note that this canopy is not water-resistant. Users should also take precautions against UV exposure, as the top has UPF 50+ protection.

Always ensure the canopy is properly secured with sandbags and fixed ropes, especially in windy conditions, to prevent shaking or collapse.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly:

- 1x Wheeled Carrying Bag & Frame
- 1x Canopy Top
- 4x Sand Bags
- 4x Ropes
- 8x Stakes

1xWheeled Bag&Frame**4 x Sand Bag****1 x Canopy Top****4 x Ropes****8 x Stakes**

Image: Visual representation of all items included in the package, including the wheeled bag, frame, canopy top, sandbags, ropes, and stakes.

4. SETUP INSTRUCTIONS

The ABCCANOPY pop-up canopy is designed for easy setup, often achievable by one person in under a minute. Follow these steps for quick assembly:

- 1. Unpack the Frame:** Remove the wheeled carrying bag and frame from the packaging. Place the frame in the desired setup location.
- 2. Expand the Frame:** With a partner or by yourself, gently pull the outer legs of the frame outwards until it begins to expand.
- 3. Attach the Canopy Top:** Drape the canopy top over the expanded frame. Ensure the corners align with the frame's legs. Secure the canopy top to the frame using the multiple Velcro straps designed inside the top cloth for effective fixing.
- 4. Extend the Legs:** Press the red button on each leg to unlock and extend the legs to your desired height. Ensure all legs are fully extended and locked into place for stability.

5. **Attach Mesh Sidewalls (Optional):** If using the mesh sidewalls, attach them to the canopy frame using the integrated zippers. These provide privacy and protection from insects.
6. **Secure the Canopy:** Fill the provided sandbags with sand or other suitable material and attach them to the canopy legs. Use the ropes and stakes to further secure the canopy to the ground, especially in windy conditions. This is crucial for stability and safety.

Your browser does not support the video tag.

Video: Official ABCCANOPY demonstration of the easy pop-up canopy tent, including setup and durability tests against wind and rain.



Image: The ABCCANOPY tent set up in a backyard, providing shade for a gathering around a table.

5. OPERATING YOUR CANOPY TENT

Your ABCCANOPY tent is designed for versatile use in various outdoor settings:

- **Shade and Protection:** The 10x10 instant canopy provides 100 square feet of shade, comfortably accommodating 6-8 people. The top features an upgraded silver coating inside, blocking 99.99% of the sun's harmful UV rays.
- **Private & Comfortable Space:** The four removable zippered mesh sidewalls offer protection from sun and rain, enhance privacy, and allow for fresh airflow while keeping out insects.
- **Portability:** When not in use, the canopy can be easily folded and stored in its 600x300D wheeled carrying bag, fitting into most car trunks for convenient transport.

Features

Uniqueness And Specific Details

Zipper for easy opening and closing the netting wall, enclosing the netting walls for keeping out the bugs, flyings.



1.Strength and Thickened Rust-proof Leg



2.Silver Coating for UV Protection



2.Durable Water Resistance Fabric

Image: Detailed view of key features: zippered mesh walls for insect protection, strength and thickened rust-proof legs, silver coating for UV protection, and durable water-resistant fabric.

6. MAINTENANCE

Proper maintenance will extend the life of your canopy tent:

- Cleaning:** Clean the canopy fabric with mild soap and water. Do not use harsh chemicals or abrasive cleaners. Rinse thoroughly and allow to air dry completely before storage.
- Drying Before Storage:** Always ensure the canopy top and frame are completely dry before folding and storing them in the carrying bag. This prevents mold, mildew, and rust.
- Frame Care:** The high-grade steel frame is powder-coated to prevent chipping, peeling, rust, and corrosion. Periodically inspect the frame for any signs of damage or wear.
- Storage:** Store the canopy in its wheeled carrying bag in a cool, dry place away from direct sunlight when not in use.

7. TROUBLESHOOTING

If you encounter issues with your canopy tent, refer to the following common solutions:

Problem	Possible Cause	Solution
Canopy shaking in wind	Insufficient anchoring.	Ensure sandbags are filled and attached, and ropes are securely staked to the ground. Do not use in strong winds without proper anchoring.
Water leakage from top	Canopy is not fully waterproof; heavy rain.	The canopy is designed to prevent leakage in rainy days due to its sloped surface, but it is not fully water-resistant. Avoid leaving it out in heavy or prolonged rain.
Difficulty expanding/collapsing frame	Legs not properly aligned or locked.	Ensure all locking mechanisms are disengaged before collapsing and fully engaged when expanding. Apply even pressure.

8. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	ABCCANOPY
Model Number	JS-04-10B straight with netting white
Product Dimensions	120 x 120 x 111.6 inches (10x10 ft base)
Item Weight	34 Pounds
Material	Nylon (Canopy), Alloy Steel (Frame)
Color	White
UV Protection	99.99% (UPF 50+)
Water Resistance Level	Not Water Resistant (Treated with waterproof design to prevent leakage in rainy days)
Coverage Area	100 square feet
Recommended Uses	Party, Picnic, Camping, Outdoor Activities
Assembly Required	No (Pop-up design)
UPC	840109907172

DIMENSIONS

8FTx8FT Pop Up Canopy



Image: Diagram illustrating the dimensions of the 10x10 pop-up canopy, showing height and base measurements.

9. WARRANTY AND SUPPORT

ABCCANOPY stands behind the quality of its products:

- **Frame Warranty:** Enjoy one year of after-sale protection for the canopy frame.
- **Fabric and Accessories Warranty:** A six-month after-sale protection is provided for fabrics and accessories.

For any questions, concerns, or warranty claims, please contact ABCCANOPY customer service through the retailer's platform or the official ABCCANOPY website. Please have your model number and purchase date ready when contacting support.

