

[Manuals.plus](#) /

› [Fisher-Price](#) /

› Fisher-Price Luminate Bassinet Instruction Manual

Fisher-Price GHP38

Fisher-Price Luminate Bassinet Instruction Manual

MODEL: GHP38

Introduction

The Fisher-Price Luminate Bassinet is a bedside sleeper designed to provide a soothing environment for newborns. It features a built-in Smart Sensing System that detects a baby's cries and responds with customizable lights, music, white noise, and vibrations. These features can be controlled directly from the bassinet or via a smart device using the Smart Connect app.

Key features include:

- Built-in sound detection with three soothing response modes.
- Customizable lights, music, white noise, and vibrations.
- Controllable via the Smart Connect app (note: app support may be discontinued by June 2025).
- Motion-activated floor light for nighttime check-ins.
- Soft amber crib light.
- Machine-washable mattress sheet and wipeable mattress pad.

Important Safety Information

Please read and understand all instructions before assembly and use. Keep these instructions for future reference.

- **Maximum Weight:** This bassinet is intended for use with a child weighing up to 20 lb (9 kg).
- **Developmental Stage:** Use only with a child who is unable to push up on hands and knees, pull up, or sit unassisted. Discontinue use when your child reaches any of these milestones.
- **Suffocation Hazard:** To prevent suffocation, never use additional padding, blankets, or pillows in the bassinet. Only use the mattress pad provided by the manufacturer.
- **Strangulation Hazard:** Keep cords and small parts away from children. Ensure all assembly is secure and no loose parts are accessible.
- **Stability:** Always place the bassinet on a firm, horizontal surface. Never use the bassinet if any parts are missing or broken.
- **Supervision:** Never leave your child unattended in the bassinet.

Setup

Assembly of the Fisher-Price Luminate Bassinet is designed to be straightforward. While specific step-by-step instructions are provided in the packaging, here is a general overview:


1. Unpack all components and verify against the parts list in your product manual.
2. Assemble the bassinet frame, ensuring all connections are secure.
3. Attach the mesh sides and secure them to the frame.
4. Insert the mattress pad and cover it with the machine-washable sheet.
5. Connect the AC adapter to the bassinet and plug it into a wall outlet.

Refer to the detailed diagrams and instructions included in your product packaging for precise assembly steps.

Operating Instructions

The Luminate Bassinet offers various features to soothe your baby. These can be controlled via the integrated control panel or the Smart Connect app.

Control Panel Overview



Soothe baby to sleep with music, sounds & vibrations

Image: Close-up of the bassinet's control panel, showing illuminated icons for various functions.

1. **Power On/Off:** Press the power button () on the control panel to turn the bassinet on or off.
2. **Smart Connect App:** Download the free Smart Connect app to your smart device for remote control and customization. **Important Note:** According to manufacturer information, support for the Smart Connect app is scheduled to be discontinued by June 2025. After this date, app functionality may cease, and features will only be controllable via the bassinet's physical control panel.




Image: A smartphone screen showing the Smart Connect app controlling the bassinet.

3. **Smart Sensing System:** The bassinet features a built-in sensor that detects your baby's cries. When activated, it can automatically respond with a combination of music, sounds, and vibrations to help soothe your baby. There are three response modes, each with a pre-set soothing combination, including the 20-minute Ready, Settle, Sleep playlist.



Smart Sensing System can detect baby's cries

Image: A baby sleeping in the bassinet with a soft internal light, demonstrating the Smart Sensing System.

4. Music, Sounds, and Vibrations:

- Select from various musical playlists or nature sounds. You can also create a custom playlist with 10 included songs via the app (subject to app availability).
- Adjust the volume using the dedicated volume buttons on the control panel.
- Choose from 3 levels of soothing vibrations.

5. Lights:

- **Motion-Activated Floor Light:** A gentle floor light automatically turns on when you approach the bassinet, illuminating your path for nighttime check-ins without disturbing your baby.
- **Soft Amber Crib Light:** A soft light inside the bassinet provides illumination for easy nighttime check-ins and feedings.



Motion-activated floor light helps with nighttime check-ins

Image: A parent standing near the bassinet, showing the motion-activated floor light in action.

6. **Timer Settings:** Set an auto shut-off timer for up to 2 hours, or select continuous play for uninterrupted soothing. This can be adjusted via the control panel or the app.

Product Demonstration Video

Your browser does not support the video tag.

Video: An official demonstration of the Fisher-Price Luminate Bassinet, showcasing its features and functionality.

Maintenance

- **Mattress Sheet:** The mattress sheet is machine-washable. Follow the care instructions on the label for best results.
- **Mattress Pad:** The mattress pad is wipeable. Clean with a damp cloth and mild soap. Allow to air dry completely before reinserting into the bassinet.
- **Frame and Mesh:** Wipe the bassinet frame and mesh sides with a damp cloth and mild soap. Do not use abrasive cleaners or harsh chemicals.
- **Storage:** When not in use, store the bassinet in a clean, dry place, away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
Bassinet does not power on.	AC adapter not properly connected or power outlet issue.	Ensure the AC adapter is securely plugged into both the bassinet and a working wall outlet. Try a different outlet.
Smart Connect app not connecting or functioning.	Bluetooth connectivity issues, app compatibility, or app decommissioning.	Ensure Bluetooth is enabled on your device and the bassinet is within range. Restart both the app and the bassinet. Note that the app is scheduled for discontinuation by June 2025; after this, app functionality will cease.
Motor makes unusual noise (e.g., "rusty swing" sound) during vibration or white noise.	Potential motor wear or internal component issue.	Reduce vibration intensity. If the noise persists or worsens, discontinue use of the vibration feature and contact customer support.
Assembly parts (e.g., arm supports) are difficult to secure or come loose.	Misalignment during assembly or manufacturing variation.	Carefully re-align parts and ensure screws are properly threaded. Do not overtighten. If parts cannot be securely fastened, discontinue use and contact customer support.
White noise has a faint background or glitching sound.	Internal speaker or sound module issue.	Try adjusting the volume. If the issue persists, consider using an external sound machine if the sound quality is disruptive. Contact customer support if the issue significantly impacts usability.

Specifications



Image: Diagram illustrating the dimensions of the Luminate Bassinet.

- **Brand:** Fisher-Price
- **Model Number:** GHP38
- **UPC:** 887961799316
- **Maximum Weight Recommendation:** 9 kg (20 lb)
- **Material Type:** Mesh, Plastic, Steel
- **Item Dimensions (L x W x H):** 36" x 22" x 32" (91.4 cm x 55.9 cm x 81.3 cm)
- **Item Weight:** 7.68 ounces (0.22 kg)
- **Included Components:** Bassinet
- **Care Instructions:** Machine Wash (sheet), Wipe Clean (pad, frame)

Warranty and Support

For information regarding product warranty, please refer to the warranty card included with your purchase or visit the official Fisher-Price website. If you encounter any issues not covered in this manual or require further assistance, please contact Fisher-Price customer support directly.

You can typically find contact information on the product packaging or the official brand website:

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08XVRJ2Q8>

More documents and user manuals: <https://manuals.plus/>