

[Manuals.plus](#) /

› [WLIVE](#) /

› WLIVE Floor-Standing TV Stand ADSJ613LSM Instruction Manual

WLIVE ADSJ613LSM

WLIVE Floor-Standing TV Stand Instruction Manual

Model: ADSJ613LSM

1. INTRODUCTION

Thank you for purchasing the WLIVE Floor-Standing TV Stand, Model ADSJ613LSM. This manual provides detailed instructions for assembly, operation, and maintenance to ensure safe and optimal use of your new TV stand. Please read this manual thoroughly before installation and retain it for future reference.



This image shows the WLIVE Floor-Standing TV Stand with a 55-inch television mounted, demonstrating its modern aesthetic and space-saving design in a typical living room environment.

2. SAFETY INFORMATION

Please observe the following safety precautions to prevent injury or damage to the product:

- Read all instructions before assembly and use.
- Do not exceed the maximum load capacity of 40kg for the TV and 10kg for the shelf.
- Ensure the TV stand is placed on a stable, level surface.
- Assemble the product with at least two people to prevent injury, especially when handling heavy components.
- Use the included anti-tip wire to secure the stand to a wall, especially in households with children or in earthquake-prone areas.
- Keep children and pets away from the assembly area.
- Do not modify the product in any way.

- Periodically check all screws and connections to ensure they remain tight.



転倒防止ワイヤー付き
子供のいたずらや地震対策
にも最適です。

This image illustrates the included anti-tip wire, a safety feature designed to prevent accidental tipping, making the stand safer for households with children and providing stability during minor tremors.

3. PACKAGE CONTENTS

Before beginning assembly, ensure all parts are present and undamaged. Refer to the assembly diagram for a complete list of components and hardware.

- Base Plate
- Central Support Column
- TV Mounting Bracket
- Adjustable Shelf
- Hardware Kit (screws, washers, nuts, anti-tip wire)
- Assembly Tools (e.g., Allen wrench)
- Instruction Manual

4. SETUP AND ASSEMBLY

Follow these steps carefully for proper assembly. It is recommended to have two people for assembly.

4.1 TV Compatibility Check

Before assembly, verify your TV's compatibility with the stand:


- **Screen Size:** Compatible with 32 to 65-inch TVs.
- **Weight Capacity:** Your TV must not exceed 40kg (88 lbs).
- **VESA Pattern:** The TV must have VESA mounting holes. Compatible patterns include:
 - Horizontal (A): 10cm, 20cm, 30cm, 40cm, 50cm, 60cm
 - Vertical (B): 10cm to 40cm
- **TV Back Design:**
 - Rear speakers must be 2cm (0.8 inches) or less in thickness.
 - The distance from the LCD screen to the four screw holes must be uniform.
 - Avoid TVs with non-removable legs or significant protrusions near the VESA mounting holes.

取り付けについて

取り付け可能なテレビ

対応サイズ: **32～65インチ** 耐荷重: **40kgまで**


- 壁掛け用のネジ穴が4点あり、
穴の間隔が下記A・Bの条件を満たしている



A = 10・20・30・40・50・60cm
(いずれかに該当)


B = 10～40cmの範囲内

- 背面スピーカーの厚さが**2cm**以下



- 液晶画面からネジ穴までの距離が**4点**同じ

凸物に
ネジ穴が
あるタイプ



背面が平な
タイプ




取り付け不可なテレビ


× ネジ穴が4点内

× 脚（スタンド）が外せない

× 液晶画面から穴までの距離が異なる



× ネジ穴の間、または下側にでっぱりがある




This diagram provides crucial information for TV compatibility. It specifies that the stand supports TVs from 32 to 65 inches, with a maximum weight of 40kg. It details compatible VESA patterns (A=10-60cm, B=10-40cm) and conditions for the TV's rear design, such as rear speaker thickness (under 2cm) and uniform distance from the screen to screw holes. It also illustrates types of TVs that are not compatible, such as those with non-removable legs or protrusions near VESA holes.

4.2 Assembly Steps (General Overview)

- 1. Attach the Central Support Column to the Base:** Secure the main vertical column to the base plate using the provided screws.
- 2. Install the Adjustable Shelf:** Attach the shelf to the central column at your desired height. The shelf can be adjusted in 5cm increments.
- 3. Assemble the TV Mounting Bracket:** Attach the horizontal bracket arms to the vertical TV mounting plate.
- 4. Attach Mounting Bracket to TV:** Secure the assembled TV mounting bracket to the back of your television using the appropriate VESA screws and spacers. Ensure a snug fit without overtightening.
- 5. Mount TV to Stand:** Carefully lift the TV with the attached bracket and hook it onto the central support column. Secure it with the safety locks.
- 6. Cable Management:** Route all TV and device cables through the designated cable management channels in the central column for a tidy appearance.
- 7. Install Anti-Tip Wire:** Attach one end of the anti-tip wire to the TV stand and the other end to a wall stud or suitable

anchor point.

5CMピッチ5段階ラック高さ調節



This image provides a detailed dimensional overview of the TV stand. It shows the overall height adjustable from 107cm to 131cm, with the TV mounting bracket measuring 60cm wide and 42cm high. The maximum load capacity for the TV is 40kg, and for the shelf, it is 10kg. The shelf height is adjustable in 5cm increments.

5. OPERATING INSTRUCTIONS

5.1 Adjusting Shelf Height

The accessory shelf can be adjusted to different heights to accommodate various media devices. To adjust, loosen the securing screws on the central column, slide the shelf to the desired position (in 5cm increments), and re-tighten the screws firmly.

5CMピッチ5段階 棚高さ調節




This diagram illustrates the adjustable shelf feature of the TV stand. The shelf height can be adjusted in 5cm increments, with a maximum height of 48.5cm and a minimum of 23.5cm from the base. The shelf dimensions are 58cm wide and 29cm deep, with the base measuring 75cm by 33cm.

5.2 Swivel Function

The TV mounting bracket allows for a 25-degree swivel to the left or right. Gently rotate the TV to achieve your preferred viewing angle. Do not force the rotation beyond its limits.

横からも見やすい25°回転

✕見づらい



○見やすい




This image highlights the TV stand's ability to swivel 25 degrees left or right, allowing for optimal viewing angles from various positions in a room. The 'X' indicates a fixed view, while the 'O' shows the improved viewing with rotation.

5.3 Cable Management

Utilize the integrated cable management system by routing all power and AV cables through the central column. This helps maintain a clean and organized appearance.

配線をきれいに背面収納



This image demonstrates the integrated cable management feature. Cables can be neatly routed and concealed within the central column of the stand, as shown by the 'before storage' inset, to maintain a tidy appearance.

6. MAINTENANCE

- **Cleaning:** Wipe the stand with a soft, dry cloth. For stubborn marks, use a slightly damp cloth and mild detergent, then dry immediately. Avoid abrasive cleaners or solvents.
- **Inspection:** Periodically check all bolts and screws to ensure they are tight. Re-tighten if necessary.
- **Damage:** If any part of the stand is damaged, discontinue use and contact customer support for replacement parts.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Stand feels unstable.	Loose screws; uneven floor; TV weight exceeds capacity.	Check and tighten all screws. Move to a level surface. Ensure TV weight is within 40kg limit. Install anti-tip wire.
TV cannot be mounted.	Incorrect VESA pattern; TV too large/heavy; TV back design incompatible.	Verify TV size, weight, and VESA pattern against specifications (32-65 inches, max 40kg, VESA A=10-60cm, B=10-40cm). Check for protrusions on TV back.
Shelf cannot be adjusted.	Securing screws are too tight; obstruction.	Loosen the securing screws completely. Check for any foreign objects obstructing movement.

8. SPECIFICATIONS

Feature	Detail
Model Number	ADSJ613LSM
Brand	WLIVE
Mounting Type	Floor Mount
Material	Alloy Steel, Wood Grain Finish
Compatible TV Sizes	32 - 65 inches
Maximum TV Load Capacity	40 kg (88 lbs)
Maximum Shelf Load Capacity	10 kg (22 lbs)
VESA Compatibility	Horizontal: 100-600mm, Vertical: 100-400mm
Swivel Angle	±25 degrees
Shelf Height Adjustment	5-step, 5cm increments (Min 23.5cm, Max 48.5cm from base)
Overall Height Adjustment	107cm - 131cm

9. WARRANTY AND SUPPORT

WLIVE products are designed for durability and performance. For warranty information, please refer to the warranty card included with your purchase or visit the official WLIVE website. If you encounter any issues or have questions regarding your TV stand, please contact WLIVE customer support through the retailer where you purchased the product or via the contact information provided on the WLIVE website.

Please have your model number (ADSJ613LSM) and purchase details ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question