

[Manuals.plus](#) /

› [HUMSURE](#) /

› HUMSURE 4500 Sq. Ft Dehumidifier User Manual

HUMSURE 4500 Sq. Ft Dehumidifier for Basements

HUMSURE 4500 Sq. Ft Dehumidifier User Manual

Model: 4500 Sq. Ft Dehumidifier for Basements

Brand: HUMSURE

1. INTRODUCTION

This manual provides comprehensive instructions for the safe and efficient operation, maintenance, and troubleshooting of your HUMSURE 4500 Sq. Ft Dehumidifier. Please read this manual thoroughly before using the appliance and retain it for future reference.

2. SETUP AND INSTALLATION

2.1 Unboxing and Placement

Carefully remove the dehumidifier from its packaging. Place the unit upright on a flat, stable surface in the area where dehumidification is desired. Ensure there is at least 8 inches of space around the unit for proper airflow.



Figure 2.1: HUMSURE 4500 Sq. Ft Dehumidifier with included drainage hose.

2.2 Drainage Methods

Your dehumidifier offers two drainage options: manual drainage using the water tank or continuous drainage with the included hose.

- **Manual Drainage:** The unit will collect moisture in its internal 5-liter water tank. When the tank is full, the unit will automatically shut off and an indicator light will illuminate. Empty the tank and reinsert it to resume operation.
- **Continuous Drainage:** For extended use without manual emptying, attach the provided drainage hose to the continuous drain outlet. Ensure the hose is sloped downwards to allow gravity to drain water directly into a floor drain or suitable receptacle.

Alternative Drainage Methods



CONTINUOUS
DRAINAGE WITH HOSE



MANUAL DRAINAGE
WITH
WATER TANK

2 ways



Figure 2.2: Illustration of continuous and manual drainage options.

2.3 Drainage Hose Installation Guide

Your browser does not support the video tag.

Video 2.1: Demonstrates how to install the drainage hose for continuous operation of the HUMSURE dehumidifier in a basement bathroom setting.

3. OPERATING INSTRUCTIONS

3.1 Control Panel Overview

The dehumidifier features an intuitive control panel on its top surface, allowing easy access to all functions. The digital

display shows the current humidity level.



Figure 3.1: Detailed view of the dehumidifier's easy-to-use control panel.

3.2 Modes and Settings

- **Power Button:** Turns the unit on or off.
- **Humidity Button:** Set your desired humidity level (e.g., 40%-80% RH) under standard mode. The unit will operate until the set humidity is reached.
- **Speed Button:** Adjusts the fan speed (High, Medium, Low) for different dehumidification needs.
- **Timer Button:** Predetermine the timing of auto start/stop from 0-24 hours.
- **Drying Mode:** Activates continuous dehumidification at high fan speed for faster drying, ideal for laundry. Humidity and fan speed cannot be adjusted in this mode.
- **Ionizer:** Releases negative ions to purify the air.
- **Child Lock:** Prevents accidental changes to settings.

Smart Temperature & Humidity Sensor

Dual NTC probe for precise temp and humidity sensing



Figure 3.2: Smart Temperature & Humidity Sensor ensures precise control.

3.3 Working Modes Overview

The dehumidifier supports various working modes to suit different environments and needs.



Figure 3.3: Three distinct working modes for versatile use.

3.4 Product Features in Action

Your browser does not support the video tag.

Video 3.1: Overview of the HUMSURE 4500 Sq. Ft Dehumidifier's features, including moisture removal capabilities and various operational modes.

4. MAINTENANCE

4.1 Cleaning the Air Filter

Regular cleaning of the air filter is crucial for maintaining the dehumidifier's efficiency and prolonging its lifespan. A dirty filter can restrict airflow and reduce performance.

- Turn off the dehumidifier and unplug it from the power outlet.
- Remove the air filter from the back of the unit.
- Wash the filter with warm, soapy water. Rinse thoroughly and allow it to air dry completely before reinserting.
- Reinsert the dry filter and plug in the unit.



Figure 4.1: The washable intake grille ensures fresh air and easy maintenance.

4.2 Emptying the Water Tank

If you are not using the continuous drainage option, the water tank will need to be emptied periodically.

- When the "Full" indicator light illuminates, gently pull out the water tank from the rear of the unit.
- Carefully carry the tank to a sink or drain and pour out the collected water.
- Wipe the inside of the tank clean with a soft cloth if necessary.
- Slide the empty tank back into the dehumidifier until it clicks into place. The unit will resume operation.

5. TROUBLESHOOTING

Before contacting customer support, please refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Dehumidifier does not turn on.	No power supply; Water tank full or incorrectly inserted.	Check power cord connection and outlet; Empty and correctly reinsert water tank.
Unit is running but not collecting water.	Room temperature too low; Humidity level already low; Air filter clogged.	Dehumidifiers operate best above 41°F (5°C); Check desired humidity setting; Clean the air filter.
Unit is noisy.	Unit not on a level surface; Air filter clogged.	Place unit on a flat, stable surface; Clean the air filter.
Water leaking from the unit.	Continuous drain hose improperly connected or clogged; Water tank damaged.	Check hose connection and ensure it's not kinked; Inspect water tank for cracks.

6. SPECIFICATIONS

Feature	Detail
Brand	HUMSURE
Model Name	4500 Sq. Ft Dehumidifier for Basements
Floor Area Coverage	4500 Square Feet
Moisture Removal Capacity	70 Pints (per day)
Tank Volume	5 Liters
Product Dimensions	10.55"D x 14.96"W x 20.47"H
Number of Speeds	2
Special Feature	Auto Shut-off
Color	White
Recommended Uses	Home, Basements

7. WARRANTY AND SUPPORT

For warranty information or technical support, please contact HUMSURE customer service. Keep your purchase receipt as proof of purchase for any warranty claims.

- Visit the official HUMSURE website for the most up-to-date support information and contact details.
- Refer to the product packaging or included warranty card for specific warranty terms and conditions.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question