Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZoneFly B08XXJZR9B

ZoneFly Silicone Reusable Air Fryer Liners Instruction Manual

Introduction

The ZoneFly Silicone Reusable Air Fryer Liners are designed to enhance your air frying experience by protecting your air fryer basket and preventing food from sticking. These heat-resistant, non-stick mats offer a sustainable alternative to disposable parchment paper or aluminum foil. Their perforated design ensures optimal air circulation for even cooking.



Image: Key features of the ZoneFly Silicone Reusable Air Fryer Liners, highlighting compatibility, heat resistance, and ease of cleaning.

Setup and First Use

1. **Unpack:** Carefully remove the silicone liners from their packaging.
2. **Initial Cleaning:** Before the first use, thoroughly wash the silicone liners with warm soapy water. Alternatively, they can be placed in a dishwasher for cleaning.
3. **Drying:** Ensure the liners are completely dry before placing them into your air fryer basket or using them for cooking.

Operating Instructions

Using with an Air Fryer

1. **Placement:** Place one silicone liner flat at the bottom of your air fryer basket. Ensure it fits properly and does not curl up the sides excessively.
2. **Food Placement:** Add your food directly onto the silicone liner.
3. **Airflow:** The perforated design of the liner is engineered to maintain optimal airflow around your food, promoting even cooking. Avoid overcrowding the basket.
4. **Temperature:** These liners are heat resistant up to 450°F (232°C), suitable for most air frying temperatures.

Versatile Use

- **Oven and Microwave:** The liners can also be safely used in conventional ovens and microwaves.

- **Trivet/Heat Pad:** Their flexible and heat-resistant nature makes them suitable for use as trivets or heat dissipating pads for hot pans or dishes.



Image: Diagram illustrating the 8.78-inch diameter of the liner and its compatibility with various air fryer and Instant Pot models.



Image: The silicone liner demonstrating its anti-scald and heat insulation function when used under a hot pan.

Care and Maintenance

- **Cleaning:** After each use, allow the liner to cool completely. Wash it with warm soapy water using a soft sponge or cloth. The flexible material facilitates easy cleaning.
- **Dishwasher Safe:** For convenience, the silicone liners are dishwasher safe. Place them on the top rack for best results.
- **Drying:** Ensure the liners are thoroughly dry before storing to prevent moisture buildup.
- **Storage:** Store the liners in a clean, dry place. They can be rolled or folded for compact storage.
- **Staining:** It is normal for silicone products to develop stains over time, especially after cooking foods with strong pigments (e.g., tomato-based sauces, turmeric, or certain vegetables). This staining does not affect the liner's performance, safety, or non-stick properties.

Troubleshooting

- **Food Sticking:** While designed to be non-stick, some foods may still adhere slightly. Ensure the liner is clean before use. A light spray of cooking oil on the liner before adding food can further enhance non-stick performance.
- **Liner Staining:** As mentioned in maintenance, staining is a common characteristic of silicone with certain foods. This is cosmetic and does not affect the liner's functionality or food safety.
- **Liner Does Not Fit:** Verify the inner dimensions of your air fryer basket. These liners have an 8.78-inch diameter and are compatible with air fryers having an inner size less than 5.7QT, 3.7QT, 5.7QT, and Instant Pot 6QT series. If your appliance is larger or smaller, the fit may not be optimal.

Product Specifications

Brand	ZoneFly
Model (ASIN)	B08XXJZR9B
Material	100% BPA-free Food-Grade Silicone
Diameter	8.78 inches
Heat Resistance	Up to 450°F (232°C)
Compatibility	Air fryers with inner size less than 5.7QT, 3.7QT, 5.7QT; Instant Pot 6QT series
Package Dimensions	7.87 x 7.87 x 0.55 inches
Item Weight	2.39 ounces

UPC	657835378660

Image: Details on the premium food-grade silicone material used for the liners, emphasizing its quality and safety.

Warranty and Support

Warranty: ZoneFly stands by the quality of its products. If you are not 100% satisfied with your ZoneFly kitchen accessories, please reach out to ZoneFly for warranty coverage.
Customer Support: For further assistance, product inquiries, or to claim warranty, please visit the official ZoneFly store on Amazon: ZoneFly Amazon Store.

© 2024 ZoneFly. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08XXJZR9B

More documents and user manuals: **https://manuals.plus/**