

# Invicta Men's Specialty Silicone Quartz Watch 35687 Instruction Manual

## INTRODUCTION

Welcome to the instruction manual for your new Invicta Men's Specialty Silicone Quartz Watch, Model 35687. This guide provides essential information on the features, setup, operation, and maintenance of your timepiece to ensure optimal performance and longevity. Please read this manual thoroughly before using your watch.

## PRODUCT FEATURES

- **Case:** Gunmetal stainless steel, 45mm diameter, 12.5mm thick.
- **Dial:** Gunmetal with luminous hands for enhanced visibility in low light.
- **Movement:** Reliable Japanese quartz movement (PC21J Caliber), assembled in Japan.
- **Battery:** SR626SW battery included.
- **Weight:** Approximately 100 grams.
- **Band:** Comfortable black silicone band, 235mm length, 22mm width, secured with a buckle clasp.
- **Crystal:** Durable Flame Fusion crystal, designed for scratch resistance.
- **Crown:** Push/pull crown for time adjustment.
- **Bezel:** Stationary stainless steel bezel with a rose gold and black top ring.
- **Water Resistance:** 100 meters (330 feet).

## The Invicta Specialty Quartz 35687



**Image:** An exploded view diagram highlighting specific features of the Invicta Specialty Watch 35687, such as the stainless steel rose gold case, scratch-resistant Flame Fusion crystal, fixed bezel, and crown for time adjustment.

### SETUP

Your Invicta watch is designed for straightforward use. Upon receiving your watch, you may need to perform a simple setup to ensure accurate timekeeping.

- 1. Unpacking:** Carefully remove the watch from its packaging.
- 2. Crown Protection:** Some watches come with a plastic stopper under the crown to preserve battery life. Gently pull out and remove this stopper if present.

3. **Initial Time Setting:** Proceed to the "Operation - Setting the Time" section to set the correct time.

## OPERATION - SETTING THE TIME

---

To set the time on your Invicta Specialty Quartz Watch:

1. **Pull the Crown:** Locate the crown on the right side of the watch case. Gently pull the crown outwards to the first position.
2. **Adjust the Time:** Rotate the crown either clockwise or counter-clockwise to move the hour and minute hands to the desired time.
3. **Push the Crown Back:** Once the correct time is set, push the crown back into its original position against the watch case. This will start the watch movement.



**Image:** A close-up view of the Invicta Men's Specialty Watch Model 35687 being worn on a wrist, showcasing its gunmetal case, black dial, and silicone band, illustrating typical watch wear.

## MAINTENANCE

Proper care will help maintain the appearance and function of your Invicta watch.

- **Cleaning:** Wipe the watch case and crystal with a soft, damp cloth. For the silicone band, mild soap and water can be used, then rinse thoroughly and dry. Avoid harsh chemicals.
- **Battery Replacement:** The watch uses an SR626SW battery. When the watch stops or the second hand begins to jump erratically, it indicates a low battery. Battery replacement should be performed by a professional.

qualified watch technician to ensure proper sealing and water resistance.

- **Storage:** When not in use, store your watch in a cool, dry place, away from direct sunlight and extreme temperatures. The original watch box (as shown below) is ideal for storage.

## Gift Ready Watch Box

Watch box may come in a **different color & style**



**Image:** An image of the Invicta watch presented in its yellow and black gift-ready box, suitable for storage or gifting.

### WATER RESISTANCE GUIDELINES

Your Invicta Specialty Watch 35687 is water resistant to 100 meters (330 feet). This rating indicates that the watch is suitable for recreational surfing, swimming, snorkeling, sailing, and water sports. It is **not suitable for diving**.

- Always ensure the crown is fully pushed in before exposing the watch to water.
- Do not operate the crown while the watch is wet or submerged.
- Avoid exposing the watch to hot water, steam, or sudden temperature changes, as this can compromise the water seals.
- After exposure to saltwater, rinse the watch with fresh water and dry it thoroughly.

## Specialty Collection


**100 Meters / 330 feet**



**Image:** The Invicta Specialty Watch 35687 displayed with a background suggesting water, emphasizing its 100-meter water resistance capabilities.

### SPECIFICATIONS

Feature	Detail
Model Number	35687
Case Material	Gunmetal Stainless Steel
Case Diameter	45mm
Case Thickness	12.5mm
Dial Color	Gunmetal
Movement Type	Japanese Quartz (PC21J Caliber)
Band Material	Black Silicone
Band Length	235mm
Band Width	22mm
Crystal Type	Flame Fusion
Water Resistance	100 meters (330 feet)
Watch Weight	100 grams (3.53 ounces)
Battery Type	SR626SW (included)



**Image:** Diagram illustrating the key dimensions of the Invicta Specialty Watch 35687, including dial diameter (45mm), strap length (235mm), band width (22mm), and watch weight (100g).

## TROUBLESHOOTING

If you encounter any issues with your watch, please refer to the following common solutions:

- **Watch Not Running:** Check if the crown is fully pushed in. If it is, the battery may need replacement.
- **Incorrect Time:** Ensure the crown is fully pushed in after setting the time. If the time continues to be inaccurate, the movement may require inspection.

- **Condensation Under Crystal:** This can indicate a breach in the water resistance. Avoid further water exposure and have the watch inspected by a professional immediately.

## WARRANTY AND SUPPORT

For information regarding your watch's warranty, please refer to the warranty card included with your purchase or visit the official Invicta website. For further assistance or service, please contact Invicta customer support.



**Image:** The official logo for the Invicta Specialty Collection, representing the brand's commitment to quality.