

YISSVIC B08XYQR8Z

YISSVIC 2.4-inch Wireless Baby Monitor

Model: B08XYQR8Z - Instruction Manual

INTRODUCTION

Thank you for choosing the YISSVIC 2.4-inch Wireless Baby Monitor. This manual provides essential information for the safe and efficient operation of your device. Please read it thoroughly before use and retain it for future reference. This monitor utilizes 2.4GHz wireless digital transmission, ensuring a secure and private connection without the need for Wi-Fi.

PACKAGE CONTENTS

- Baby Monitor Unit (Parent Unit)
- Baby Camera Unit (Baby Unit)
- Power Adapter for Monitor
- Power Adapter for Camera
- User Manual

SETUP

1. Camera Placement

Place the baby camera unit in a location that provides a clear view of your baby. Ensure it is at least 1 meter (3 feet) away from the baby to prevent entanglement with the power cord. The camera features a 360° adjustable angle for optimal positioning. Avoid placing the camera near other electronic devices that may cause interference.



Image: Camera and Monitor Dimensions with 360° Adjustable Camera Angle.

2. Powering On

1. Connect the camera unit to a power outlet using its dedicated power adapter. The camera will power on automatically.
2. Connect the monitor unit to a power outlet using its dedicated power adapter. Press and hold the power button on the monitor to turn it on.
3. The camera and monitor are pre-paired from the factory. The monitor should automatically display the camera's video feed. If not, refer to the 'Troubleshooting' section for pairing instructions.

OPERATING INSTRUCTIONS

1. Basic Monitoring

Once powered on, the monitor will display live video from the camera. You can adjust the screen brightness and volume on the monitor unit using the dedicated buttons.

2. Two-Way Audio Communication

The monitor features a two-way audio function, allowing you to speak to your baby through the camera's speaker. Press and hold the talk button on the monitor to speak. Release the button to hear your baby.

双方向音声

モニターから離れている赤ちゃんに話しかける。



Image: Two-Way Audio feature in use.

3. ECO Mode (VOX)

Activate ECO mode to conserve battery power. In this mode, the monitor screen will turn off, and the audio will be muted. The monitor will automatically activate (screen on, audio on) when it detects sound above a certain threshold from the baby's room, such as crying.



エコモード

赤ちゃんの泣き声に反応し、
モニターが自動で起動します。



Image: ECO Mode (VOX) activation based on baby's sound.

4. Night Vision

The camera is equipped with automatic infrared night vision. When the ambient light is low, the camera will automatically switch to night vision mode, providing a clear black and white image on the monitor.

暗視機能を搭載
夜もばっちり見守ります。




Image: Automatic Night Vision function.

5. Zoom Function

The monitor features a 2x digital zoom function. Use the dedicated zoom button on the monitor to magnify the image for a closer view of your baby.



Image: 2x Digital Zoom function.

6. Lullabies

The camera has built-in lullabies. You can play these melodies from the camera unit to soothe your baby. Use the music button on the monitor to control playback and adjust the volume.

子守歌機能



Image: Lullaby feature in action.

7. Multi-Camera Support

The system supports connecting up to four cameras (sold separately) simultaneously. The monitor can automatically cycle through the camera feeds, allowing you to monitor multiple rooms or angles.



Image: Overview of features including multi-camera support.

8. Additional Features

- **Temperature Monitoring:** The camera unit includes a temperature sensor, and the monitor displays the room temperature.
- **Feeding Timer:** Set reminders for feeding times directly from the monitor unit.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the camera and monitor units. Do not use liquid cleaners or aerosols.
- **Battery Care:** The monitor unit contains a rechargeable lithium-ion battery. For optimal battery life, avoid fully discharging the battery frequently. Charge the monitor regularly.
- **Storage:** If storing the device for an extended period, ensure both units are turned off and disconnected from power. Store in a cool, dry place.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No image/sound on monitor	Units not powered on; Out of range; Not paired.	Ensure both units are powered and charged. Move units closer. Re-pair units (refer to manual for specific pairing steps if needed, typically found in advanced settings).
Poor image quality/interference	Obstructions; Other 2.4GHz devices; Low battery.	Reduce distance between units. Move away from Wi-Fi routers, microwaves, or cordless phones. Charge monitor battery.
Monitor battery drains quickly	ECO mode off; Frequent use.	Activate ECO mode to save power. Reduce screen brightness.
Two-way audio not working	Volume too low; Microphone/speaker obstruction.	Adjust volume on both units. Ensure no obstructions cover the microphone or speaker.

SPECIFICATIONS

- **Model:** B08XYQR8Z
- **Transmission Frequency:** 2.4GHz Digital Wireless
- **Monitor Screen Size:** 2.4 inches
- **Camera Features:** Night Vision, Two-Way Audio, Lullabies, Temperature Sensor, 360° Adjustable Angle
- **Monitor Features:** 2x Digital Zoom, ECO Mode (VOX), Feeding Timer, Multi-Camera Support (up to 4 cameras, sold separately)
- **Monitor Battery:** 1 Lithium-ion battery (included)
- **Power Supply:** DC 5V/0.7A via included power adapters
- **Item Weight:** Approximately 500 g
- **Package Dimensions:** 18 x 17.6 x 7.8 cm
- **First Available Date:** March 4, 2021

WARRANTY AND SUPPORT

YISSVIC products are designed and manufactured to the highest quality standards. This product is covered by a standard manufacturer's warranty. For detailed warranty information, technical support, or service inquiries, please refer to the contact information provided with your purchase or visit the official YISSVIC website. Please have your model number (B08XYQR8Z) ready when contacting support.

